
Fantastic Furniture

Version 1.0





Sonoma

Clothes Rack Large

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love

Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a $250 Fantastic Furniture Gift Card!
@fantasticfurniture

Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious of fatal injury, a wall strap has been provided with this product to prevent topping. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Weight Limit: 20kgs per shelf


Assembly Checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.


! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

! Please see page 2 for any safety requirements or weight restrictions.

What You Need

to assemble the product




Other tools you need
Phillips Head Screwdriver

Parts list

Box 1:

Large Top Panel (P1)
2 x Large Shelf Panels (P2)
Small Top Panel (P3)
5 x Small Shelf Panels (P4)
Top Left Frame (P5)
Lower Left Frame (P6)
4 x Back Supports (P7)
2 x Hanging Rails (P8)
Top Right Frame (P9)
Lower Right Frame (P10)
Top Middle Frame (P11)
Lower Middle Frame (P12)



Hardware Pack :


6 x Adjustable Feet (H1)


11 x Screws (H2)


49 x Screws (H3)


2 x Nuts (H4)


1 x Allen Key (H5)


2 x Wall Straps (H6)


2 x Wall Strap Screws (H7)


4 x Washers (H8)


1 x Wrench (H9)


Step 1

You will need	
	
6 x Adjustable Feet (H1)	4 x Screws (H3)
	
Allen Key (H5)	

Attach Top & Lower Left Frames (P5&P6) with 2 x Screws (H3) by tightening with the Allen Key (H5).
Repeat steps for Top & Lower Right Frames (P9&P10).
Secure 4 x Adjustable Feet (H1) to the bottom of Lower Left & Right Frames (P6&P10) as shown.

Step 2


You will need	
	
2 x Adjustable Feet (H1)	2 x Screws (H3)
	
Allen Key (H5)	



Attach Top & Lower Middle Frames (P11&P12) with 2 x Screws (H3) by tightening with the Allen Key (H5). Secure 2 x Adjustable Feet (H1) to the bottom of Lower Middle Frame (P12) as shown.

Step 3


You will need	
	
12 x Screws (H3)	Allen Key (H5)



Attach Top & Lower Left Frames (P5&P6) and Top & Lower Middle Frames (P11&P12) to Large Top Panel (P1) and Large Shelf Panels (P2x2) with 12 x Screws (H3) as shown by tightening with the Allen Key (H5).

Step 4

You will need	
	
4 x Screws (H3)	Allen Key (H5)



Secure Hanging Rails (P8x2) to Top & Lower Left Frames (P5&P6) and Top & Lower Middle Frames (P11&P12) with 4 x Screws (H3) as shown by tightening with the Allen Key (H5).

Step 5


You will need	
	
2 x Screws (H2)	2 x Nuts (H4)
	
Allen Key (H5)	1 x Wrench (H9)

x2

Secure Back Supports (P7x2) together as shown with 1 x Nut (H4) and 1 x Screw (H2) by tightening with the Allen Key (H5) and Wrench (H9).
Repeat steps for the second set of Back Supports (P7x2).

Step 6


You will need	
	
8 x Screws (H2)	Allen Key (H5)



Attach Back Supports (P7x4) to Top & Lower Left Frames (P5&P6) and Top & Lower Middle Frames (P11&P12) as shown with 8 x Screws (H2) by tightening with the Allen Key (H5).

Step 7


You will need	
	
24 x Screws (H3)	Allen Key (H5)



Attach Small Top Panel (P3) and Small Shelf Panels (P4x5) to Top & Lower Middle Frames (P11&P12) and Top & Lower Right Frames (P9&P10) with 24 x Screws (H3) as shown by tightening with the Allen Key (H5).

Step 8

You will need	
	
2 x Wall Straps (H6)	2 x Wall Strap Screws (H7)
	
2 x Washers (H8)	Phillips head Screwdriver



Attach 2 x Wall Straps (H6) toTop Panels (P1 & P3) with 2 x Washers (H8) and 2 x Wall Strap Screws (H7) by tightening with the Phillips Head Screwdriver.


Step 9

You will need	
	
2 x Washers (H8)	

Screws and wall plugs are not provided please use appropriate fixtures for your wall.

We strongly suggest using the wall strap to prevent this unit from toppling.


Seek advice from a qualified trades person on how to attach this to your specific wall.



Move furniture to its final position, then connect the ends of 2 x Wall Straps (H6) to the wall.Make sure it is firmly attached and a snug fit.


Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



Fantastic Furniture

Version 1.0





Sonoma

Clothes Rack 2 Drawer

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love

Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a $250 Fantastic Furniture Gift Card!
@fantasticfurniture

Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious of fatal injury, a wall strap has been provided with this product to prevent topping. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Weight Limit: 20kgs per shelf


Assembly Checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

! Please see page 2 for any safety requirements or weight restrictions.


What You Need

to assemble the product



Other tools you need

Phillips Head screwdriver;Hammer



Parts list

Box 1:

Top Panel (P1)
2 x Base Rails (P2)
Top Left Frame (P3)
Lower Left Frame (P4)
Top Right Frame (P5)
Lower Right Frame (P6)
2 x Back Supports (P7)
Hanging Rail (P8)
Drawer Top Panel (P9)
Base Panel (P10)
Left Side Panel (P11)
Right Side Panel (P12)
Back Panel (P13)
2 x Drawer Fronts (P14)
2 x Drawer Left Side Panels (P15)
2 x Drawer Right Side Panels (P16)
2 x Drawer Back Panels (P17)
2 x Drawer Bottom Panels (P18)
2 x Drawer Support Panels (P19)

Hardware Pack :



4 x Adjustable Feet (H1)


5 x Screws (H2)


22 x Screws (H3)


1 x Nut (H4)


18 x Cam Nuts (H5)


18 x Cam Bolts (H6)


8 x Dowels (H7)


22 x Nails (H8)


2 x CL Runner Tracks (H9)


2 x DL Runners (H10)


2 x CR Runner Tracks (H11)


2 x DR Runners (H12)


28 x Screws (H13)


12 x Screws (H14)


1 x Allen Key (H15)


1 x Wall Strap (H16)


1 x Wall Strap Screw (H17)


2 x Washers (H18)


1 x Wrench (H19)

Step 1


You will need	
	
4 x Adustable Feet (H1)	4 x Screws (H3)
	
Allen Key (H15)	

Attach Top & Lower Left Frames (P3&P4) with 2 x Screws (H3) by tightening with the Allen Key (H15).

Repeat steps for Top & Lower Right Frames (P5&P6). Secure 4 x Adjustable Feet (H1)to the bottom of Lower Left & Right Frames (P4&P6) as shown.

Step 2

You will need	
	
8 x Screws (H3)	Allen Key (H15)



Attach Top & Lower Left Frames (P3&P4) and Top & Lower Right Frames (P5&P6) to Top Panel (P1) and Base Rails (P2x2) with 8 x Screws (H3) as shown by tightening with the Allen Key (H15).

Step 3

You will need	
	
1 x Screw (H2)	1 x Nut (H4)
	
Allen Key (H15)	1 x Wrench (H19)


Secure Back Supports (P7x2) together as shown with 1 x Nut (H4) and 1 x Screw (H2) by tightening with the Allen Key (H15) and Wrench (H19).


Step 4

You will need	
	
4 x Screws (H2)	2 x Screws (H3)
	
Allen Key (H15)	

Attach Back Supports (P7x2) to Top Left & Right Frames (P3&P5) as shown with 4 x Screws (H2) by tightening with the Allen Key (H15).
Secure Hanging Rail (P8) to Top Left & Right Frames (P3&P5) as shown with 2 x Screws (H3) by tightening with the Allen Key (H15).

Step 5


You will need	
	
4 x Cam Nuts (H5)	4 x Dowels (H7)
	
2 x CL Runner Tracks (H9)	8 x Screws (H13)
	
Phillps head Screwdriver	




Attach 2 x CL Runner Tracks (H9) to Left Side Panel (P11) with 8 x Screws (H13) as shown by tightening with the Phillips Head Screwdriver.

Insert 4 x Dowels (H7) and 4 x Cam Nuts (H5) into Left Side Panel (P11) as shown.

Step 6


You will need	
	
4 x Cam Nuts (H5)	4 x Dowels (H7)
	
2 x CR Runner Tracks (H11)	16 x Screws (H13)
	
Phillps head Screwdriver	



Attach 2 x CR Runner Tracks (H11) to Right Side Panel (P12) with 8 x Screws (H13) as shown by tightening with the Phillips Head Screwdriver.

Insert 4 x Dowels (H7) and 4 x Cam Nuts (H5) into Right Side Panel (P12) as shown.

Step 7

You will need	
	
8 x Cam Bolts (H6)	Phillps head Screwdriver

Attach 8 x Cam Bolts (H6) to Drawer Top Panel (P9) and Base Panel (P10) as shown by tightening with the Phillips Head Screwdriver.


Step 8

You will need	
	
Phillps head Screwdriver	

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Rotate the Cam Nuts so the arrows point towards the incoming Cam Bolts. Secure the Drawer Top Panel (P9) and Base Panel (P10) to Left & Right Side Panels (P11&P12) as shown by tightening 8 x Cam Nuts (H5) with the Phillips Head Screwdriver.

Step 9

You will need	
	
6 x Screws (H3)	Allen Key (H15)




Gently place the partially assembled drawer unit into the shelving frame as shown. Secure the Base Panel (P10) to Lower Left & Right Frames (P4&P6) and Base Rails (P2x2) with 6 x Screws (H3) by tightening with the Allen Key (H15).

Step 10


You will need	
	
20 x Nails (H8)	Hammer

Secure Back Panel (P13) to the back of the partially assembled drawer unit as shown with 20 x Nails, approximately 5mm from the edge, using the Hammer. Ensure the Back Panel is sitting square in the unit before securing, with about 2mm around each edge.

Step 11

You will need	
	
10 x Cam Bolts (H6)	Phillps head Screwdriver

x 2




Secure 5 x Cam Bolts (H6) to Drawer Front (P14) by tightening with the Phillips Head Screwdriver.
Repeat steps for the second Drawer.

Step 12

You will need	
	
12 x Screws (H14)	Phillps head Screwdriver


x 2



Secure Left & Right Drawer Sides (P15&P16) to Back Panel (P17) with 4 x Screws (H14) by tightening with the Phillips Head Screwdriver. Attach Drawer Support Panel (P19) to Back Panel (P17) with 2 x Screws (H14) by tightening with the Phillips Head Screwdriver.
Repeat steps for the second Drawer.

Step 13

x 2




Slide Drawer Base (P18) into the grooves of Left & Right Drawer Sides (P15&P16) and Back Panel (P17).
Repeat steps for the second Drawer.

Step 14


You will need	
	
10 x Cam Nuts (H5)	Phillps head screwdriver

This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.


x 2




Insert 5 x Cam Nuts (H5) into Left & Right Drawer Sides (P15&P16) and Drawer Support Panel (P19) as shown. Rotate the Cam Nuts so the arrows point towards the incoming Cam Bolts. Secure the Drawer Front (P14) to Drawer Lef t & Right Side Panels (P15&P16) and Drawer Support Panel (P19) as shown by tightening 5 x Cam Nuts (H15) with the Phillips Head Screwdriver.

Repeat steps for the second Drawer.

Step 15


You will need	
	
2 x DL Runners (H10)	2 x DR Runners (H12)
	
12 x Screws (H13)	Phillips head screwdriver



Secure 1 x DL Runner (H10) to Drawer Left Side Panel (P15) and 1 x DR Runner (H12) to Drawer Right Side Panel (P16) as shown with 6 x Screws (H13) by tightening with the Phillips Head Screwdriver.
Repeat steps for the second Drawer.

Step 16

You will need	
	
1 x Wall Strap (H16)	1 x Wall Strap Screw (H17)
	
1 x Washer (H18)	Phillps head Screwdriver



Attach the Wall Strap (H16) to Top Panel (P1) with 1 x Washer (H18) and 1 x Wall Strap Screw (H17) by tightening with the Phillips Head Screwdriver.
Carefully insert the assembled drawers into the unit by gently guiding the runners into the tracks.

Step 17


You will need	
	
1 x Washer (H18)	


Screws and wall plugs are not provided please use appropriate fixtures for your wall.

We strongly suggest using the wall strap to prevent this unit from toppling.

Seek advice from a qualified trades person on how to attach this to your specific wall.

Move furniture to its final position, then connect the end of Wall Strap (H16) to the wall.Make sure it is firmly attached and a snug fit.





Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.