




**Fantastic
Furniture**

Version 1.1



Buzz
Student Desk

fantasticfurniture.com.au

Recommended weight capacity: 30kg maximum.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE



Other tools you need:

Phillips head screwdriver;

Flat blade screwdriver

Soft headed mallet

Parts list

Side Panel Left (P1);


Side Panel Right (P2);

Top Panel (P3);


Back Panel (P4);

Back Support (P5);

Shelf Panel (P6);




Hardware pack



15 x Dowels
(H1)



11 x Large
Screws
(H2)



4 x Cam Bolts
(H3)





4 x Cam Nuts
(H4)




4 x Leg Studs
(H5)

Step 1



You will need	
	
15 x Wood Dowels (H1)	Soft Headed Mallet


DETAIL A



Insert 15 x Wood Dowels (H1) into panels (P1, P2, P4, P5 & P6) by gently pushing them in or tapping with a soft headed mallet.


Step 2


You will need	
	
1 x Screw (H2)	Phillips Head Screwdriver



Fix the Back Panel (P4) to the Shelf Panel (P6) and tighten with the Screw (H2) using a phillips head screwdriver.



Step 3


You will need	
	
4 x Cam Bolts (H3)	



Using a phillips head screwdriver, screw 4 x Cam Bolts (H3) into the Top Panel (P3) until tight.





Step 4


You will need	
	
5 x Screws (H2)	Phillips Head Screwdriver



Align the dowels on Shelf Panel (P6), Back Panel (P4) and Back Support (P5) to holes on Side Panel L (P1) and slot in. Fix the panels with 5 x Screws (H2) and tighten with a phillips head screwdriver.



Step 5




You will need			
			
5 x Screws (H2)	4 x Leg Studs (H5)	Phillips Head Screwdriver	Soft Headed Mallet



Fix the Side Panel R (P2) to unit by aligning dowels to matching holes and slot in. Fasten using 5 x Screws (H2) using a phillips head screwdriver. Gently tap 4 x Leg Studs (H5) to the underside of the Side Panels (P1 & P2) with a soft headed mallet as shown.


Step 6

You will need	
	
4 x Cam Nuts (H4)	Flat Blade Screwdriver



Insert 4 x Cam Nuts (H4) into holes of Side Panels (P1 & P2). Rotate the Cam Nuts (H4) so the arrows point towards the incoming Cam Bolts (H3). Align the Cam Bolts (H3) and holes on the Top Panel (P3) to the holes and dowels on panels (P1 & P2) and slot the panel on top. Tighten the Cam Nuts (H4) with a flat blade screwdriver, rotating clockwise to lock into position.

Step 7




Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.



**Fantastic
Furniture**

Version 1.0



Mini Me

Chair

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture




**Fantastic
Furniture**

Page 2


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need


to assemble the product



DO NOT USE

Parts list

Seat (P1)
Seat Plate (P2)
Gas Lift (P3)
Decoration Cap (P4)
Star Base (P5)
5 x Castors (6)



Hardware pack



4 x Bolts
(H1)




Allen Key (H2)



**Fantastic
Furniture**

Page 4


Step 1



Insert 5 x castors into the star base (P5) one at a time as shown.
Push down firmly on each castor to ensure they are fixed into position.



Step 2


Note: Make sure to remove the plastic cap from the top of gas lift.



Remove the plastic cap from the top of the gas lift (P3).
Place the decoration cap (P4) over the top of the star base (P5).
Insert the gas lift (P3) through the decoration cap (P4)
and into the star base (P5) as shown.


Step 3

You will need	
	
4 x Bolts (H1)	Allen Key (H2)




Align the holes of the seat plate (P2) to the holes of the underside of the seat (P1). Attach the seat plate (P2) to the underside of the seat (P1) with 4 x bolts (H1) using an allen key (H2).

Step 4



Position the centre on the seat plate (P2) over the top of the gas lift (P3). Carefully lower the seat (P1) onto the gas lift (P3) . Carefully and firmly press the seat down firmly to lock it into position. Check the connection is secure before sitting in the chair.

Step 5




Job Complete !

In the interest of our environment please dispose of all packaging thoughtfully.



**Fantastic
Furniture**

Version 1.1



Buzz

Utility 5 Shelf

fantasticfurniture.com.au

Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious or fatal injury, this product has been fitted with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Warning: Weight on top shelf and internal shelves not to exceed 20kg each.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture


Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE




Other tools you need:

Phillips head screwdriver;

Soft headed mallet

Parts list

Side Panel Left (P1);
Side Panel Right (P2);
Top Panel (P3);
Bottom Panel (P3);
Centre Panels (P4);
2x Back Panels (P5);
3x Shelf Panels (P6);



Hardware pack



24 x Long
Phillips Screws
(H1)



1 x Wall Strap
(H2)






1 x Pan
Head Screw
(H3)



1 x Flat
Washer
(H4)



Step 1


You will need	
	
2 x Long Phillips Screws (H1)	Phillips Head Screwdriver



Align the holes in Shelf Panel (P6) to holes in the Centre Panel (P4).
Attach the Shelf Panel (P6) to the Centre Panel (P4) with 2 x Long Phillips Screws (H1).
Tighten with a phillips head screwdriver.



Step 2


You will need	
	
4 x Long Phillips Screws (H1)	Phillips Head Screwdriver



Align the holes in 2 x Shelf Panels (P6) to the holes in the Centre Panel (P4).
Attach 2 x Shelf Panels (P6) to the Centre Panel (P4) with 4 x Long Phillips Screws (H1).
Tighten with a phillips head screwdriver.



Step 3


You will need	
	
2 x Long Phillips Screws (H1)	Phillips Head Screwdriver



Attach the Bottom Panel (P3) to the Centre Panel (P4) with 2 x Long Phillips Screws (H1). Tighten with a phillips head screwdriver.


Step 4

You will need	
	
2 x Long Phillips Screws (H1)	Phillips Head Screwdriver





Attach the Top Panel (P3) to the Centre Panel (P4) with 2 x Long Phillips Screws (H1). Tighten with a phillips head screwdriver.


Step 5



Slide 1 x Back Panel (P5) into grooves of Top Panel (P3), Centre Panel (P4) and Bottom Panel (P3).


Step 6

You will need	
	
6 x Long Phillips Screws (H1)	Phillips Head Screwdriver





Fix the Side Panel L (P1) to Panels (P3 & P6) with 6 x Long Phillips Screws (H1) . Tighten with a phillips head screwdriver.


Step 7



Slide 1 x Back Panel (P5) into grooves of Top Panel (P3), Centre Panel (P4) and Bottom Panel (P3).

Step 8



You will need	
	
8 x Long Phillips Screws (H1)	Phillips Head Screwdriver



Fix the Side Panel R (P2) to Panels (P3 & P6) with 8 x Long Phillips Screws (H1) . Tighten with a phillips head screwdriver.


Step 9

You will need			
1 x Wall Strap (H2)	1 x Flat Washer (H4)	1 x Pan Head Screw (H3)	Phillips Head Screwdriver




Attach the Wall Strap (H2) to the unit using the Flat Washer (H4) and Pan Head Screw (H3) with a phillips head screwdriver. **We strongly advise that you secure the unit to a wall using the webbing provided, to prevent the unit from toppling.**

Step 10



Move the furniture to its final position, then connect the end of the Wall Strap (H5) to the wall, ensuring it is firmly attached. Seek advice from a qualified trades person on how to attach this to your specific wall. Screws and wall plugs are not supplied. Please use appropriate fixtures for your wall.

Step 11




Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.



**Fantastic
Furniture**

Version 1.1



Buzz
Utility 3 Shelf

fantasticfurniture.com.au

Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious or fatal injury, this product has been fitted with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Warning: Weight on top shelf and internal shelves not to exceed 20kg each.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture


Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE



Other tools you need:

Phillips head screwdriver;

Soft headed mallet



Parts list

2 x Side Panels (P1);

2 x Shelf Panel 1 (P2);

2 x Shelf Panel 2 (P3);

3 x Back Panels (P4);

Hardware pack



16 x Long
Screws
(H1)



1 x Wall Strap
(H2)






1 x Pan
Head Screw
(H3)



1 x Flat
Washer
(H4)

Step 1


You will need	
	
8 x Long Screws (H1)	Phillips Head Screwdriver



Attach 2 x Shelf Panel 1 (P2) and 2 x Shelf Panel 2 (P3) to the Side Panel (P1) with 8 x Long Screws (H1) and tighten with a phillips head screwdriver.



Step 2


Ensure that the Back Panel (P4) with the warning label on the back will be at the top of the unit.



Slide 3 x Back Panels (P4) into grooves of Shelf Panel 1 (P2) and Shelf Panel 2 (P3).





Step 3


You will need	
	
8 x Long Screws (H1)	Phillips Head Screwdriver



Fix the Side Panel (P1) to Shelf Panels (P2 & P3) with 8 x Long Screws (H1) and tighten with a phillips head screwdriver.

Step 4

You will need			
			
1 x Wall Strap (H2)	1 x Flat Washer (H4)	1 x Pan Head Screw (H3)	Phillips Head Screwdriver




Attach the Wall Strap (H2) to the unit using the Flat Washer (H4) and Pan Head Screw (H3) with a phillips head screwdriver. **We strongly advise that you secure the unit to a wall using the webbing provided, to prevent the unit from toppling.**




Fantastic Furniture

Step 5



Move the furniture to its final position, then connect the end of the Wall Strap (H5) to the wall, ensuring it is firmly attached. Seek advice from a qualified trades person on how to attach this to your specific wall. Screws and wall plugs are not supplied. Please use appropriate fixtures for your wall.

Step 6



Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.