




Version 1.0



TWO PEOPLE



REQUIRED

SHUTEYE FUTON 3 STR

www.fantasticfurniture.com.au

Enjoy

Your purchase from
Australia's Best Value Furniture Store



Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.


Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need to assemble the product



DO NOT USE






Parts list

Box 1:Futon (P1);

Back Legs (P2) Front Legs (P3) .

Futon
(P1)



Back legs
2 x (P2)

Front legs
2 x (P3)




4 x Bolts
(H1)



4 x Washers
(H2)



1 x Allen key
(H3)



2 x Felts
(H4)

Step 1

You will need:



4 x Bolts
(H1)




4 x Washers
(H2)



1 x Allen key
(H3)



2 x Felts
(H4)




Screw 2 x front legs (P3) to the underside of the futon (P1) as shown.
Attach the 2 x back legs (P2) to the underside of the futon (P1) with 4 x bolts (H1) and 4 x washers (H2) using the allen key (H3).
Attach the 2 x felt stickers (H4) to the underside of the front legs (P3).

Step 2

Sofa bed to sofa


Lifting from centre



To change the futon from laying flat to a seated futon, lift the futon back from the centre and after 2 clicks it will be in an upright position.


Step 3

Sofa to sofa bed



To change the futon from a seated position to lay flat, bring the back section forward to unlock the seat and then lower it towards the floor until it lays flat.

Step 4



The futon arms can click up and down for a headrest.

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.