




**Fantastic
Furniture**

Version 1.0



Two People



Required

Sonoma

Clothes Rack 2 Drawer

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture



Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious or fatal injury, a wall strap has been provided with
this product to prevent tipping. We strongly recommend that this
product is permanently fixed to the wall or other suitable surface. Fixing
devices are not included since different surface materials require
different attachments. Please seek professional advice if you are in doubt
of what fixing device to use.

Weight Limit: 20kgs per shelf

Assembly Checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What You Need

to assemble the product



DO NOT USE




Other tools you need

Phillips Head screwdriver; Hammer


Parts list

Box 1:




- Top Panel (P1)
- 2 x Base Rails (P2)
- Top Left Frame (P3)
- Lower Left Frame (P4)
- Top Right Frame (P5)
- Lower Right Frame (P6)
- 2 x Back Supports (P7)
- Hanging Rail (P8)
- Drawer Top Panel (P9)
- Base Panel (P10)
- Left Side Panel (P11)
- Right Side Panel (P12)
- Back Panel (P13)
- 2 x Drawer Fronts (P14)
- 2 x Drawer Left Side Panels (P15)
- 2 x Drawer Right Side Panels (P16)
- 2 x Drawer Back Panels (P17)
- 2 x Drawer Bottom Panels (P18)
- 2 x Drawer Support Panels (P19)




Hardware Pack :



Step 1



You will need	
	
4 x Adjustable Feet (H1)	4 x Screws (H3)
	
Allen Key (H15)	




Attach Top & Lower Left Frames (P3&P4) with 2 x Screws (H3) by tightening with the Allen Key (H15).

Repeat steps for Top & Lower Right Frames (P5&P6). Secure 4 x Adjustable Feet (H1) to the bottom of Lower Left & Right Frames (P4&P6) as shown.





Step 2


You will need	
	
8 x Screws (H3)	Allen Key (H15)



Attach Top & Lower Left Frames (P3&P4) and Top & Lower Right Frames (P5&P6) to Top Panel (P1) and Base Rails (P2x2) with 8 x Screws (H3) as shown by tightening with the Allen Key (H15).




Step 3


You will need	
	
1 x Screw (H2)	1 x Nut (H4)
	
Allen Key (H15)	1 x Wrench (H19)



Secure Back Supports (P7x2) together as shown with 1 x Nut (H4) and 1 x Screw (H2) by tightening with the Allen Key (H15) and Wrench (H19).






Step 4


You will need	
	
4 x Screws (H2)	2 x Screws (H3)
	
Allen Key (H15)	



Attach Back Supports (P7x2) to Top Left & Right Frames (P3&P5) as shown with 4 x Screws (H2) by tightening with the Allen Key (H15).
Secure Hanging Rail (P8) to Top Left & Right Frames (P3&P5) as shown with 2 x Screws (H3) by tightening with the Allen Key (H15).
fantasticfurniture.com.au

Step 5






You will need	
	
4 x Cam Nuts (H5)	4 x Dowels (H7)
	
2 x CL Runner Tracks (H9)	8 x Screws (H13)
	
Phillips head Screwdriver	




Attach 2 x CL Runner Tracks (H9) to Left Side Panel (P11) with 8 x Screws (H13) as shown by tightening with the Phillips Head Screwdriver.

Insert 4 x Dowels (H7) and 4 x Cam Nuts (H5) into Left Side Panel (P11) as shown.

Step 6



You will need	
	
4 x Cam Nuts (H5)	4 x Dowels (H7)
	
2 x CR Runner Tracks (H11)	16 x Screws (H13)
	
Phillips head Screwdriver	




Attach 2 x CR Runner Tracks (H11) to Right Side Panel (P12) with 8 x Screws (H13) as shown by tightening with the Phillips Head Screwdriver.

Insert 4 x Dowels (H7) and 4 x Cam Nuts (H5) into Right Side Panel (P12) as shown.


Step 7



You will need	
	
8 x Cam Bolts (H6)	Phillips head Screwdriver



Attach 8 x Cam Bolts (H6) to Drawer Top Panel (P9) and Base Panel (P10) as shown by tightening with the Phillips Head Screwdriver.



Step 8


You will need	
	
Phillips head Screwdriver	



Rotate the Cam Nuts so the arrows point towards the incoming Cam Bolts. Secure the Drawer Top Panel (P9) and Base Panel (P10) to Left & Right Side Panels (P11&P12) as shown by tightening 8 x Cam Nuts (H5) with the Phillips Head Screwdriver.



Step 9


You will need	
	
6 x Screws (H3)	Allen Key (H15)



Gently place the partially assembled drawer unit into the shelving frame as shown. Secure the Base Panel (P10) to Lower Left & Right Frames (P4&P6) and Base Rails (P2x2) with 6 x Screws (H3) by tightening with the Allen Key (H15).



Step 10

You will need	
	
20 x Nails (H8)	Hammer




Secure Back Panel (P13) to the back of the partially assembled drawer unit as shown with 20 x Nails, approximately 5mm from the edge, using the Hammer. Ensure the Back Panel is sitting square in the unit before securing, with about 2mm around each edge.

Step 11



You will need	
	
10 x Cam Bolts (H6)	Phillips head Screwdriver

x 2




Secure 5 x Cam Bolts (H6) to Drawer Front (P14) by tightening with the Phillips Head Screwdriver.
Repeat steps for the second Drawer.

Step 12

You will need	
	
12 x Screws (H14)	Phillips head Screwdriver


x 2



Secure Left & Right Drawer Sides (P15&P16) to Back Panel (P17) with 4 x Screws (H14) by tightening with the Phillips Head Screwdriver. Attach Drawer Support Panel (P19) to Back Panel (P17) with 2 x Screws (H14) by tightening with the Phillips Head Screwdriver.
Repeat steps for the second Drawer.

Step 13



x 2



Slide Drawer Base (P18) into the grooves of Left & Right Drawer Sides (P15&P16) and Back Panel (P17).
Repeat steps for the second Drawer.

Step 14

You will need	
10 x Cam Nuts (H5)	Phillips head screwdriver








Insert 5 x Cam Nuts (H5) into Left & Right Drawer Sides (P15&P16) and Drawer Support Panel (P19) as shown. Rotate the Cam Nuts so the arrows point towards the incoming Cam Bolts. Secure the Drawer Front (P14) to Drawer Left & Right Side Panels (P15&P16) and Drawer Support Panel (P19) as shown by tightening 5 x Cam Nuts (H5) with the Phillips Head Screwdriver.

Repeat steps for the second Drawer.

fantasticfurniture.com.au





Step 15


You will need	
	
2 x DL Runners (H10)	2 x DR Runners (H12)
	
12 x Screws (H13)	Phillips head screwdriver



Secure 1 x DL Runner (H10) to Drawer Left Side Panel (P15) and 1 x DR Runner (H12) to Drawer Right Side Panel (P16) as shown with 6 x Screws (H13) by tightening with the Phillips Head Screwdriver.
Repeat steps for the second Drawer.


Step 16

You will need	
	
1 x Wall Strap (H16)	1 x Wall Strap Screw (H17)
	
1 x Washer (H18)	Phillips head Screwdriver



Attach the Wall Strap (H16) to Top Panel (P1) with 1 x Washer (H18) and 1 x Wall Strap Screw (H17) by tightening with the Phillips Head Screwdriver.
Carefully insert the assembled drawers into the unit by gently guiding the runners into the tracks.
fantasticfurniture.com.au

Step 17



You will need	
	
1 x Washer (H18)	

Screws and wall plugs are not provided please use appropriate fixtures for your wall.

We strongly suggest using the wall strap to prevent this unit from toppling.

Seek advice from a qualified trades person on how to attach this to your specific wall.

Move furniture to its final position, then connect the end of Wall Strap (H16) to the wall. Make sure it is firmly attached and a snug fit.




Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



**Fantastic
Furniture**

Version 1.0



Two People



Required

Sonoma

Utility 3 Shelf

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture



Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious or fatal injury, a wall strap has been provided with
this product to prevent tipping. We strongly recommend that this
product is permanently fixed to the wall or other suitable surface. Fixing
devices are not included since different surface materials require
different attachments. Please seek professional advice if you are in doubt
of what fixing device to use.

Weight Limit: 20kgs per shelf


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What You Need

to assemble the product




DO NOT USE



Other tools you need

Phillips Head screwdriver



Parts list

Box 1:

- Top Panel (P1)
- 2 x Shelf Panels (P2)
- Left Side Frame (P3)
- Right Side Frame (P4)
- 2 x Back Supports (P5)

Hardware Pack :



4 x Adjustable Feet (H1)



5 x Screws (H2)



12 x Screws (H3)



1 x Nut (H4)



1 x Allen Key (H5)



1 x Wall Strap (H6)



1 x Wall Strap Screw (H7)





2 x Washers (H8)



1 x Wrench (H9)



Step 1

You will need	
	
4 x Adjustable Feet (H1)	




Secure 4 x Adjustable Feet (H1) to the bottom of Left & Right Side Frames (P3&P4) as shown.

Step 2





You will need	
	
12 x Screws (H3)	Allen Key (H5)


Ensure the top panel is rotated so the pre-drilled hole is facing underneath the unit.



Attach Top Panel (P1) and Shelf Panels (P2x2) to Left & Right Side Frames (P3&P4) with 12 x Screws (H3) by tightening with the Allen Key (H5).



Step 3


You will need	
	
1 x Screw (H2)	1 x Nut (H4)
	
Allen Key (H5)	1 x Wrench (H9)



Secure Back Supports (P5×2) together as shown with 1 x Nut (H4) and 1 x Screw (H2) by tightening with the Allen Key (H5) and Wrench (H9).





Step 4


You will need	
	
4 x Screw (H2)	Allen Key (H5)



Attach Back Supports (P5×2) to Left & Right Side Frames (P3&P4) as shown with 4 x Screws (H2) by tightening with the Allen Key (H5).


Step 5

You will need	
	
1 x Wall Strap (H6)	1 x Wall Strap Screw (H7)
	
1 x Washer (H8)	Phillips head screwdriver



Attach the Wall Strap (H6) to Top Panel (P1) with 1 x Washer (H8) and 1 x Wall Strap Screw (H7) by tightening with the Phillips Head Screwdriver.


Step 6

You will need	
	
1 x Washer (H8)	

Screws and wall plugs are not provided please use appropriate fixtures for your wall.

We strongly suggest using the wall strap to prevent this unit from toppling.

Seek advice from a qualified trades person on how to attach this to your specific wall.



Move furniture to its final position, then connect the end of Wall Strap (H6) to the wall. Make sure it is firmly attached and a snug fit.

Job Complete!

In the interest of our environment
please dispose of all
packaging thoughtfully.

