




**Fantastic
Furniture**



Marley

Chair 1 Seater + Foot Stool

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture


Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE



Parts list

Armchair (P1);
Foot Stool (P2);
8 x Wooden Legs (P3);



(P3)




(P3)



(P3)



(P3)



(P2)



(P3)



(P3)




(P3)



(P3)

Hardware pack







8x Bolts
(H1)

8 x Flat
Washers
(H2)


1 x Allen
Key
(H3)

Step 1





You will need	
	
4 x Bolts (H1)	4 x Flat Washers (H2)
	
1 x Allen Key (H3)	4 x Wooden Legs (P3)

To attach a leg to the armchair, first fix the dowel in the leg into the side hole on the underside of the armchair. Then screw 1 x bolt (H1) and 1 x washer (H2) by using the allen key as shown. Repeat this for the remaining legs. Ensure to tighten bolts fully.

If the bolt can't be fitted into the hole well, please slope the leg until the bolt can be inserted into the hole completely as shown, then screw the bolt to the bottom.




Step 2


You will need	
	
4 x Bolts (H1)	4 x Flat Washers (H2)
	
1 x Allen Key (H3)	4 x Wooden Legs (P3)

To attach a leg to the foot stool, first fix the dowel in the leg into the side hole on the underside of the foot stool. Then screw 1 x bolt (H1) and 1 x washer (H2) by using the allen key as shown. Repeat this for the remaining legs. Ensure to tighten bolts fully.

If the bolt can't be fitted into the hole well, please slope the leg until the bolt can be inserted into the hole completely as shown, then screw the bolt to the bottom.



Step 3



Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.