



Version 1.0







Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!


@fantasticfurniture




Assembly checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



before you begin assembly.



Identify and lay out all of the components Unless instructed, do not fully tighten screws until the item is fully assembled.


Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need


to assemble the product







- 1 x Top Rail (P5);
- 1 x Top Rail (P6);
- 1 x Middle Rail (P7);
- 1 x Rack Base (P8);

Hardware pack





Attach the Top Rails (P5&P6) to the Middle Rail (P7) as shown. Ensure the metal tabs on the Top Rails (P5&P6) and Middle Rail (P7) are rotated into shown position.




Attach the assembled Top and Middle Rails (P5,P6&P7) and the Bottom Rails (P4x2) to the End Frame Left & Right (P2&P3) as shown.


Ensure the metal tabs on the Top Rails and Middle Rail (P5,P6&P7) and the End Frame Right (P2) are rotated into shown position.

Fantastic

Step 3




Secure the Top Rails and Middle Rail (P5,P6&P7) and the Bottom Rails (P4x2) to the End Frame Left & Right (P2&P3) with 16 x Bolts (H2) by tightening with the Allen Key (H3). Do not fully tighten Bolts, tighten only to 80 %





Attach the Rack Base (P8) to the End Frame Left (P3) and Middle Rail (P7) using Screws (H1) and Phillips Head Screwdriver



Step 5








Place the Top (P1) into the assembled frame as shown.

Secure the Top (P1) to the Top Rails and Middle Rails (P5,P6&P7) and the End Frame Right (P2) using Screws (H1) and Phillips Head Screwdriver

Tighten all Bolts (H2) to 100 % using the Allen Key (H3)

Furniture

Step 6



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.

