

Version 1.1








Dresser 6 Drawer Dusk Brown

fantasticfurniture.com.au



of what fixing device to use.

## Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



# Fantastic Furniture


### Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card! @fantasticfurniture




# Assembly checklist

Read through the instructions carefully before you begin.





Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.

Unless instructed, do not fully tighten screws until the item is fully assembled.

### **Useful Information**

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.


! Please see page 2 for any safety requirements or weight restrictions.




fantasticfurniture.com.au

### What you need

to assemble the product






### Hardware pack




Please make sure you have all these parts before you start.





Turn the carton upside down (Bottom up). Open the carton and remove the pallet (P3).




Use a Soft Headed Mallet to nail the gliders (H1) into the middle of the each leg. and approximately 15mm from the front and the back side.




fantasticfurniture.com.au

### Step 3






Gently turn carton over and remove carton from dresser.



Unwrap dresser and move into final position. Seek advice from a qualified trades person on how to attach the safety strap to your specific wall.






If required to move this dresser for any reason, with assistance ensure you:

A) Fully retract the adjuster.

B) Lift and move the dresser to the new resting position.

C) Extend the adjuster such that it rests on the floor.

Moving the dresser without first retracting the adjuster may damage your dresser.



### Job Complete !

In the interest of our environment please dispose of all packing thoughtfully.

