


Version 2.0







RECOMMENDED WEIGHT CAPACITY 15 KG PER SHELF



WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been fitted with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Enjoy

Your purchase from Australia's Best Value Furniture Store



Assembly checklist




Read through the instructions carefully before you begin.



Identify and lay out all of the components before you begin assembly.



Make sure you have all the required tools. Never use power tools unless instructed.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.




What you need

to assemble the product





Phillips head screwdriver



Parts list

Box 1: Left Side Frame (P1) and Right Side Frame (P2); Top Frame Bars (P3 x 2); Bottom Frame Bars (P4 x 2); Bottom Middle Front & Back Bars (P5 & P6); Top Middle Front and Back Bars (P7 and P8); Square Frame (P9); Vertical Frame Bars (P10 x 4); Legs (P11 x 2); Horizontal Frame Bars (P12 x 2); Top and Bottom Shelves (P13 x 2); Large shelves (P14 x 2); Short shelf (P15).






NOTE: Before securing, ensure that the protruding metal screw tabs on the Top and bottom frame bars (P3 & P4) are rotated so the tabs are facing the inside of the bookcase. These will be used to secure and support the Top and bottom shelves (P13).


NOTE: During transit the metal screw tabs may become slightly bent. Ensure screw tabs on all frame bars are straight before securing screws.


(H3) can be tightened 100%



Attach Top Frame Bars (P3 x 2) to the Left Side Frame (P1) using Frame Screws (H3) by tightening with the Allen key (H4). Attach Bottom Frame Bars (P4 x 2) to the Left Side Frame (P1) using Screws (H3) by tightening with the Allen Key (H4). Repeat above steps to attach the Right Side Frame (P2).









Attach Legs (P11 x 2) and Vertical Frame Bars (P10 x 2) to Bottom Frame Bars (P4) using the Threaded Rods (H1).






NOTE: Before securing, ensure that the protruding metal screw tabs on the Bottom middle front and back frame bars (P5 & P6) are rotated so the tabs are facing the inside of the bookcase. These will be used to secure and support the Large shelf (P13).



Note: Please only tighten the frame screws (H3) 80%, when shelves have been added, the frame screws (H3) can be tightened 100 %


Attach Bottom Middle Front and Back Bars (P5 and P6) to Left Side Frame (P1)using Frame Screws (H3) by tightening with the Allen Key (H4). Ensure the screw holes on the Frame Bars (P5 and P6) are facing upwards on all bars before securing. Attach Bottom Middle Front and Back Bars (P5 and P6) to the Vertical Frame Bars (P10) using Frame Screws (H3) by tightening with the Allen Key (H4).






Attach Top Middle Front and Back Bars (P7 and P8) to Left Side Frame (P1) using Frame Screw (H3) by tightening with the Allen Key (H4). Ensure the screw holes on the Frame Bars (P7 and P8) are facing upwards on all bars before securing.





NOTE: Before securing ensure that the protruding metal screw tabs on the Square Frame (P9) are rotated so the tabs are facing the inside of the bookcase. These will be used to secure and support the Large shelf (P13).




Note: Please only tighten the frame screws (H3) 80%, when shelves have been added, the frame screws (H3) can be tightened 100 %

Attach Square Frame (P9) to the end of the Frame Bars (P5, P6, P7 and P8) using Frame Screws (H3) by tightening with the Allen Key (H4).




You will need	
Frame screw 4 × (H3)	Allen key 1 × (H4)



Note: Please only tighten the frame screws (H3) 80%, when shelves have been added, the frame screws (H3) can be tightened 100 %


Attach Vertical Frame Bars (P10 x 2) to Top Frame Bars (P3) and Top Middle Back and Front Frames (P7 and P8) using Frame Screw (H3) by tightening with the Allen Key (H4).

You will need	
Frame screw 4 × (H3)	Allen key 1 × (H4)




Note: Please only tighten the frame screws (H3) 80%, when shelves have been added, the frame screws (H3) can be tightened 100 %


Attach Horizontal Frame Bars (P12 x 2) to the Square Frame (P9) and Right Side Frame (P2) using Frame Screws (H3) by tightening with the Allen key (H4).




Place Top and Bottom shelves (P13 x 2) into the assembled top and bottom shelving frame. Place Short and Large Shelves (P14 x 2) and (P15) into the remaining shelving frames. When shelves (P13 x 2, P14 x 2 and P15) have been placed, tighten all Screws (H3) 100% by using the Allen Key (H4).




Secure all Shelves (P13 x 2, P14 x 2 and P15) to the assembled bookcase frame using Shelf Screws (H2) using Phillips Head Screwdriver.



We strongly advise that you use the wall straps provided to prevent the unit from toppling




Use the Wall Strap Screw (H8), Washer (H7) and Nut (H6) to connect the Wall Strap (H5) to the Right and Left Frames (P1 & P2) using the Allen Key (H10) and Spanner (H9).




Screws and wall plugs are not provided, please use appropriate fixtures for your wall.

Seek advice from a qualified trades person on how to attach this to your specific wall.



Step 12



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.

