




**Fantastic
Furniture**

Version 1.0



Two People



Required

Sonoma

Clothes Rack A Frame

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
[@fantasticfurniture](#)

Weight Limit: 15kgs

Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What You Need

to assemble the product



DO NOT USE



Parts list

Box 1:


- Hanging Rail (P1)
- 4 x Top Frames (P2)
- 2 x Lower Back Frames (P3)
- 2 x Lower Front Frames (P4)
- 2 x Back Supports (P5)
- 2 x Side Supports (P6)
- 2 x Base Supports (P7)
- Fabric Base (P8)

Hardware Pack :



Step 1

You will need	
	
4 x Screws (H4)	Allen Key (H6)




Attach Top Frames (P2x2) to Lower Back & Front Frames (P3&P4) with 2 x Screws (H4) by tightening with the Allen Key (H6).

Repeat for the second set of Top Frames (P2x2) and Lower Back & Front Frames (P3&P4).


Step 2

You will need	
	
2 x Screws (H2)	Allen Key (H6)



Secure Side Support (P6) and Base Supports (P7x2) to Lower Back & Front Frames (P3&P4) with 2 x Screws (H2) by tightening with the Allen Key (H6).


Step 3



Slide the Fabric Base (P8) over Base Supports (P7x2) as shown.

Step 4


You will need	
	
2 x Screws (H2)	Allen Key (H6)



Secure Side Support (P6) and Lower Back & Front Frames (P3&P4) to Base Supports (P7x2) to with 2 x Screws (H2) by tightening with the Allen Key (H6).

Step 5


You will need	
	
2 x Screws (H1)	Allen Key (H6)



Secure Hanging Rail (P1) to Top Frames (P2) with 2 x Screws (H1) by tightening with the Allen Key (H6).

Step 6


You will need	
	
1 x Screw (H3)	1 x Nut (H5)
	
Allen Key (H6)	1 x Wrench (H7)




Secure Back Supports (P5x2) together as shown with 1 x Nut (H5) and 1 x Screw (H3) by tightening with the Allen Key (H6) and Wrench (H7).
fantasticfurniture.com.au

Step 7

You will need	
	
4 x Screws (H3)	Allen Key (H6)



Secure Back Supports (P5x2) to Lower Back Frames (P3x2) with 4 x Screws (H3) by tightening with the Allen Key (H6).



Job Complete!

In the interest of our environment
please dispose of all
packaging thoughtfully.