




**Fantastic
Furniture**

Version 1.0



ELKE

CHAIR 1 STR WALNUT

fantasticfurniture.com.au

CAUTION:

Do not stand on, or use this product as a step ladder.
Use this product for seating one person at a time.
This product should be checked periodically to ensure all
components are secure and all hardware is tight.

RECOMMENDED WEIGHT CAPACITY 120 KG

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture



Assembly checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.


! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE



Parts list.

Back Rest (P1);
Leg Frame (Left) (P2);
Leg Frame (Right) (P3);
Long Corner Block (P4);
Short Corner Block (P5);
Seat Cushion (P6);
Cross Rail (P7);


Hardware Pack.




1 x Allen Key
(H1)




4 x 60mm Bolt
(H2)



2 x 50mm Bolt
(H3)



8 x 35mm Bolt
(H4)




4 x 30mm Bolt
(H5)



14 x Spring
Washer
(H6)



14 x Flat
Washer
(H7)



1 x Long Screw
(H8)






1 x Short Wood
Bolt
(H9)



4 x Wood
Button (H10)

Step 1



You will need	
	
1 x Allen Key (H1)	1 x Long Screw (H8)




ENSURE BOLT HOLES ARE FACING EACH OTHER IN FRONT AND BACK CORNERS, NOT FACING THE SIDES OF CHAIR.

Attach Leg Frame (Right) (P3) to Leg Frame (Left) (P2) using 1 x Long Screw (H8) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

Step 2





You will need	
	
1 x Allen Key (H1)	4 x 60mm Bolt (H2)




CORRECT POSITION OF BOLT HOLES AT BACK OF CHAIR.

Attach Seat Cushion (P6) to Leg Frame (P2) & (P3) using 4 x 60mm Bolt (H2) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.
fantasticfurniture.com.au





Step 3


You will need	
	
1 x Allen Key (H1)	4 x 35mm Bolt (H4)
	
4 x Spring Washer (H6)	4 x Flat Washer (H7)



Attach Short Corner Block (P5) to leg Frame (P2) & (P3) using 4 x Spring Washer (H6), 4 x Flat Washer (H7) and 4 x 35mm Bolt (H4) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

Step 4





You will need	
	
1 x Allen Key (H1)	4 x 35mm Bolt (H4)
	
4 x Spring Washer (H6)	4 x Flat Washer (H7)




Attach Long Corner Block (P4) to Leg Frame (P2) & (P3) using 4 x Spring Washer (H6), 4 x Flat Washer (H7) and 4 x 35mm Bolt (H4) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

fantasticfurniture.com.au



Step 5


You will need	
	
1 x Allen Key (H1)	2 x 50mm Bolt (H3)
	
2 x Spring Washer (H6)	2 x Flat Washer (H7)



Attach Cross Rail (P7) to Leg Frame (Right) (P3) using 2 x 50mm Bolt (H3), 2 x Spring Washer (H6) and 2 x Flat Washer (H7) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.





Step 6


You will need	
	
1 x Allen Key (H1)	1 x Short Wood Bolt (H9)



Secure Cross Rail (P7) using 1 x Short Wood Bolt (H9).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

Step 7


You will need	
	
1 x Allen Key (H1)	4 x 30mm Bolt (H5)
	
4 x Spring Washer (H6)	4 x Flat Washer (H7)




(Turn Chair upright)


Attach Back Rest (P1) to Leg Frame (P2) & (P3) using 4 x Flat Washer (H7), 4 x Spring Washer (H6), and 4 x 30mm Bolt (H5) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

Step 8

You will need

4 x Wood Button (H10)



Place chair on a flat surface and press the seat to level the legs. Tighten all screws and bolts. Attach 4 X Wood Button (H10) to Leg Frame (P2) & (P3) by pushing into hole firmly.



Job complete!

In the interest of our environment please
dispose of all packaging thoughtfully.



Version 1.0



TARA

TABLE D4 ROUND

www.fantasticfurniture.com.au

Enjoy
Your purchase from
Australia's Best Value furniture



Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.




What you need

to assemble the product



DO NOT USE



Part list

Table Top(P1);

Table Leg (P2);

Box 1 Hardware Pack.



1 x Allen Key
(H1)



8 x Bolts
(H2)









8 x Spring Washer
(H3)



8 x Flat Washer
(H4)

Step 1

You will need	
	
8 x Bolts (H2)	1 x Allen Key (H1)
	
8 x Spring Washer (H3)	8 x Flat Washer (H4)



Attach table legs (P2) table top (P1) using Bolts (H2) and Washers (H3) & (H4).
 Note : Do not tighten bolts until table is on flat surface



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.