




**Fantastic
Furniture**

Version 1.0



Two People



Required

Sonoma

Clothes Rack Large

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture



Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent tipping. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Weight Limit: 20kgs per shelf


Assembly Checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What You Need

to assemble the product



DO NOT USE




Other tools you need

Phillips Head Screwdriver

Parts list

Box 1:

Large Top Panel (P1)
 2 x Large Shelf Panels (P2)
 Small Top Panel (P3)
 5 x Small Shelf Panels (P4)
 Top Left Frame (P5)
 Lower Left Frame (P6)
 4 x Back Supports (P7)
 2 x Hanging Rails (P8)
 Top Right Frame (P9)
 Lower Right Frame (P10)
 Top Middle Frame (P11)
 Lower Middle Frame (P12)



Hardware Pack :



6 x Adjustable Feet (H1)



11 x Screws (H2)



49 x Screws (H3)



2 x Nuts (H4)



1 x Allen Key (H5)



2 x Wall Straps (H6)



2 x Wall Strap Screws (H7)







4 x Washers (H8)



1 x Wrench (H9)




Step 1


You will need	
	
6 x Adjustable Feet (H1)	4 x Screws (H3)
	
Allen Key (H5)	



Attach Top & Lower Left Frames (P5&P6) with 2 x Screws (H3) by tightening with the Allen Key (H5).
 Repeat steps for Top & Lower Right Frames (P9&P10).
 Secure 4 x Adjustable Feet (H1) to the bottom of Lower Left & Right Frames (P6&P10) as shown.



Step 2


You will need	
	
2 x Adjustable Feet (H1)	2 x Screws (H3)
	
Allen Key (H5)	



Attach Top & Lower Middle Frames (P11&P12) with 2 x Screws (H3) by tightening with the Allen Key (H5). Secure 2 x Adjustable Feet (H1) to the bottom of Lower Middle Frame (P12) as shown.



Step 3


You will need	
	
12 x Screws (H3)	Allen Key (H5)



Attach Top & Lower Left Frames (P5&P6) and Top & Lower Middle Frames (P11&P12) to Large Top Panel (P1) and Large Shelf Panels (P2x2) with 12 x Screws (H3) as shown by tightening with the Allen Key (H5).





Step 4


You will need	
	
4 x Screws (H3)	Allen Key (H5)



Secure Hanging Rails (P8x2) to Top & Lower Left Frames (P5&P6) and Top & Lower Middle Frames (P11&P12) with 4 x Screws (H3) as shown by tightening with the Allen Key (H5).

Step 5



You will need	
	
2 x Screws (H2)	2 x Nuts (H4)
	
Allen Key (H5)	1 x Wrench (H9)




Secure Back Supports (P7x2) together as shown with 1 x Nut (H4) and 1 x Screw (H2) by tightening with the Allen Key (H5) and Wrench (H9).

Repeat steps for the second set of Back Supports (P7x2).



Step 6


You will need	
	
8 x Screws (H2)	Allen Key (H5)



Attach Back Supports (P7x4) to Top & Lower Left Frames (P5&P6) and Top & Lower Middle Frames (P11&P12) as shown with 8 x Screws (H2) by tightening with the Allen Key (H5).





Step 7


You will need	
	
24 x Screws (H3)	Allen Key (H5)



Attach Small Top Panel (P3) and Small Shelf Panels (P4x5) to Top & Lower Middle Frames (P11&P12) and Top & Lower Right Frames (P9&P10) with 24 x Screws (H3) as shown by tightening with the Allen Key (H5).


Step 8

You will need	
	
2 x Wall Straps (H6)	2 x Wall Strap Screws (H7)
	
2 x Washers (H8)	Phillips head Screwdriver



Attach 2 x Wall Straps (H6) to Top Panels (P1 & P3) with 2 x Washers (H8) and 2 x Wall Strap Screws (H7) by tightening with the Phillips Head Screwdriver.

Step 9


You will need	
	
2 x Washers (H8)	

Screws and wall plugs are not provided please use appropriate fixtures for your wall.

We strongly suggest using the wall strap to prevent this unit from toppling.


Seek advice from a qualified trades person on how to attach this to your specific wall.

Move furniture to its final position, then connect the ends of 2 x Wall Straps (H6) to the wall. Make sure it is firmly attached and a snug fit.



Job Complete!


In the interest of our environment please dispose of all packaging thoughtfully.





**Fantastic
Furniture**

Version 1.0



Two People



Required

Sonoma

Utility 3 Shelf

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture



Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious or fatal injury, a wall strap has been provided with
this product to prevent tipping. We strongly recommend that this
product is permanently fixed to the wall or other suitable surface. Fixing
devices are not included since different surface materials require
different attachments. Please seek professional advice if you are in doubt
of what fixing device to use.

Weight Limit: 20kgs per shelf


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What You Need

to assemble the product




DO NOT USE



Other tools you need

Phillips Head screwdriver



Parts list

Box 1:

- Top Panel (P1)
- 2 x Shelf Panels (P2)
- Left Side Frame (P3)
- Right Side Frame (P4)
- 2 x Back Supports (P5)

Hardware Pack :



4 x Adjustable Feet (H1)



5 x Screws (H2)



12 x Screws (H3)



1 x Nut (H4)



1 x Allen Key (H5)



1 x Wall Strap (H6)



1 x Wall Strap Screw (H7)





2 x Washers (H8)



1 x Wrench (H9)



Step 1

You will need	
	
4 x Adjustable Feet (H1)	




Secure 4 x Adjustable Feet (H1) to the bottom of Left & Right Side Frames (P3&P4) as shown.

Step 2





You will need	
	
12 x Screws (H3)	Allen Key (H5)


Ensure the top panel is rotated so the pre-drilled hole is facing underneath the unit.



Attach Top Panel (P1) and Shelf Panels (P2x2) to Left & Right Side Frames (P3&P4) with 12 x Screws (H3) by tightening with the Allen Key (H5).



Step 3


You will need	
	
1 x Screw (H2)	1 x Nut (H4)
	
Allen Key (H5)	1 x Wrench (H9)



Secure Back Supports (P5×2) together as shown with 1 x Nut (H4) and 1 x Screw (H2) by tightening with the Allen Key (H5) and Wrench (H9).





Step 4


You will need	
	
4 x Screw (H2)	Allen Key (H5)



Attach Back Supports (P5×2) to Left & Right Side Frames (P3&P4) as shown with 4 x Screws (H2) by tightening with the Allen Key (H5).


Step 5

You will need	
	
1 x Wall Strap (H6)	1 x Wall Strap Screw (H7)
	
1 x Washer (H8)	Phillips head screwdriver



Attach the Wall Strap (H6) to Top Panel (P1) with 1 x Washer (H8) and 1 x Wall Strap Screw (H7) by tightening with the Phillips Head Screwdriver.


Step 6

You will need	
	
1 x Washer (H8)	

Screws and wall plugs are not provided please use appropriate fixtures for your wall.

We strongly suggest using the wall strap to prevent this unit from toppling.

Seek advice from a qualified trades person on how to attach this to your specific wall.



Move furniture to its final position, then connect the end of Wall Strap (H6) to the wall. Make sure it is firmly attached and a snug fit.

Job Complete!

In the interest of our environment
please dispose of all
packaging thoughtfully.

