

Product Care & Maintenance



Foils, Veneers and Melamine Care Instructions

We want you to enjoy your Fantastic Furniture for as long as possible, with simple care and maintenance you will extend the life of your furniture.

Dust regularly to prevent dirt build up, for regular maintenance a damp cloth is all you need. If you have stubborn dirt, use mild soapy water and dry with a soft cloth. Ensure you wipe up spills immediately. Use specialised cleaning products for chrome and stainless steel.

Do not use abrasive cleaning products and make sure your furniture is not exposed to damp or wet environments, as this may cause erosion.

Check all your furniture hardware (screws, nuts and bolts) to make sure they are not loose and tighten regularly to help keep the product looking its best for years to come.

These care instructions are a general guide – for any specific instructions check your product care label.

Product Care & Maintenance



Plastic Furniture

We want you to enjoy your Fantastic Furniture for as long as possible, with simple care and maintenance you will extend the life of your furniture.

For general maintenance dust regularly with a dry duster and wipe over with a clean damp non abrasive cloth. Use warm mild soapy water to remove stubborn stains. Avoid using scouring pads as this will cause scratches.

Protect your plastic furniture from the weather, direct sunlight and direct heat as this may cause the colours to fade and plastic to become brittle.

Check all your furniture hardware (screws, nuts and bolts) to make sure they are not loose and tighten regularly to help keep the product looking its best for years to come.

These care instructions are a general guide – for any specific instructions check your product care label.