Product Care & Maintenance

Fabric Upholstered Furniture

We want you to enjoy your Fantastic Furniture for as long as possible, with simple care and maintenance you will extend the life of your furniture.

For general maintenance regularly vacuum on a low suction setting. When dust settles it can become abrasive and cause damage to the cover.

Do not remove covers for cleaning unless otherwise stated. Blot food and drink spills immediately with a white, clean and dry cloth. Avoid rubbing and allowing these spills to dry, keep furniture in the shade away from direct heat and sunlight. If further cleaning is required use a clean cloth and mild, warm, soapy water using non coloured soap flakes. Professional cleaning is also recommended.

All covers will fade over time; however protecting your furniture from direct sunlight will avoid rapid and excessive fading from our sun's harmful UV rays. Keep your product away from direct heat sources such as fireplaces and heaters. Avoid contact with chlorine, chlorine stains are permanent and will change the colour of the material. Be careful of wet swimmers and towels after a swim in the pool! Wet towels and clothing can also cause mould growth and dye transfer as well as leave watermarks.

Check all your furniture hardware (screws, nuts and bolts) fastenings to make sure they are not loose and tighten regularly to help keep product looking its best for years to come.

These care instructions are a general guide – for any specific instructions check your product care label.

Product Care & Maintenance

Glass

We want you to enjoy your Fantastic Furniture for as long as possible, with simple care and maintenance you will extend the life of your furniture.

Glass is breakable, always handle with care. Scratches, chips, sudden changes in temperature, hairline fractures or other minor impurities may cause the glass to break suddenly and without warning.

For general maintenance dust regularly to prevent dirt build up. Use a damp cloth for general cleaning or to remove finger prints and smudges use glass cleaning products according to the manufacturer's instructions. Never use caustic or abrasive cleaning agents and do not use silicone based cleaning products.

Be careful to avoid dragging sharp and hard objects over any glass surface. Do not place very hot or very cold items directly on the glass; instead use table clothes, coasters or heat resistant mats.

Check all your furniture hardware (screws, nuts and bolts) to make sure they are not loose and tighten regularly to help keep the product looking its best for years to come. These care instructions are a general guide – for any specific instructions check your product care label.