



ASSEMBLY INSTRUCTION


(1)*1




STEP1




STEP2




(2)*1



STEP3



STEP4



Assembly instructions

1. Assembly to be carried out by a competent adult only .
2. During assembly children should be kept away from the product due to possible risk of injury .
3. Do not use this item if any components are missing or damaged .

Product information

1. This product is suitable for children between 3 to 12 years old.
2. The maximum capacity for this product is 60kg.
3. Folding and unfolding this product should only be carried out under adult supervision .
4. Where a product has a folding action or requires adjustment in use, ensure the fingers and legs are not in the way when adjusting.
5. Check all fastenings regularly to ensure that they are properly tightened.
6. This product is a child furniture , not a toy .
7. Please do not place the product under direct sunshine or places in wet and cold condition .
8. Keep away from fire.
9. Wipe clean only .
10. Important: Retain these instructions for future reference .