

Product Care & Maintenance



Polyurethane Lacquer

We want you to enjoy your Fantastic Furniture for as long as possible, with simple care and maintenance you will extend the life of your furniture.

For general maintenance dust regularly to avoid dust build up. Use a clean damp non abrasive cloth with warm mild soapy water, this will remove stubborn stains. Avoid using scouring pads and abrasive cleaners as this will cause scratches. Always clean stains and spills immediately otherwise you risk damaging the lacquer.

Use heat protecting mats for hot items. Tablecloths, placements and coaster are recommended to protect against general wear and tear.

Check all your furniture hardware (screws, nuts and bolts) to make sure they are not loose and tighten regularly to help keep the product looking its best for years to come.

These care instructions are a general guide – for any specific instructions check your product care label.

Product Care & Maintenance



Foils, Veneers and Melamine Care Instructions

We want you to enjoy your Fantastic Furniture for as long as possible, with simple care and maintenance you will extend the life of your furniture.

Dust regularly to prevent dirt build up, for regular maintenance a damp cloth is all you need. If you have stubborn dirt, use mild soapy water and dry with a soft cloth. Ensure you wipe up spills immediately. Use specialised cleaning products for chrome and stainless steel.

Do not use abrasive cleaning products and make sure your furniture is not exposed to damp or wet environments, as this may cause erosion.

Check all your furniture hardware (screws, nuts and bolts) to make sure they are not loose and tighten regularly to help keep the product looking its best for years to come.

These care instructions are a general guide – for any specific instructions check your product care label.