



FURNITURE SIZES

Choosing a slipcover size is easy - simply determine how many people can be comfortably seated on your furniture. When measuring your furniture, simply measure from arm-to-arm and choose the correct size from the chart below.




1 SEATER
outside arm to
outside arm
81cm to 109cm

sofa depth:
86cm to 95cm



2 SEATER
outside arm to
outside arm
147cm to 185cm


sofa depth:
86cm to 95cm




3 SEATER
outside arm to
outside arm
188cm to 244cm

sofa depth:
86cm to 95cm

Form Fit and Relax Fit Arm Width Guidlines




Form Fit
arm extends
to 35cm wide



Relaxed Fit
arm extends
to 31cm wide

RECLINERS AND DINING CHAIRS




1 SEATER RECLINER

around the entire back
198cm to 244cm

recliner width:
88cm to 94cm

recliner depth:
75cm to 99cm



DINING CHAIR

back height up to 106cm
seat width 47cm