Version 2.0

TWO PEOPLE REQUIRED

Seaforth
Buffet 2 Drawer

www.fantasticfurniture.com.au

⚠️

WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been provided with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Enjoy
Your purchase from
Australia's Best Value Furniture Store

**FANTASTIC FURNITURE**

Assembly checklist

Read through the instructions carefully before you begin.

Make sure you have all the required tools. Never use power tools unless instructed.

Identify and lay out all of the components before you begin assembly.

Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

! Please see page 2 for any safety requirements or weight restrictions.

# What you need

to assemble the product

Other tools you need
Phillips head screwdriver

DO NOT USE

Top
(P1)

Large shelf
(P7)

Short shelf
(P6)

Left side
(P3)

Back panel
(P8)

Right side
(P5)

Middle part
(P4)

Back panel
(P9)

Bottom
(P2)

Door
(P10)

Legs
4 x (P17)

Drawer bottom
(P16)

Drawer back
(P14)

Drawer side left
(P12)

Drawer side right
(P13)

Drawer front
(P11)

Drawer support bar
(P15)

Drawer bottom
(P16)

Drawer back
(P14)

Drawer side left
(P12)

Drawer side right
(P13)

Drawer front
(P11)

Drawer support bar
(P15)

Box 1:
Left side (P3), Middle part (P4), Right side (P5), Short shelf (P6),
Door (P10), Drawer front (P11), Drawer back (P14), Legs (P17),
Box 2:
Top (P1), Bottom (P2), Large shelf (P7), Back panels (P8 & P9),
Drawer side left (P12), Drawer side right (P13),
Drawer support bar (P15), Drawer bottom (P16),

What you need

to assemble the product

|				
Cam bolt 22 x (H1)	Cam nut 22 x (H2)	Dowel 16 x (H3)	Screw 6 x (H4)	Bolt 16 x (H5)
Screw 36 x (H6)	Screw 12 x (H7)	Slide 4 x (H8)	Screw 3 x (H9)	Handle 3 x (H10)
Hinge 2 x (H11)	Shelf support 4 x (H12)	Allen key 1 x (H13)	Back panel connector 8 x (H14)	Connector screw 12 x (H15)
Washer Ø15 2 x (H16)	Wall strap 1 x (H17)	Screw Ø3,5 x 22 1 x (H18)	Rubber pad 1 x (H19)	

Step 1

You will need

4 x Slide
(H8)

X 4

H8-1

H8-2

Separate the Drawer Slide Runners (H8-2) and Slide Tracks (H8-1) from
Slide (H8) by following the step below. Extend the Slide Runner (H8-2) all
the way forwards. Press the plastic release lever of the slide down and
the pull the slide runner (H8-2) completely out.

Step 2

You will need

12 x Screw
(H7)

H7
H7

**P14**

X 2

H7
H7

P12

P15

H7
H7

P13

Attach drawer sides (P12 and P13) to drawer back (P14).
And drawer support bar (P15) to the drawer back (P14), by
using screw (H7).

Step 3

You will need	
12 x Cam bolt (H1)	12 x Cam nut (H2)
2 x Screw (H9)	2 x Handle (H10)

X 2

H1
H1

P16

H1

H1

H1

H1

H1

H1

H1

H1

H9

H1

H1

H1

P11

H10

This is how a cam nut works........

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Screw cam bolts (H1) to the drawer front (P11).
Mount the handle (H10), by using screw (H9), Push the drawer bottom (P16)
into the drawer sides.
Insert cam nut (H2) into drawer sides and drawer support bar (P15),
rotate the cam nut, so that the arrow is facing towards the incomming cam bolts (H1).
Attach drawer front (P11) to drawer box by tightening the cam nuts clockwise.

Step 4

You will need	
4 x Slide runner (H8-2)	12 x Screw (H6)

X 2

H6
H6
H6
H8-2
H8-2
H6
H6
H6
H6
H6
H6

Attach drawer slide runner (H8-2) to the
assembled drawer by using screw (H6).
Repeat step 2, 3 and 4 for drawer no. 2.

Step 5

You will need	
4 x Slide track (H8-1)	12 x Screw (H6)

P4

P5

H8-1

H8-1

H6

H8-1

Please make sure that
the PVC covered edge
is facing outwards

Add the drawer slide track (H8-1) to the right side (P5)
and the middle part (P4), by using screw (H6).

Step 6

| You will need	
4 x Cam bolt (H1)	4 x Cam nut (H2)
4 x Dowel (H3)	

This is how a cam nut works........

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

P5

H2

H1

H2

H3

H3

H1

P7

H2

H2

H3

P4

H1

Attach each 2 x cam bolts (H1) and 2 x dowels (H3) on to panel (P4 + P5).
Insert cam nuts on to large shelf (P7), rotate the cam nut, so the arrow is
pointing towards the incomming cam bolts. Attach shelf (P7) to side panel
(P4 + P5) by tightening the cam nut clockwise.

Step 7

You will need	
6 x Cam bolt (H1)	6 x Cam nut (H2)
6 x Dowel (H3)	

P5

P7

P4

P3

H3

H3

H2

H1

H2

H1

H2

P1

H2

H3

H1

H3

H1

H3

H1

H3

H1

H3

H1

This is how a cam nut works........

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Attach 6 x cam bolts (H1) to top panel (P1). Insert 6 x dowels (H3) to top panel (P1). Insert 6 x cam nuts (H2) to panel (P3 + P4 + P5). Rotate the cam nut, so the arrow is pointing towards the incomming cam bolts. Attach panels (P3 + P4 + P5) to top panel (P1) by tightening the cam nut clockwise.

Step 8

Please make sure that the PVC covered side is facing to the front

P9

P8

Push the bottom back panel (P8) and top back panel (P9) into the buffet frame.

Step 9

You will need	
6 x Screw (H4)	6 x Dowel (H3)
1 x Allen key (H13)	

H4

H4

H4

H4

H4

H4

H13

H4

P2

H3

H3

H3

H3

H3

H3

Attach the bottom (P2) by using dowel (H3), screw (H4) and allen key (H13).

Step 10

You will need	
16 × Bolt (H5)	1 × Allen Key (H13)

Attach the legs (P17) to the buffet, by using bolt (H5) and allen key (H13).

Step 11

You will need

4 x Shelf support (H12)

Screw the shelf support (H12) to the buffet and push the short shelf into the buffet.

Step 12

You will need

4 x Screw (H6)	1 x Screw (H9)
1 x Handle (H10)	2 x Hinge (H11)

Attach the hinge (H11) to the door (P10), by using screw (H6).
Mount the handle (H10), by using screw (H9)

Step 13

(H19)

(H19)

H11 H6
H6
H6
H6

Attach the door (P10) to the buffet by using screw (H6).
Stick rubber pad (H19) on to shelf as shown.

Step 14

Move Inner Ball Bearing Track outward.

Gently Insert Slide Runner into Ball Bearing Track.

(P7)

Hole (B)

Hole (A)

Position drawer so that slide runner (H8-2) aligns with slide track (H8-1) as show, gently push drawer into closed position. The drawers can be adjusted upwards or downwards by re-installing the screw from hole (A) to hole (B)

Step 15

You will need	
8 x Back panel connector (H14)	12 x Connector Screw (H15)
1 x Wall strap (H17)	1 x Washer (H16)
1 x Screw (H18)	

(H17)

(H18)

(H16)

(H18)

(H17)

(H14)

(H14)

(H14)

(H14)

(H16)

(H14)

(H14)

(H14)

(H15)

(H15)

(H14)

(H14)

(H14)

xx

yy

If necessary, gently adjust the top panel sideways in either direction until xx and yy are equal. Fix back panel connector to grooves as shown by using screw (H15), fix backpanel to middle part by using screw (H15) as shown.

Step 16

Seek advice from a qualified trades person on how to attach this to your specific wall. wall screw and wall plug, which are not provided, please use appropriate fixture for your wall.

(H16)

(H15)

Move the buffet to final position and attach the wall strap to the wall securely, make sure it's firmly attached and a snug fit.

Step 17

TO ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN (OPTIONAL).

STEP 17.1
Open the door.


Top panel

Door · Side panel



STEP 17.2
Adjust the door panels upward or downward

1.
Unscrew 2 screws in round holes
Loosen 2 screws in oval holes a bit.

2.
MOVE DOOR UPWARD OR DOWNWARD

3.
Tighten 2 screws in oval holes.
Screw in 2 screws in round holes

STEP 17.3
Adjust the flush between door panel and side panel

1.
MOVE DOOR OUTWARD by turning this screw counter-clockwise

2.
KEEP DOOR IN RIGHT POSITION

3.
MOVE DOOR OUTWARD by turning this screw clockwise

---

STEP 17.4
Adjust the gap between door panel and side panel

1.
Loosen this screw a bit.

2.
MOVE DOOR BACK OR FORTH

3.
Re-tighten this screw.

Step 18

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully .