A

B

Note: Assembly has two options: A or B

TWO PEOPLE

REQUIRED

CABIN
King Single Loft Bed

www.fantasticfurniture.com.au

Enjoy
Your purchase from
Australia's Best Value Furniture Store

FANTASTIC FURNITURE

IMPORTANT INFORMATION

1. Children should be discouraged from playing on top of this bunk bed.
2. The bunk bed should be checked periodically by the owner to ensure that the guardrail, ladder and other components are maintained in the correct position and state of repair and that all connectors are tight.
3. The bunk bed is not to be placed near a ceiling fan unless the distance between the closest points on the ceiling fan and bunk bed is at least 2 metres.
4. Prohibit horseplay on or under bed(s).
5. Prohibit more than one person on upper bunk.
6. Use Ladder for entering and leaving upper bunk.
7. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.

IMPORTANT INFORMATION

8. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed. For example, hooks, belts and jump ropes.

Assembly checklist

Read through the instructions carefully
before you begin.

Make sure you have all the required tools.
Never use power tools unless instructed.

Identify and lay out all of the components
before you begin assembly.

Unless instructed, do not fully tighten screws
until the item is fully assembled.

Useful Information

! Never use power tools unless specifically instructed. They can damage your components or
   hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting
   components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to
   avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be
   used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighen all fasteners. Check the product care label or website for
   product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or
   components please visit our website Help Centre for further assistance.

What you need

## to assemble the product

DO NOT USE

Other tools you need
Flat head screwdriver, Phillips head
screwdriver, Hammer

39 x Cam Bolts (⌀7x35)
(H1)

43 x Cam Nuts (⌀15x12)
(H2)

2 x Cam Bolts (⌀6x64)
(H3)

56 x Dowels (L30mm)
(H4)

26 x Nuts
(H5)

32 x Bolts (M6x60)
(H6)

6 x Bolts (M6x35)
(H7)

33 x Bolts (M6x30)
(H8)

2 x Bolts (M6x12)
(H9)

4 x Bolts (M8x100)
(H10)

8 x Half Moon Nuts
(H11)

8 x Hex Nuts (M8x10)
(H12)

16 x Screws (L30mm)
(H13)

20 x Screws (L14mm)
(H14)

16 x Bolts (M4x10)
(H15)

8 x Plastic Shelf Support
(H16)

8 x Plastic Shelf Support
(H17)

4 x Hinges
(H18)

2 x Wardrobe Rail Support
(H19)

2 x Door Catch
(H20)

2 x Door Catch
(H21)

4 x Vintage Cover (⌀50)
(H22)

1 x Allen Key
(H23)

2 x Spanner
(H24)

4 x Bolts (M6x12)
(H25)

4 x White Cover (⌀50)
(H26)

Parts list
Box 1:
1 x Right Front Leg (P8);
1 x Right Middle Panel (P9);
1 x Right Back Leg (P10);
1 x Left Back Support (P16);
 1 x Left Ladder Post (P29);

Box 2:
1 x Front Bedside Down Panel (P6);
4 x Long Support Rails (P7);
2 x Short Support Rails (P11);
1 x Front Bedside Up Panel (P12);
1 x Back Bedside Panel (P17);
3 x Metal Ladder Step Support Rails (P30);
1 x Metal Support Bar (P37)

Box 3:
1 x Left Middle Panel (P13);
1 x Bookshelf Lower Shelf (P14);
1 x Bookshelf Upper Shelf (P15);
1 x Down back panel (P18);
1 x Back book shelf (P19);
1 x Desk Back Panel (P20);
1 x Desk Back Support Rail (P21);
1 x Desk Left Support Rail (P22);
1 x Desk Right Support Rail (P23);
1 x Desk Top Panel (P24);

Box 4:
1 x Wardrobe Back Panel (P1);
1 x Wardrobe Top Panel (P2);
1 x Wardrobe Bottom Panel (P3);
2 x Wardrobe Shelf (P31);
1 x Wardrobe Rail (P36);

Box 5:
1 x W right Side Panel (P5);
1 x W left Door (P32);
1 x Wardrobe Right Door (P33);
1 x Ladder Down Back Apron (P25);
1 x Ladder Down Step (P26);
1 x Ladder Middle Step (P27);
1 x Ladder Up Step (P28);

Box 6:
2 x BedBase (P34);
1 x Middle Bedbase (P35);
1 x Wardrobe Left Side Panel (P4);

Parts list

Step 1

You will need

18 x Cam Bolts (H1)	12 x Dowels (H4)
Phillips head screwdriver	
Hammer	

P5

P4

P3

P2

P1

Insert 18 x Cam Bolts (H1) to Panels (P2), (P3), (P4) & (P5)
and 12 x Dowels (H4) to Panels (P1), (P2) & (P3) as shown.

Step 2

You will need

8 x Plastic Shelf Support (H16)	2 x Door Catch (H20)
4 x Screws (H14)	Phillips head screwdriver

(H16)

P5

P4

P2

(H14)

(H20)

Insert 8 x Plastic Shelf Support (H16) to Panels (P4) & (P5).
Fix the 2 x Door Catch (H20) to (P2) with 4 x Screws (H14) by
using a Phillips head screwdriver as shown.

Fantastic FURNITURE

Step 3

You will need

4 x Cam Nuts (H2)

Phillips head screwdriver

TWO PEOPLE REQUIRED

Face up 195mm

P3

P1

P2

37mm Face bottom

Insert 4 x Cam Nuts (H2) to Panels (P1), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts, then attach (P2) & (P3) to (P1), turn the Cam Nuts clockwise to tighten.

This is how a cam Nuts works........

The head of the cam bolt goes into the open mouth of the cam Nuts. You then turn the cam Nuts so it tightens over the bolt.

Step 4

You will need

7 x Cam Nuts (H2)

Phillips head screwdriver

TWO PEOPLE REQUIRED

P3

P1

P2

P4

Insert 7 x Cam Nuts (H2) to Panels (P1), (P2) & (P3), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts. Attach (P1), (P2) & (P3) to (P4) as shown, turn the Cam Nuts clockwise to tighten.

FANTASTIC FURNITURE

Step 5

You will need

7 x Cam Nuts (H2)
Phillips head screwdriver

Insert 7 x Cam Nuts (H2) to Panels (P1), (P2) & (P3), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts. Attach (P5) to (P1), (P2) & (P3) as shown, turn the Cam Nuts clockwise to tighten.

P5

P1

P3

P2

Step 6

You will need

12 x Dowels (H4)	20 x Bolts (H8)
Phillips head screwdriver	
Hammer	

P7

P7

P17

P7

P7

P11

P13

Raw edge (Face upward)

P6

(H8)

Raw edge (Face upward)

(H4)

Insert 12 x Dowels (H4) to Panels (P6), (P17) & (P13) as shown. Attach 2 x (P7) to (P6), 2 x (P7) to (P17) and 1 x (P11) to (P13) with 20 x Bolts (H8).

Fantastic FURNITURE

Step 7

You will need	
32 x Dowels (H4)	Hammer

P15
P14
P9
P18
P25
P19
P28
P27
P22
P21
P26
P23

Insert 26 x Dowels (H4) to Panels (P9), (P14), (P15), (P18), (P19), (P20), (P21), (P22), (P25), (P26), (P27) & (P28) as shown.

Step 8

You will need
21 x Cam Bolts (H1)
Phillips head screwdriver

P19
P16
P8
P29
P12
P20

Insert 21 x Cam Bolts (H1) to Panels (P8), (P12), (P16), (P19), (P20) & (P29) by using a Phillips head screwdriver as shown.

Step 9

You will need		
4 x Bolts (H10)	8 x Half Moon Nuts(H11)	8 x Hex Nuts (H12)
2 x Spanner (H24)		

(H12)
(H11)
(H24)
(H24)
(H11)
(H10)
(H12)

P8
P9
P10

Insert 4 x Bolts (H10) between panels (P8) & (P9), (P9) & (P10) firstly, then connect (P8) & (P9), (P9) & (P10) with 8 x Half Moon Nuts (H11) and 8 x Hex Nuts (H12) by using 2 x Spanner (H24) as showing.

Step 10

You will need	
4 x Bolts (H8)	4 x Vintage Cover (H22)
4 x White Cover (H26)	Phillips head screwdriver

(H8)
(H26)
(H22)

P11
P9
P10

Raw edge
(Face upward)

Attach (P11) to (P9) with 4 x Bolts (H8) by using a Phillips head screwdriver. Then stick 4 x White Covers (H26) to the white panel holes, stick 4 x Vintage Covers to the Vintage Panel holes

Step 11

You will need	
4 x Nuts (H5)	4 x Bolts (H6)
1 x Allen Key (H23)	

Ensure the slot on nut is facing incoming bolt

P8

P6

(H5)

(H6)

(H5)

(H5)

(H6)

P4

TWO PEOPLE REQUIRED

Insert 4 x Nuts (H5) to Panel (P6). Then attach (P6) to (P4) & (P8) with 4 x Bolts (H6) by using a Allen Key.

FANTASTIC FURNITURE

Step 12

Insert 10 x Cam Nuts (H2) to Panel (P25), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts. Attach (P25), (P26), (P27), (P28) to (P29) & (P8), turn the Cam Nuts clockwise to tighten.

P28

P27

P8

P26

P25

P29

Step 13

P8

P30

P29

Attach 3 x Metal Ladder Step Support Rails (P30) with 6 x Bolts (H7) by using a Phillips head screwdriver.

Step 14

You will need

5 x Nuts (H5)	5 x Bolts (H6)
1 x Allen Key (H23)	

Insert 5 x Nuts (H5) to Panel (P12) and (P29). Then attach (P12) to (P4) & (P29) with 5 x Bolts (H6) by using a Allen Key (H23).

P12

P6

P29

P4

Step 15

You will need

2 x Nuts (H5)	2 x Bolts (H6)	1 x Allen Key (H23)

TWO PEOPLE REQUIRED

Insert 2 x Nuts (H5) to Panel (P13). Then attach (P13) to (P6) & (P12) with 2 x Bolts (H6) by using a Allen Key (H23).

P13

P12

P6

fantastic FURNITURE

Step 16

P17

P10

P13

TWO PEOPLE REQUIRED

Insert 4 x Nuts (H5) to Panel (P17). Then attach (P17) to (P10) & (P13) with 4 x Bolts (H6) by using a Allen Key (H23).

Step 17

| You will need	
3 x Nuts (H5)	3 x Bolts (H6)
1 x Allen Key (H23)	

P13

P14

P4

TWO PEOPLE REQUIRED

Insert 3 x Nuts (H5) to Panel (P14). Then attach (P14) to (P4) & (P13) with 3 x Bolts (H6) by using a Allen Key (H23).

Step 18

You will need		
2 x Cam Nuts (H2)	3 x Nuts (H5)	3 x Bolts (H6)
1 x Allen Key (H23)	Phillips head screwdriver	

P15

P13

P12

P4

(H23)

(H5)

(H6)

(H2)

(H2)

Insert 3 x Nuts (H5) to Panel (P15), then attach (P15) to (P4) & (P13) with 3 x Bolts (H6) by using a Allen Key (H23).
Insert 2 x Cam Nuts (H2) to (P15), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts, turn the Cam Nuts clockwise to tighten.

# Step 19

You will need

4 x Cam Nuts (H2)

Phillips head screwdriver

P17

P15

P13

P14

P16

Insert 4 x Cam Nuts (H2) to Panels (P14) & (P15), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts, then attach (P16) to (P14) & (P15), turn the Cam Nuts clockwise to tighten.

Step 20

You will need	
2 x Bolts (H8)	2 x Bolts (H9)
Phillips head screwdriver	
Flat head screwdriver	

P17

P16

(H8)

(H9)

Insert 2 x Bolts (H8) to panel (P16) & (P17), then lock with 2 x Bolts (H9) by using a Phillips head screwdriver and a Flat head screwdriver as shown.

Step 21

You will need

2 x Cam Nuts (H2)

2 x Cam Bolts (H3)

Phillips head screwdriver

(H3)

(H2)

120°

P5

P20

Insert (H3) half length of the bolt into the hole, then put Cam Nuts (H2) to (P20), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts, turn the Cam Nuts clockwise 120°to tighten.


Step 22

You will need

4 x Cam Nuts (H2)

Phillips head screwdriver

P18

P19

Insert 4 x Cam Nuts (H2) to panel (P18), rotate the Cam Nuts, so the arrow point towards the incoming Cam Bolts, attach (P18) to (P19), turn the Cam Nuts clockwise to tighten.

Step 23

You will need		
1 x Cam Nut (H2)	5 x Nuts (H5)	5 x Bolts (H6)
1 x Allen Key (H23)		
Phillips head screwdriver		

P10

P19

P18

P20

(H2)

(H5)

(H6)

Insert 1 x Cam Nut (H2) to (P19), rotate the Cam Nut, so the arrow point towards the incoming Cam Bolts, insert 5 x Nuts (H5) to (P18) & (P19), attach (P18) & (P19) to (P10) & (P20) with 5 x Bolts (H6) by using a Allen Key, turn the Cam Nuts clockwise to tighten.

TWO PEOPLE

REQUIRED

Step 24

You will need

2 x Cam Nuts
(H2)

Phillips head
screwdriver

TWO PEOPLE

REQUIRED

P20

P5

Insert 2 x Cam Nuts (H2) to (P5),
rotate the Cam Nut, so the arrow
point towards the incoming Cam
Bolts, push (P20) tightly to (P5),
then turn the Cam Nuts clockwise
to tighten.

# *Step 25*

You will need

6 x Bolts
(H6)

1 x Allen Key
(H23)

P23

P21

P24

P22

Make sure Nuts holes face outside

Attach (P21), (P22) & (P23) to (P24) with 6 x Bolts (H6)
by using a Allen Key (H23).

Step 26

Option A

Attach (P21), (P22), (P23) & (P24) to
(P1), (P16) & (P20) with 7 x Bolts (H8)
by using a Phillips head screwdriver.

Do not fully tighten the bolts at beginning,
until all botls are well aligned.

P21

P24

P23

P22

**TWO PEOPLE
REQUIRED**

P20

P16

P1

Option B

P21

P22

P23

Step 27

| You will need	
4 x Screws (H14)	8 x Bolts (H15)
4 x Hinges (H18)	
2 x Door Catch (H21)	
Phillips head screwdriver	

(H15) (H15)

(H18)

(H14) (H14)

(H21)

P32

P33

Fix 4 x Hinges (H18) to wardrobe doors (P32) & (P33) with 8 x Bolts (H15) by using a Phillips head screwdriver as shown.
Fix 2 x Door Catch (H21) to wardrobe doors (P32) & (P33) with 4 x Screws (H14) by using a Phillips head screwdriver.

Step 28

You will need
8 x Plastic Shelf Support (H17)

(H17)

P31

x 2

Insert 8 x Plastic Shelf Support (H17) to 2 x (P31), keep the opening towards the outside aligning the holes' gap.

Step 29

P31

P31

P33

P4

P5

P32

Option A

(H15)
(H14)
(H14)
(H15)

Attention:
Before you fix Screws (H14), adjust the door panels up and down evenly.

Attach Wardrobe doors (P32) & (P33) to (P4) & (P5) with 8 x Screws (H14) and 8 x Bolts (H15) by using a Phillips head screwdriver.

TWO PEOPLE

REQUIRED

P31
P31
P33
P4
P5
P32

Option B

Step 30

Fix the Metal Support Bar (H37) with 4 x Bolts (H25) by using a Phillips head screwdriver.

| You will need	
4 x Bolts (H25)	Phillips head screwdriver

(H25)

(H25)

(H25)

P17

P37

P6

Option A

P17

P37

P6

Option B

Step 31

Lock the bedbase 2 x (P34) & 1 x (P35) with 16 x Screws (H13) by using a Phillips head screwdriver.

You will need	
16 x Screws (H13)	Phillips head screwdriver

(H16)

P34

P35

P34

84mm

84mm

Option A

84mm

84mm

## Option B

FANTASTIC FURNITURE

Step 32

Option A

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully

Step 33

You will need	
4 x Screws (H14)	2 x Wardrobe Rail Support (H19)
Phillips head screwdriver	

Wardrobe Rail
Support A (H19)

(H14)

(H14)

P36

P16

Wardrobe Rail
Support B (H19)

Option B

Fix 2 x Wardrobe Rail Support A (H19) to (P16) & (P1) with 4 x Screws (H14) by using a Phillips head screwdriver.
Across the Wardrobe Rail Support B (H19) to the Wardrobe Rail (P36), then insert the Wardrobe Rail (P36) to the Wardrobe Rail Support A (H19).
Lock 2 x Wardrobe Support B (H19) to 2 x Wardrobe Support A (H19) by hand.

Step 34

Option B

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully

Step 35

## TO ADJUST YOU DOORS TO MAKE THE GAPS MORE EVEN (OPTIONAL).

You will need

Phillips head screwdriver

**STEP 35.1
Open the door.**

Side panel

Bottom Panel

Door

**STEP 35.2
Adjust the door panels upward or downward**

Unscrew 2 screws in round holes Loosen 2 screws in oval holes a bit.

MOVE DOOR UPWARD OR DOWNWARD

Tighten 2 screws in oval holes. Screw in round holes.

**STEP 35.3
Adjust the flush between door panel and side panel**

MOVE DOOR OUTWARD by turning this screw counter-clockwise

KEEP DOOR IN RIGHT POSITION

MOVE DOOR OUTWARD by turning this screw clockwise

**STEP 35.4
Adjust the gap between door panel and side panel**

Loosen this screw a bit

MOVE DOOR BACK OR FORTH

Re-tighten this screw