




Version 1.0



HAYMAN

Cabinet 2 Door

TEMPERED GLASS SHOULD ALWAYS BE HANDLED WITH CARE

www.fantasticfurniture.com.au

Enjoy


Your purchase from
Australia's Best Value Furniture Store




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need

to assemble the product




DO NOT USE




Other tools you need

Flat head screwdriver;
Phillips head screwdriver;




Parts list

Box 1: Top Panel (P1); Left Side Panel (P2);
Right Side Panel (P3); Rail (P4);
Shelf Panel (P5); Bottom Panel (P6);
Divider (P7); Back Panels (P8);
Rail (P9); Left Door (P10);
Right Door (P11); Support Leg (P12);
Back Panel (P13); Shelf Panel (P14);



Step 1


You will need	
	
4 x Dowels (H1)	8 x Cam Bolts (H3)
	
Phillips head screwdriver	




Insert 4 x Dowels (H1) into Side Panels (P2, P3).
Attach 8 x Cam Bolts (H3) into Side Panels (P2, P3) as shown.

Step 2

You will need	
	
2 x Cam Bolts (H3)	2 x Cam Nuts (H4)
	
Phillips head screwdriver	Flat head screwdriver



This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Bottom is flash.

Attach 2 x Cam Bolts (H3) into Rail (P4) as shown.
Insert 2 x Cam Nuts (H4) into the holes of Bottom Panel (P6).
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Attach Rail (P4) to Bottom Panel (P6), then tighten the cam nuts.

Step 3


You will need	
	
4 x Cam Nuts (H4)	Flat head screwdriver



Insert 4 x Cam Nuts (H4) into the holes of Bottom Panel (P6) and Rail (P9). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Bottom Panel (P6) and Rail (P9) to Left Side Panel (P2), then tighten the cam nuts.

Step 4


You will need	
	
4 x Cam Nuts (H4)	Flat head screwdriver



Put Back Panel (P13) into the groove of Bottom Panel (P6) and Rail (P9). Insert 4 x Cam Nuts (H4) into the holes of Bottom Panel (P6) and Rail (P9). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Push Right Side Panel (P3) into place and tighten the cam nuts.


Step 5

You will need	
	
2 x Dowels (H1)	2 x Long Screws (H2)
	
4 x Screws (H13)	Phillips head screwdriver




Insert 2 x Dowels (H1) into the holes of Divider (P7).
Attach Divider (P7) to Bottom Panel (P6) with 2 x Long Screws (H2).
Attach Support Leg (P12) to Bottom Panel (P6) with 4 x Screws (H13) as shown.


Step 6



Put Back Panel (P8) into the groove of Side Panels (P2, P3) and Rail (P9).

Step 7


You will need	
	
6 x Cam Bolts (H3)	4 x Screws (H8)
	
2 x Magnetics (H9)	Phillips head screwdriver



Attach 6 x Cam Bolts (H3) into Top Panel (P1) as shown.
Attach 2 x Magnetics (H9) to Top Panel (P1) with 4 x Screws (H8).

Step 8


You will need	
	
4 x Dowels (H1)	6 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 4 x Dowels (H1) into the holes of Side Panels (P2, P3).
Insert 6 x Cam Nuts (H4) into the holes of Side Panels (P2, P3) and Divider (P7).
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Attach Top Panel (P1) and tighten the cam nuts.

Step 9


You will need	
	
10 x Timber Screws (H5)	4 x Hinges (H6)
	
2 x Magnetic Bars (H7)	Phillips head screwdriver



Attach 4 x Hinges (H6) and 2 x Magnetic Bars (H7) to Doors (P10, P11) with 10 x Timber Screws (H5).

Step 10

You will need	
	
8 x Timber Screws (H5)	2 x Handles (H11)
	
2 x Bolts (H12)	Phillips head screwdriver




Attach Left Door (P10) to Left Side Panel (P2) and Right Door (P11) to Right Side Panel (P3) with 8 x Timber Screws (H5). Tighten screws using a Phillips screwdriver.

Attach 2 x Handles (H11) to Doors (P10, P11) with 2 x Bolts (H12).

www.fantasticfurniture.com.au

Step 11

You will need	
	
8 x Shelf Pins (H10)	





Insert 8 x Shelf Pins (H10) into the holes of Side Panels (P2, P3) and Divider (P7) as shown. Insert Shelf Panels (P5, P14) into the cabinet.

Step 12

You will need	
	
1 x Safety Strap (H14)	1 x Screw (H15)
	
1 x Washer (H16)	Phillips head screwdriver


We strongly advise that you use the wall safety strap provided to prevent the unit toppling




Use 1 x Screw (H15) and 1 x Washer (H16) to connect 1 x Safety Strap (H14) on Top Panel (P1).

Step 13

You will need	
	
1 x Washer (H16)	Phillips head screwdriver
Screw and Wall Plug which are not provided. Please use appropriate fixtures for your wall.	




Seek advice from a qualified trades person on how to attach this safety strap to your specific wall.



Move the cabinet to the final position. Attach the safety strap to the wall. Make sure it is firmly attached and make sure it is snug fit.

Step 14



TEMPERED GLASS should be handled with care. Scratches, chips, sudden changes in temperature and hairline fractures may cause the glass to break. This glass is designed to break into small, relatively harmless pieces and not sharp fragments.

Good to know

- Never place extremely hot or cold objects directly onto the glass surface. This may weaken the integrity of the glass and cause it to break suddenly and without warning.
- Dropping heavy, glass, ceramic, metal or similar objects on the table may cause unseen damage to the table leading it to break suddenly and without warning.

Recommended weight capacity : 40KG.

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.