


Version 1.0





Recommended weight capacity: 30kgs on top.



#### WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Connecting attachments for your wall are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what wall connections to use.

## Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



#### Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


#### **Assembly Checklist**



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.




Identify and lay out all of the components before you begin assembly.





Unless instructed, do not fully tighten screws until the item is fully assembled.

#### **Useful Information**


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.








Attach  $4 \times \text{Cam}$  Bolts (H3) to Top Panel (P1), and attach Rail (P5) to Top Panel (P1) with  $2 \times \text{Long}$  Screws (H2) by tightening the Phillips Head Screwdriver.




Attach 1 x CL Runner Track (H6) and 1 x CR Runner Track (H7) to Left & Right Side Panels (P2&P3) with  $6 \times 5$  Screws (H5) by tightening with the Phillips Head Screwdriver.







Attach 10 x Cam Bolts (H3) to Left & Right Side Panels (P2&P3) by tightening the Phillips Head Screwdriver.



Insert 1x Dowel (H1) into Left Side Panel (P2). Insert 4 x Cam Nuts (H4) into Rail & Back Panel & Shelf Panel (P6&P4&P7) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Rail & Back Panel & Shelf Panel (P6&P4&P7) to Left Side Panel (P2) by tightening all cam nuts with the Phillips Head







Insert 1x Dowel (H1) into Right Side Panel (P3). Insert 4 x Cam Nuts (H4) into Rail & Back Panel & Shelf Panel (P6&P4&P7) as shown. Rotate

the cam nuts so the arrows point towards the incoming cam bolts. Attach Rail & Back Panel & Shelf Panel (P6&P4&P7) to Right Side Panel (P3) by tightening all cam nuts with the Phillips Head Screwdriver.


#### Step 6



Insert 4 x Cam Nuts (H4) into
Left & Right Side Panel (P2&P3)
as shown. Rotate the cam nuts so
the arrows point towards the incoming
cam bolts. Attach Top Panel (P1) to Left &
Right Side Panel (P2&P3) by tightening all cam
nuts with the Phillips Head Screwdriver.









Use 1 x Safety Screw (H14) and 1 x Washer (H15) to connect 1 x Safety Strap (H14) on Back Panel (P4) by tightening with the Phillips head screwdriver.

#### Step 8







Attach 4 x Cam Bolts (H3) to Drawer Front (P8). Tighten with a Phillips Head Screwdriver.



Insert 4 x Cam Nuts (H4) into Left&Right
Drawer Side (P9&P10) as shown. Rotate
the cam nuts so the arrows point towards
the incoming cam bolts. Attach Drawer Front (P8)
to Left&Right Drawer Side (P9&P10) by
tightening all cam nuts with the Phillips Head Screwdriver.



#### Step 10





Slide the Drawer Base (P11) into the grooves between drawer sides as shown.


#### Step 11



Attach Drawer Back (P12) to Left & Right
Drawer Side (P9&P10) with 4 x Screws (H12)
by tightening with the Phillips Head Screwdriver.
Ensure the Drawer Base lines up with the grooves the whole way aroundthe drawer before securing.










Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P9) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P10) with  $4 \times 5$  x Small Screws (H5) by tightening with the Phillips Head Screwdriver.

#### Step 13






Attach 1 x Handle (H10) to Drawer Front (P8) with 1 x Handle Bolt (H11) by tightening with the Phillips Head Screwdriver.




Insert the assembled drawers into the corresponding compartments as shown. Ensure the drawers slide easily along the rails.



Move the dresser to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.





### Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.