




**Fantastic
Furniture**

Version 1.0



TWO PEOPLE



REQUIRED

Palermo

Buffet 3 Door Walnut

fantasticfurniture.com.au



Warning: Ensure the wall strap is attached to avoid serious injury.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE




Other tools you need:







Phillips head screwdriver;
Hammer




Hardware Pack



Step 1


You will need:	
	
12 x Short Bolts (H8)	16 x Washers (H7)
	
4 x Long Bolts (H6)	1 x Allen Key (H9)
	
4 x Levelling Feet (H10)	2 x Felt Pads (H13)



Stick 2 x Felt Pads (H13) to the centre of Support Rails (P15)
 Align and position 4 x Legs (P14) with the pre-drilled holes on the Bottom Panel (P2).
 Align and position the 2 x Support Rails (P15) between the Legs (P14) as shown.
 Ensuring the side with the Felt Pads (H13) is on the Bottom Panel (P2)
 Using 3 x Washers (H7) and 3 x Short Bolts (H8), secure 1 x Leg (P14) to the Bottom Panel (P2), tightening using the Allen Key (H9).
 Secure the Support Rails (P15) to the Leg (P14) and Bottom Panel (P2) using 1 x Washer (H7) and 1 x Long Bolt (H6), tightening using the Allen Key (H9).
 Repeat this step for the other 3 x Legs (P14).

Step 2


You will need:	
	
6 x Cam Bolts (H1)	6 x Dowels (H3)
	
Phillips Head Screwdriver	



Insert 6 x Dowels (H3) into Bottom Panel (P2).
 Secure 6 x Cam Bolts (H1) into Bottom Panel (P2),
 tightening using a Phillips Head Screwdriver.

Step 3

You will need:	
	
8 x Cam Bolts (H1)	8 x Dowels (H3)
	
Phillips Head Screwdriver	




Insert 2 x Dowels(H3) into Right Panel(P3) and secure 2 x Cam Bolts(H1) to Right Panel(P3) by tightening with a Phillips Head Screwdriver.


Repeat for Left Panel (P4)

Insert 2 x Dowels(H3) into Middle Panel(P5) and secure 2 x Cam Bolts(H1) to Middle Panel(P5) by tightening with a Phillips Head Screwdriver,
Turn the Middle Panel (P5) over repeat the previous step.


Step 4

You will need:	
	
2 x Cam Nuts (H2)	Phillips Head Screwdriver

This is how a cam nut works.....




The head of the bolt goes into the wide mouth of the cam nut. You then turn the nut so the narrow part closes over the bolt.




Insert 2 x Cam Nuts(H2) into Short Shelf(P9) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Attach Short Shelf(P9) to Right Panel(P3) by tightening the cam nuts(H2) with the Phillips Head Screwdriver

Step 5

You will need:	
	
2 x Dowels (H3)	



Insert 2 x Dowels(H3)into Right Panel(P3) and connect Short Support(P7) to Right Panel(P3).


Step 6

You will need:	
	
2 x Dowels (H15)	2 x Cam Nuts (H2)
	
Phillips Head Screwdriver	

This is how a cam nut works.....



The head of the bolt goes into the wide mouth of the cam nut. You then turn the nut so the narrow part closes over the bolt.



Insert 2 x Dowels(H15) into Middle Panel(P5)
 Insert 2 x Cam Nuts(H2) into Short Shelf(P9) as shown.
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Align the Short Shelf (P9) with the Middle Panel (P5) and Short Support (P7) as shown. Attach together by tightening the Cam Nuts (H2) on the Short Shelf (P9) by turning clockwise with the Phillips Head Screwdriver.
fantasticfurniture.com.au

Step 7


You will need:

	
2 x Cam Nuts (H2)	Phillips Head Screwdriver

This is how a cam nut works.....



The head of the bolt goes into the wide mouth of the cam nut. You then turn the nut so the narrow part closes over the bolt.



Insert 2 x Cam Nuts(H2) into Long Shelf(P8) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Long Shelf (P8) to Middle Panel (P5) ensuring the groove on the Long Shelf (P8) is positioned as shown. Secure the panel by turning the Cam Nuts (H2) clockwise to lock using the Phillips Head Screwdriver.

Step 8


You will need:

	
2 x Cam Nuts (H2)	2 x Dowels (H3)
	
Phillips Head Screwdriver	

This is how a cam nut works.....




The head of the bolt goes into the wide mouth of the cam nut. You then turn the nut so the narrow part closes over the bolt.





Connect Long Support(P6) to Middle Panel(P5) using the Dowels (H15) on the Middle Panel (P5). Insert 2 x Dowels(H3) into Left Panel(P4). Insert 2 x Cam Nuts(H2) into Long Shelf(P8) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Align the Left Panel (P4) with the Long Support (P6) and Long Shelf (P8) as shown. Attach together by tightening the Cam Nuts (H2) in the Long Shelf (P8) by turning clockwise to lock using the Phillips Head Screwdriver.


Step 9



With assistance, carefully turn the assembled frame upright.
Slide 1 x Long Back Panel (P10) through the grooves on the Left Panel (P4) and Middle Panel (P5) as shown.

Step 10

You will need:	
	
6 x Cam Bolts (H1)	6 x Dowels (H3)



Insert 6 x Dowels(H3) into Top Panel(P1) and secure 6 x Cam Bolts(H1) into Top Panel(P1) by tightening with the Phillips Head Screwdriver.

Step 11

TWO PEOPLE



You will need:



6 x Cam Nuts
(H2)





Phillips Head
Screwdriver

This is how a cam nut works.....



The head of the bolt
goes into the wide
mouth of the cam nut.
You then turn the nut
so the narrow part
closes over the bolt.




H2

Insert 6 x Cam Nuts(H2) into Panel(P3&P4&P5) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. With assistance, attach the Top Panel (P1) to the assembled frame (P3, P4, P5) as shown. Attach together by tightening the Cam Nuts (H2) on the assembled frame (P3, P4, P5) by turning clockwise using the Phillips Head Screwdriver.

Step 12



TWO PEOPLE



With assistance, carefully turn the assembled frame over. Slide the other Long Back Panel (P10) through the grooves on the Middle Panel (P5) and Left Panel (P4). Slide the Short Back Panel (P11) through the grooves on the Middle Panel (P5) and Right Panel (P3).



Step 13


You will need:	
	
6 x Cam Nuts (H2)	Phillips Head Screwdriver



Insert 6 x Cam Nuts(H2) into Panel(P3&P4&P5) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. With assistance, attach the Bottom panel (P2) to the assembled frame (P3, P4, P5) as shown. Attach together by tightening the Cam Nuts (H2) on the assembled frame (P3, P4, P5) by turning clockwise using the Phillips Head Screwdriver.



Step 14

You will need:	
	
6 x Hinges (H4)	12 x Short Screws (H5)



Attach 2 x hinges (H4) to 1 x right door (P13) using 4 x short screws (H5) as shown. Tighten using a phillips head screwdriver. Repeat this step for the other right door (P13) and the left door (P12).

Step 15




With assistance, turn the assembled unit upright.

Using 8 x Short Screws (H5), attach 1 x Right Door (P13) to the Right Panel (P3) by tightening with the Phillips Head Screwdriver. Repeating this process, attach the other Right Door (P13) to the Middle Panel (P5).






Repeat this process to attach the Left Door (P12) to the Left Panel (P4).

Step 16

TO ADJUST YOU DOORS TO MAKE THE GAPS MORE EVEN (OPTIONAL)

You will need	
	
Phillips head Screwdriver	

STEP 16.1
Open the door.







**MOVE DOOR UPWARD
OR DOWNWARD**

STEP 16.2
**Adjust the door panels
upward or downward**

Unscrew 2 screws in round
holes loosen 2 screws in
oval holes a bit.

Tighten 2 screws in
oval holes. Screw in
round holes.







MOVE DOOR OUTWARD
by turning this screw
counter-clockwise

**KEEP DOOR IN
RIGHT POSITION**

**MOVE DOOR
OUTWARD**
by turning this
screw clockwise

STEP 16.3
**Adjust the flush between
door panel and side panel**






Loosen this screw a bit


**MOVE DOOR
BACK OR FORTH**

Re-tighten this screw

STEP 16.4
**Adjust the gap between door
panel and side panel**




Step 17


You will need:	
	
12 x Wedges (H11)	12 x Short Screws (H5)
	
Phillips Head Screwdriver	



Insert 12 x Wedges (H11) into all corners of the back of the assembled unit as shown. Secure the 12 x Wedges (H11) to the assembled unit using 12 x Short Screws (H5), tightening with the Phillips Head Screwdriver.

Step 18

You will need:	
	
2 x Long Screws (H12)	2 x Washers (H16)
	
2 x Wall Straps (H14)	



We strongly advise that you use the wall strap provided to prevent the unit topping

Use 2 x Washers (H16) and 2 x Long Screws (H12) to secure the Wall Strap (H14) to the middle of the Top Panel (P1) as shown. Tighten using the Phillips Head Screwdriver.

Step 19

You will need:




2 x Washers
(H16)


Screws and wall plugs are not provided please use appropriate fixtures for your wall.

Seek advice from a qualified trades person on how to attach this to your specific wall.

With assistance, move the buffet to its final position. Secure the 2 x Wall Straps (H17) to the wall ensuring it is firmly attached and secure.



Step 20



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.