





**Fantastic
Furniture**

Version 1.0



Two People



Required

Torkay

Lamp Table 1 Drawer White Walnut

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture

Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk bed should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you Need

To assemble the product




Other tools you need:
Phillips Head Screwdriver
Mallet (soft headed)

















Part list



- 1 x Top Panel (P1);
- 1 x Left Side (P2);
- 1 x Right Side (P3);
- 1 x Top Panel Rail (P4);
- 1 x Front Support Rail (P5);
- 1 x Bottom Shelf (P6);
- 1 x Back Panel (P7);
- 1 x Drawer Front (P8);
- 1 x Left Drawer Side (P9);
- 1 x Right Drawer Side (P10);
- 1 x Drawer Back (P11);
- 1 x Drawer Base (P12).




Hardware pack

								
21 x Large Cam Bolts (H1)	21 x Large Cam Nuts (H2)	14x Wooden Dowels (H3)	1 x Large Screws (H4)	2 x Handle Screws (H5)	1 x Handle (H6)	12 x Small Screws (H7)	4 x Medium Screws (H8)	4 x Small Cam Bolts (H9)
								
4 x Small Cam Nuts (H10)	1 x Left Runner Track (H11)	1 x Right Runner Track (H12)	1 x Left Runner (H13)	1 x Right Runner (H14)				



Step 1


You will need:	
	
7 x Large Cam Bolts (H1)	Phillips Head Screwdriver



Attach 7 x cam bolts (H1) to top panel (P1), tightening using a phillips head screwdriver.







Step 2

You will need:	
	
10 x Wooden Dowels(H3)	Mallet (soft headed)




Insert 10 x wooden dowels (H3) into the front support rail (P5) and bottom shelf (P6) and back panel (P7).







Step 3

You will need:			
	7 x Large Cam Bolts (H1)		3 x Small Screws (H7)
	2 x Wooden Dowels (H3)		Phillips Head Screwdriver
	1 x Left Runner Track (H11)		Mallet (soft headed)


Attach 7 x large cam bolts (H1) to left side (P2), tightening using a phillips head screwdriver. Insert 2 x wooden dowels (H3) into the left side (P2). Attach 1 x left runner track (H11) to left side (P2) using 3 x small screws (H7), tightening with a phillips head screwdriver. Ensure you insert the screws (H7) into the holes on the track (H11) as shown.



Step 4

You will need:			
	7 x Large Cam Bolts (H1)		3 x Small Screws (H7)
	2 x Wooden Dowels (H3)		Phillips Head Screwdriver
	1 x Right Runner Track (H12)		Mallet (soft headed)

Attach 7 x large cam bolts (H1) to right side (P3), tightening using a phillips head screwdriver. Insert 2 x wooden dowels (H3) into the right side (P3). Attach 1 x right runner track (H12) to right side (P3) using 3 x small screws (H7), tightening with a phillips head screwdriver. Ensure you insert the screws (H7) into the holes on the track (H12) as shown.



Step 5

You will need:



2 x Large
Cam Nuts (H2)




Phillips Head
Screwdriver

This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach back panel (P7) to right side (P3), ensuring the side with cam nut holes faces inwards. Insert 2 x large cam nuts (H2) into back panel (P7). Using a phillips head screwdriver, rotate the cam nut so the arrow points towards incoming cam bolts. Turn clockwise to lock.

Step 6

You will need:



1 x Large
Cam Nut (H2)




Phillips Head
Screwdriver

This is how a cam nut works.....







The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach top panel rail (P4) to right side (P3), ensuring the side with the cam nut hole faces inwards. Insert 1 x large cam nut (H2) into top panel rail (P4). Using a phillips head screwdriver, rotate the cam nut so the arrow points towards incoming cam bolt. Turn clockwise to lock.



Step 7



You will need:	
	
1 x Large Cam Nut (H2)	Phillips Head Screwdriver



Attach front support rail (P5) to right side (P3), ensuring the side with cam nuts faces down as shown. Insert 1 x large cam nut (H2) into support rail (P5). Using a phillips head screwdriver, rotate the cam nut so the arrow points towards incoming cam bolt. Turn clockwise to lock.



Step 8



You will need:	
	
3 x Large Cam Nuts (H2)	Phillips Head Screwdriver



Attach bottom shelf (P6) to right side (P3), ensuring the side with cam nut holes faces down. Insert 3 x large cam nuts (H2) into bottom shelf (P6). Using a phillips head screwdriver, rotate the cam nut so the arrow points towards incoming cam bolt. Turn clockwise to lock.


Step 9

You will need:	
	
7 x Large Cam Nuts (H2)	Phillips Head Screwdriver







With assistance, attach left side (P2) to assembled unit as shown.

Insert 7 x large cam nuts (H2) into bottom shelf panel (P6), back panel (P7), top panel rail (P4) and front support rail (P5). Using a phillips head screwdriver, rotate the cam nut so the arrow points towards incoming cam bolt. Turn clockwise to lock.




Step 10



You will need:		
		
7 x Large Cam Nuts (H2)	1 x Large Screw (H4)	Phillips Head Screwdriver




Attach top panel (P1) to assembled unit as shown. Insert 7 x large cam nuts (H2) into the side panels (P2, P3) and back panel (P7). Using a phillips head screwdriver, rotate the cam nut so the arrow points towards incoming cam bolts. Turn clockwise to lock. Attach top panel rail (P4) to top panel (P1) using 1 x large screw (H4), tightening with a phillips head screwdriver.





Step 11



You will need:	
	
4 x Small Cam bolts (H9)	Phillips Head Screwdriver



Attach 4 x small cam bolts (H9) to 1 x drawer front (P8) and tighten using a phillips head screwdriver.


Step 12

You will need:	
	
4 x Small Cam Nuts (H10)	Phillips Head Screwdriver





Attach 1 x left drawer side (P9) and 1 x right drawer side (P10) to 1 x drawer front (P8), ensuring the grooves on all the panels align. Insert 4 x small cam nuts (H10) into drawer sides (P9, P10) rotating the cam nuts so the arrow points towards the incoming cam bolts. Turn clockwise to lock using a phillips head screwdriver.


Step 13



Slide drawer base (P12) into the grooves on the drawer sides (P9, P10) and drawer front (P8).




Step 14


You will need:	
	
4 x Medium Screws(H8)	Phillips Head Screwdriver



Attach drawer back (P11) to drawer sides (P9, P10) using 4 x medium screws (H8), tightening using a phillips head screwdriver.





Step 15


You will need:		
		
2 x Handle Screws (H5)	1 x Handles (H6)	Phillips Head Screwdriver



Attach 1 x handle (H6) to drawer front using 2 x handle screws (H5).


Step 16

You will need:			
			
6 x Small Screws (H7)	1 x Left Runner (H13)	1 x Right Runner (H14)	Phillips Head Screwdriver




Attach 1 x left runner (H13) and 1 x right runner (H14) to the bottom of drawer sides (P9, P10) using 6 x small screws (H7). Ensure you insert the screws into the holes as shown.

Step 17



Slide the assembled drawer into the lamp table as shown.

Step 18



Job Complete!

In the interest of our environment please dispose
of all packing thoughtfully.