




**Fantastic  
Furniture**

Version 1.0



**Two People**



**Required**

**Java**  
**Slimboy 4 Drawer**  
[fantasticfurniture.com.au](http://fantasticfurniture.com.au)



## **Warning: Ensure the wall strap is attached to avoid serious injury**

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

## **Rattan**

Rattan is a natural material that will respond to humidity in the environment. Low humidity may cause the rattan to shrink. High humidity may cause the rattan to absorb moisture and expand, causing the weaving to look loose and wavy.

This is a natural phenomenon and not a defect.

**Recommended weight capacity: 60kgs on top**

## **Looks like you've found your Fantastic!**

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



**Fantastic  
Furniture**


## **Love it? Share it!**

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!  
**@fantasticfurniture**


# Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need

## to assemble the product




DO NOT USE



### Other tools you need


Flat Head Screwdriver;  
Phillips Head Screwdriver;  
Mallet



### Parts list

- |                           |                                |
|---------------------------|--------------------------------|
| 1 x Top Panel (P1)        | 4 x Drawer Fronts (P8)         |
| 1 x Left Side Panel (P2)  | 4 x Drawer Left Sides (P9)     |
| 1 x Right Side Panel (P3) | 4 x Drawer Right Sides (P10)   |
| 1 x Bottom Panel (P4)     | 4 x Drawer Backs (P11)         |
| 1 x Back Panel (P5)       | 4 x Drawer Support Rails (P12) |
| 1 x Rail (P6)             | 4 x Drawer bases (P13)         |
| 4 x Legs (P7)             |                                |

## Hardware Pack



30 x Cam Bolts  
(H1)



6 x Large Cam  
Nuts (H2)



10 x Dowels ø8mm  
(H3)



4 x Handles  
(H4)



4 x Felt Feet  
(H5)



10 x Screws 16mm  
(H6)



10 x Back Panel  
Connectors (H7)




8 x Bolts 55mm  
(H8)



10 x Flat Washers  
(H9)




8 x Spring  
Washers (H10)




8 x Screws 28mm  
(H11)



1 x Allen Key  
(H12)




1 x Wall Strap  
(H13)




1 x Screw 25mm  
(H14)



24 x Small Cam  
Nuts (H15)



8 x Dowels ø6mm  
(H16)



28 x Screws 38mm  
(H17)




48 x Screws 12mm  
(H18)



8 x Slides  
(H19)

# Step 1


You will need	
4 x Felt Feet (H5)	



Attach 1 x felt foot (H5) onto each leg (P7) as shown.







# Step 2

You will need	
8 x Bolts 55mm (H8)	8 x Flat Washers (H9)
8 x Spring Washers (H10)	1 x Allen Key (H12)





Attach 1 x leg (P7) onto bottom panel (P4), using 2 x bolts (H8), 2 x spring washers (H10) and 2 x flat washers (H9). Tighten the bolts with allen key (H12). Repeat this step for the other 3 x legs (P11).

## Step 3

You will need	
	
8 x Slides (H19)	12 x Screws 12mm (H18)
	
Phillips Head Screwdriver	4 x Dowels ø8mm (H3)
	
Mallet	1 x Cam Bolt (H1)

Separate the 8 x slide runners (H19-2) and slide tracks (H19-1) from the slides (H19) by following the steps below:  
 Extend the slide runner (H19-2) all the way out.  
 Press down the plastic release lever on the slide track (H19-1) and pull out the slide runner (H19-2) completely.









Attach 4 x separated slide tracks (H19-1) onto left side panel (P2) with 12 x screws (H18), using a phillips head screwdriver as shown. Ensure the slide tracks (H19-1) are attached so the rubber stopper is positioned near the grooves on left side panel (P2) as shown.


Screw 1 x cam bolt (H1) into left side panel (P2), using a phillips head screwdriver.

Insert 4 x dowels (H3) into left side panel (P2) as shown. If needed use a mallet to gently tap the dowels into place.


# Step 4

You will need	
	
4 x Slides Track (H19-1)	12 x Screws 12mm (H18)
	
Phillips Head Screwdriver	4 x Dowels ø8mm (H3)
	
Mallet	1 x Cam Bolt (H1)

Adjust runner to access the screw holes.



Please fasten the screws through these holes for this step.



Attach 4 x separated slide tracks (H19-1) onto right side panel (P3) with 12 x screws (H18) as shown, using a phillips head screwdriver.

Ensure the slide tracks (H19-1) are attached so the rubber stopper is positioned near the grooves on right side panel (P3) as shown.



Screw 1 x cam bolt (H1) into right side panel (P3), using a phillips head screwdriver.


Insert 4 x dowels (H3) into right side panel (P3) as shown.

If needed use a mallet to gently tap the dowels into place.





# Step 5


You will need	
	
2 x Dowels ø8mm (H3)	Mallet



Insert 2 x dowels (H3) into rail (P6) as shown.  
Use a mallet to gently tap the dowels into place if needed.



# Step 6



You will need	
	
2 x Large Cam Nuts (H2)	Flat Head Screwdriver



With assistance, position rail (P6) between left & right side panels (P2, P3), ensuring the grooves on left & right side panels (P2, P3) are on the same side. Insert 2 x large cam nuts (H2) into rail (P6). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Using a flat head screwdriver turn clockwise to lock.

## Step 7


You will need	
	
4 x Screws 38mm (H17)	Phillips Head Screwdriver





With assistance, position bottom panel (P4) to left & right side panels (P2, P3), ensuring the grooves on all the panels (P2, P3, P4) align. Secure the bottom panel (P4) to the left & right side panels (P2, P3) by inserting 4 x screws (H17) through the bottom panel (P4) and tighten using a phillips head screwdriver. With assistance, carefully turn the assembled frame over.


## Step 8

Unfold and slide back panel (P5) into the grooves on left & right side panels (P2, P3) and bottom panel (P4).





## Step 9


You will need	
	
4 x Cam Bolts (H1)	Phillips Head Screwdriver



Screw 4 x cam bolts (H1) into top panel (P1) as shown.  
Using a phillips head screwdriver turn clockwise to lock.




## Step 10




You will need	
	
4 x Large Cam Nuts (H2)	Flat Head Screwdriver



Attach top panel (P1) to  
left & right side panels (P2, P3) as shown.  
Insert 4 x large cam nuts (H2) into  
left & right side panels (P2, P3).  
Rotate the cam nuts so the arrows point  
towards the incoming cam bolts.  
Using a flat head screwdriver turn clockwise to lock.

# Step 11





You will need	
	
10 x Screws 16mm (H6)	10 x Back Panel Connectors (H7)
	
Phillips Head Screwdriver	




If necessary, gently adjust the top panel (P1) sideways in either direction until XX and YY are equal.

Holding it in place, fix 10 x back panel connectors (H7) to assembled unit with 10 x screws (H6) as shown, using a phillips head screwdriver.



## Step 12


You will need	
	
24 x Cam Bolts (H1)	Phillips Head Screwdriver
	
8 x Dowels ø6mm (H16)	Mallet



Screw 6 x cam bolts (H1) into drawer front (P8), using a phillips head screwdriver.  
 Insert 2 x dowels (H16) into the drawer front (P8).  
 If needed use a mallet to gently tap the dowels into place.  
 Repeat step for the other drawer fronts (P8x3).


## Step 13

You will need	
	
24 x Small Cam Nuts (H15)	Flat Head Screwdriver





Position 1 x drawer left side (P9), 1 x drawer right side (P10) and 1 x drawer support rail (P12) onto drawer front (P8). Ensure the grooves on each of the panels align.  
 Insert 6 x small cam nuts (H15) into left & right drawer sides (P9, P10) and drawer support rail (P12).  
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.  
 Using a flat head screwdriver turn clockwise to lock.

## Step 14




Slide drawer base (P13) into the grooves on drawer left & right sides (P9, P10) and drawer front (P8). Repeat this step for the other 3 x drawers.

## Step 15

You will need	
	
24 x Screws 38mm (H17)	Phillips Head Screwdriver




Ensure the pre-drilled holes on drawer left & right sides (P9, P10) align with holes on drawer back (P11), and the holes on drawer back (P11) align with the holes on drawer support rail (P12).





Attach drawer back (P11) onto an assembled drawer with 6 x screws (H17), using a phillips head screwdriver as shown. Repeat this step for the other 3 x drawers.

## Step 16




Please fasten the screws through these holes for this step.


You will need	
	
8 x Slide Runners (H19-2)	24 x Screws 12mm (H18)
	
Phillips Head Screwdriver	



Attach 2 x slide runners (H19-2) to drawer left & right sides (P9, P10) with 6 x screws (H18), using a phillips head screwdriver as shown. Repeat this step for the other 3 x drawers.




## Step 17

You will need	
	
8 x Screws 28mm (H11)	4 x Handles (H4)
	
Phillips Head Screwdriver	



Attach 1 x handle (H4) onto a drawer front (P8) with 2 x screws (H11), using a phillips head screwdriver as shown. Repeat this step for the other 3 x drawers.


## Step 18



Move inner ball bearing track to front of slide track (H19-1).



Gently insert drawer slide runner (H19-2) in between the ball bearing track.









Position drawer so that slide runners (H19-2) align with slide tracks (H19-1) as shown. Gently push drawer into the closed position.



## Step 19



We strongly recommend that this product is permanently fixed to the wall or other suitable surface.

You will need	
	
1 x Flat Washer (H9)	1 x Screw 25mm (H14)
	
1 x Wall Strap (H13)	Phillips Head Screwdriver




Fix 1 x wall strap (H13) to top panel (P1) with 1 x screw (H14) and 1 x flat washer (H9) as shown, using a phillips head screwdriver.

## Step 20

You will need	
	
1 x Flat Washer (H9)	Phillips Head Screwdriver

Two People





Required


**Seek advice from a qualified trades person on how to attach this wall strap to your specific wall.**

Screw and wall plug are not included. Please use appropriate fixtures for your wall.

With assistance, move the slimboy to its final position. Attach the wall strap to the wall with the appropriate fixtures using a phillips head screwdriver. Make sure they are firmly attached and secure.



## Step 21



# Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.