




Version 2.0



TWO PEOPLE



REQUIRED

Ashford

Tallboy 5 Drawer

www.fantasticfurniture.com.au



**WARNING: ENSURE THE WALL STRAP IS ATTACHED TO
AVOID SERIOUS INJURY.**

To avoid any serious or fatal injury, this product has been provided with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Enjoy

Your purchase from
Australia's Best Value Furniture Store



Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.
Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk bed should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.




What You Need

To Assemble the Product



(Other Tools You Need)
Phillips Head Screwdriver
Mallet


X4



Part List

Box 1:

- 1 x Top Panel (P1);
- 1 x Left Side (P2);
- 1 x Right Side (P3);
- 2 x Side Plinth (P4);
- 1 x Top Panel Rail (P5);
- 4 x Front Rail (P6);
- 1 x Front Plinth (P7);
- 1 x Front Support Rail (P8);
- 1 x Back Support Rail (P9);
- 1 x Back Panel (P11);
- 4 x Drawer Front (P12);
- 8 x Drawer Side (P13);
- 4 x Drawer Back (P14);
- 5 x Drawer Base (P15);
- 5 x Drawer Support Rail (P16);
- 1 x Large Drawer Front (P17);
- 2 x Large Drawer Side (P18);
- 1 x Large Drawer Back (P19);




Please make sure you have all these parts before you start.


Step 1

You will need:

6 x Cam bolts
(H1)



Phillips head
screwdriver



Fix 6 x Cam Bolts (H1) to Top Panel (P1) by using a Phillips head screwdriver.


Step 2

You will need:

3 x Wood
Screws
(H4)








Phillips head
screwdriver




Attach Top Panel Rail (P5) to Top Panel (P1) by using 3 Wood Screws (H4) and a Philip head screwdriver.

Step 3

You will need:

2 x Wooden Dowels (H3)	
5 x Left Runner Track (H11)	
15 x Wood Screws (H9)	
Phillips head screwdriver	
Mallet	









Insert 2 Wooden Dowels (H3) to Left Side (P2).

Fix 5 Left Runner Track (H11) to Left Side (P2) by using 15 Wood Screw (H9) and a Phillips head screwdriver.

Step 4

You will need:

2 x Wooden Dowels (H3)	
5 x Right Runner Track (H12)	
15 x Wood Screws (H9)	
Phillips head screwdriver	
Mallet	







Insert 2 Wooden Dowels (H3) to Right Side (P3).

Fix 5 Right Runner Track (H12) to Right Side (P3) by using 15 Wood Screw (H9) and a Phillips head screwdriver.

Step 5

You will need:

3 x Wood Screw (H4)	
7 x Cam bolts (H1)	
Phillips head screwdriver	







Attach Side Plinth (P4) to Left Side (P2) by using 3 Wood Screws (H4) and a Philip head screwdriver.

Fix 7 x Cam Bolts (H1) to Left Side (P2) by using a Phillips head screwdriver.

Step 6

You will need:

3 x Wood Screw (H4)	
7 x Cam bolts (H1)	
Phillips head screwdriver	



Attach Side Plinth (P4) to Right Side (P3) by using 3 Wood Screws (H4) and a Philip head screwdriver.

Fix 7 x Cam Bolts (H1) to Right Side (P3) by using a Phillips head screwdriver.


Step 7

You will need:

14 x Wooden
Dowels
(H3)



Mallet



Insert Dowels (H3) to Front Rails (P6) and Front Support Rail (P8) and Back Rail (P9) and Back Support Rail (P10).


Step 8

You will need:

4 x Wood
Screws
(H4)



Phillips head
screwdriver



Attach Front Support Rail (P8) to Front Plinth (P7) by using 3 Wood Screws (H4) and a Philip head screwdriver.

Step 9

You will need:

2 x Cam
Nut
(H2)




Phillips head
screwdriver



This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach Back Support Rail (P10) and Back Rail (P9) to Left Side (P2), insert Cam Nut (H2) into Rail(P9, P10), rotate the Cam Nuts so the arrow point towards the incoming cam bolt, turn clockwise to lock.

Step 10

You will need:


5 x Cam
Nut
(H2)




Phillips head
screwdriver



This is how a cam nut works.....





The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach Front Rails (P6) and Front Support Rail (P8) to Left Side (P2), insert Cam Nut (H2) into Rail(P6, P8), rotate the Cam Nuts so the arrow point towards the incoming cam bolt, turn clockwise to lock.

Step 11


You will need:

7 x Cam Nuts (H2)	
Phillips head screwdriver	

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach Right Side (P3) to all the Rails which already attached to Left Side (P2), insert Cam Nut (H2) into Rail(P9, P10), rotate the Cam Nuts so the arrow point towards the incoming cam bolt, turn clockwise to lock.

Step 12




Turn the unit upright carefully, slip Back Panel (P11) into the grooves on the side panels, make sure the informative label on position as the drawing shown.

Step 13


You will need:

6 x Cam Nuts (H2)	
Phillips head screwdriver	

This is how a cam nut works.....



Attach Top Panel (P1) to the unit as show on picture.
Insert Cam Nuts (H2) and use a Philip head screw driver turn clock wise to lock.




Step 14

You will need:

4 x Back Panel Support (H5)	
4 x Wood Screws (H6)	
4 x Wood Screws (H15)	
Phillips head screwdriver	

Fix Back Panel (P11) to Back Rail (P9) by using 4 Wood Screws (H15).
Fix Back Panel Support (H5) to each corner on the back by using Wood Screws (H6).



www.fantasticfurniture.com.au


Step 15

You will need:

5 x Cam bolts
(H18)



Phillips head
screwdriver



Fix small Cam Bolts (H18) to Drawer Front (P12) and Large Drawer Front (P17) by using a Phillips head screwdriver.


Step 16

You will need:

16 x Wood
Screws
(H10)



Phillips head
screwdriver



X4

Attach Drawer Side (P13) to Drawer Front (P12) by using Wood Screw (P10) and a Philip head screw driver.

Step 17

You will need:

4 x Cam
Nuts
(H19)




Phillips head
screwdriver



This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach Drawer Support Rail (P16) to Drawer Front (P12), insert small Cam Nut (H19) and use a Philip head screw driver turn clockwise to lock.

X4

Step 18



X4

Slip Drawer Base (P15) into the grooves on the Drawer Sides.




Step 19

You will need:

24 x Wood
Screws
(H10)



Phillips head
screwdriver



Use Wood Screws (H10) to fix Drawer Back panel to
Drawer Sides and Drawer Support Rails.

X4


Step 20

You will need:

24 x Wood
Screws
(H9)




4 x left
Runner
(H13)



4 x Right
Runner
(H14)



Phillips head
screwdriver







Fix Left Runner (H13) and Right Runner (H14) to drawer side panels by using
Wood Screws (H9) and a Philip head screw driver.

X4

Step 21

You will need:

16 x Screws (H7)	
8 x Handles (H8)	
Phillips head screwdriver	





Steps to assemble small drawers.


Fix Handles (H8) on drawer front by using Screws (H7).

X4

Step 22

You will need:

4 x Wood Screws (H10)	
Phillips head screwdriver	





Steps to assemble large drawer.



Attach Large Drawer Side (P18) to Drawer Front (P17) by using Wood Screw (P10) and a Philip head screw driver.

Step 23

You will need:

1 x Cam Nuts (H19)	
Phillips head screwdriver	


This is how a cam nut works.....



Steps to assemble large drawer.

Attach Drawer Support Rail (P16) to Large Drawer Front (P17), insert SmallCam Nut (H19) into Drawer Base Rail (P16), rotate the Cam Nuts so the arrow point towards the incoming cam bolt, turn clockwise to lock.

Step 24






Steps to assemble large drawer.

Slip Drawer Base (P15) into the grooves on the Drawer Sides.

Step 25

You will need:

6 x Wood Screws (H10)	
Phillips head screwdriver	








Steps to assemble large drawer.

Use Wood Screws (H10) fix the drawer box as show on picture

Step 26

You will need:

6 x Wood Screws (H9)	
1 x left Runner (H13)	
1 x Right Runner (H14)	
Phillips head screwdriver	







Steps to assembly large drawer.

Fix Left Runner (H13) and Right Runner (H14) to drawer side panels by using Wood Screws (H9) and a Philip head screw driver.

Step 27

You will need:

4 x Screws (H7)	
2 x Handles (H8)	
Phillips head screwdriver	




Steps to assemble large drawer.

Fix Handles (H8) on drawer front by using Screws (H7).

Step 28

Slide the drawers into the carcass of the tall boy, large drawer box place on the bottom, the other drawer box are the same.



Step 29

You will need:

1 x Wall Strap
(H16)



1 x Washer
(H17)




1 x Wood
Screws
(H10)



Phillips head
screwdriver





We strongly advise that you use the wall safety strap provided to prevent the unit toppling.



Fix Wall Strap (H16) to back of the Top Panel by using Wood Screw (H10) and Washer (H17).



Step 30

You will need:


1 x Washer (H17)	
Phillips head screwdriver	

Screw and Wall Plug are not provided.
Please use appropriate fixtures
for your wall.

Seek advice from a qualified
trades person on how to
attach safety strap
to the wall .



Move the Tallboy to the final
position. Attach the safety strap to
the wall. Make sure it is firmly
attached and a snug fit.



Job Complete!

In the interest of our environment
please dispose of all packing thoughtfully.