




Version 1.0



# HAVANA

Bedside 2 Drawer

[www.fantasticfurniture.com.au](http://www.fantasticfurniture.com.au)


**Enjoy**  
Your purchase from  
Australia's Best Value Furniture Store




# Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.  
Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

# What you need

to assemble the product



DO NOT USE






## Additional Tools Required

Flat head screwdriver;  
Phillips head screwdriver;  
Hammer

## Parts list

**Box 1:** Top Panel (P1);  
Left Side Panel (P2);  
Right Side Panel (P3);  
Rail (P4); Rail (P5);  
Back Panel (P6);  
LF Leg (P7); RF Leg (P8);  
LR Leg (P9); RR Leg (P10);  
2 x Drawer Front (P11);  
2 x Left Drawer Side (P12);  
2 x Right Drawer Side (P13);  
2 x Drawer Base (P14);  
2 x Drawer Back (P15);  
LF: Left Front  
LR: Left Rear  
RF: Right Front  
RR: Right Rear


## Hardware pack



20 x Dowels  
(H1)



4 x Plastic  
Glides  
(H2)



18 x Cam Bolts  
(H3)



18 x Cam Nuts  
(H4)



20 x Small  
Screws  
(H5)




2 x CL Runner  
Tracks  
(H6)




2 x CR Runner  
Tracks  
(H7)



2 x DL Runners  
(H8)



2 x DR Runners  
(H9)




8 x Small  
Cam Bolts  
(H10)



8 x Small  
Cam Nuts  
(H11)



8 x Long  
Screws  
(H12)



2 x Handles  
(H13)



4 x Round  
Head Bolts  
(H14)






4 x Wedges  
(H15)



4 x Screws  
(H16)




# Step 1


You will need	
	
8 x Cam Bolts (H3)	Phillips head screwdriver




Attach 8 x Cam Bolts (H3) into Legs (P7, P8, P9, P10).

# Step 2

You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	






This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 4 x Dowels (H1) into the holes of Left Side Panel (P2).  
Insert 4 x Cam Nuts (H4) into the holes of Left Side Panel (P2).  
Rotate the cam nuts so the arrows point towards the incoming cam bolts.  
Attach Legs (P7, P9) to Left Side Panel (P2), then tighten the cam nuts.




# Step 3


You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 4 x Dowels (H1) into the holes of Right Side Panel (P3).  
Insert 4 x Cam Nuts (H4) into the holes of Right Side Panel (P3).  
Rotate the cam nuts so the arrows point towards the incoming cam bolts.  
Attach Legs (P8, P10) to Right Side Panel (P3), then tighten the cam nuts.




## Step 4


You will need	
	
2 x CL Runner Tracks (H6)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CL Runner Tracks (H6) to Left Side Panel (P2) with 6 x Small Screws (H5).



## Step 5


You will need	
	
2 x CR Runner Tracks (H7)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CR Runner Tracks (H7) to Right Side Panel (P3) with 6 x Small Screws (H5).




## Step 6


You will need	
	
4 x Cam Bolts (H3)	Phillips head screwdriver



Attach 4 x Cam Bolts (H3) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).

## Step 7

You will need	
	
2 x Dowels (H1)	2 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 2 x Dowels (H1) into Rails (P4, P5).




Insert 2 x Cam Nuts (H4) into the holes of Rails (P4, P5).


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Align the holes and attach Legs (P7, P9) to Left Side Panel (P2).

Tighten the cam nuts.

## Step 8

You will need	
	
2 x Dowels (H1)	2 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 2 x Dowels (H1) into Rails (P4, P5).



Insert 2 x Cam Nuts (H4) into the holes of Rails (P4, P5).


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Align the holes and attach Legs (P8, P10) to Right Side Panel (P3).

Tighten the cam nuts.


## Step 9


You will need	
	
4 x Plastic Glides (H2)	Hammer



Attach 4 x Plastic Glides (H2) to the bottom of Legs (P7, P8, P9, P10) with a Hammer.



## Step 10


You will need	
	
8 x Dowels (H1)	



Slide Back Panel (P6) into the groove in Legs (P9, P10) and Rail (P5).  
Insert 8 x Dowels (H1) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).

## Step 11



You will need	
	
6 x Cam Bolts (H3)	Phillips head screwdriver




Attach 6 x Cam Bolts (H3) into Top Panel (P1) as shown.






## Step 12



You will need	
	
6 x Cam Nuts (H4)	Flat head screwdriver



Insert 6 x Cam Nuts (H4) into the holes of Side Panels (P2, P3) and Legs (P7, P8, P9, P10). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) to the frame and tighten the cam nuts using a Flat head screwdriver.



## Step 13


You will need	
	
4 x Wedges (H15)	4 x Screws (H16)
	
Phillips head screwdriver	



Secure Back Panel (P6) in place with 4 x Wedges (H15) using 4 x Screws (H16).



## Step 14


You will need	
	
4 x Small Cam Bolts (H10)	Phillips head screwdriver



Screw 4 x Small Cam Bolts (H10) into Drawer Front (P11) with a Phillips head screwdriver.


## Step 15

You will need	
	
4 x Small Cam Nuts (H11)	Flat head screwdriver





Insert 4 x Small Cam Nuts (H11) into the holes of Drawer Sides (P12, P13). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Align the holes together, secure Drawer Sides (P12, P13) into place and tighten the cam nuts using a Flat head screwdriver.

## Step 16




Slide Drawer Base (P14) in through the grooves on Drawer Sides (P12, P13).





## Step 17


You will need	
	
4 x Long Screws(H12)	Phillips head screwdriver

Attach Drawer Back (P15) to Drawer Sides (P12, P13) with 4 x Long Screws (H12), make sure that the groove lines up the whole way around the drawer. Tighten Screws using a Phillips head screwdriver.






## Step 18


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P12) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P13) with 4 x Small Screws (H5). Tighten Screws using a Phillips head screwdriver.


## Step 19

You will need	
	
1 x Handle (H13)	2 x Round Head Bolts (H14)
	
Phillips head screwdriver	




Attach 1 x Handle (H13) to Drawer Front (P11) with 2 x Round Head Bolts (H14). Tighten round head bolts using a Phillips head screwdriver. Repeat Step 14 to Step 19 to assemble the other drawer.

## Step 20



Slide the drawers into the bedside table.

## Step 21




**Recommended weight capacity : 80KG.**

# **Job Complete!**

In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0



TWO PEOPLE



REQUIRED

# HAVANA

Bed Double (Frame Only)

[www.fantasticfurniture.com.au](http://www.fantasticfurniture.com.au)


**Enjoy**  
Your purchase from  
Australia's Best Value Furniture Store




# Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.  
Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

# What you need

to assemble the product




DO NOT USE



## Additional Tools Required

Flat head screwdriver;  
Phillips head screwdriver;  
Hammer



## Parts list


**Box 1:** Bedhead (P1);  
Bedfoot (P2);

**Box 2:** 2 x Side Covers (P3);  
2 x Side Rails (P4);  
Centre Rail (P5);  
2 x Support Legs (P6);


26 x End Connectors



13 x Centre Connectors




26 x Fantastic Furniture  
ComfortSlats™ Double




## Hardware pack



16 x Dowels  
(H1)



4 x Screws  
(H2)



12 x Cam Bolts  
(H3)



12 x Cam Nuts  
(H4)



8 x Half Round  
Nuts  
(H5)



8 x Threaded Rod  
(H6)



8 x Hexagonal  
Nuts  
(H7)



1 x Spanner  
(H8)



4 x Plastic  
Glides  
(H9)







2 x Long Bolts  
(H10)




1 x Allen Key  
(H11)







# Step 1


You will need	
	
6 x Dowels (H1)	4 x Threaded Rod (H6)
	
2 x Plastic Glides (H9)	Hammer



Insert 6 x Dowels (H1) into Bedhead (P1).  
 Attach 4 x Threaded Rod (H6) into Bedhead (P1).  
 Hammer 2 x Plastic Glides (H9) onto the bottom of Bedhead (P1).






# Step 2


You will need	
	
6 x Dowels (H1)	4 x Threaded Rod (H6)
	
2 x Plastic Glides (H9)	Hammer



Insert 6 x Dowels (H1) into Bedfoot (P2).  
 Attach 4 x Threaded Rod (H6) into Bedfoot (P2).  
 Hammer 2 x Plastic Glides (H9) onto the bottom of Bedfoot (P2).




## Step 3


You will need	
	
4 x Dowels (H1)	12 x Cam Bolts (H3)
	
12 x Cam Nuts (H4)	Phillips head screwdriver
	
Flat head screwdriver	



Insert 2 x Dowels (H1) into Side Cover (P3).  
 Attach 6 x Cam Bolts (H3) into Side Cover (P3).  
 Insert 6 x Cam Nuts (H4) into the holes of Side Rail (P4).  
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.  
 Attach Side Cover (P3) to Side Rail (P4), then tighten the cam nuts.  
 Repeat Step 3 for the other Side Cover (P3) and Side Rail (P4).

## Step 4

You will need	
	
4 x Half Round Nuts (H5)	4 x Hexagonal Nuts (H7)
	
1 x Spanner (H8)	






TWO PEOPLE




REQUIRED

Attach Bedfoot (P2) to Side Covers (P3) and Side Rails (P4) with 4 x Half Round Nuts (H5) and 4 x Hexagonal Nuts (H7) using Spanner (H8).

## Step 5

You will need	
	
4 x Half Round Nuts (H5)	4 x Hexagonal Nuts (H7)
	
1 x Spanner (H8)	





TWO PEOPLE




REQUIRED

Attach Bedhead (P1) to Side Covers (P3) and Side Rails (P4) with 4 x Half Round Nuts (H5) and 4 x Hexagonal Nuts (H7) using Spanner (H8).



## Step 6


You will need	
	
2 x Long Bolts (H10)	1 x Allen Key (H11)



Attach 2 x Support Legs (P6) to Centre Rail (P5) with 2 x Long Bolts (H10) using Allen Key (H11).




## Step 7

You will need	
	
4 x Screws (H2)	Phillips head screwdriver




Attach Centre Rail (P5) to Bedhead (P1) and Bedfoot (P2) as shown. Then screw Centre Rail (P5) with 4 x Screws (H2).


## Step 8

You will need	
	
26 x End Connectors	13 x Centre Connectors
	
26 x Fantastic Furniture ComfortSlats™ Double	

### HOW TO FIT YOUR COMFORT SLATS




Push 2 End Connectors, 2 Fantastic Furniture ComfortSlats™ Double and a Centre Connector together.




Insert the full slat into the side rail and centre rail one by one.

3




Sometimes it makes it easier to line up the hole if you press down in the middle of the slat to flatten it out.

4



Repeat for every bed slat until finished.




## Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



**Fantastic  
Furniture**

Version 1.0



**HAVANA**  
SLIM BOY

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)

Recommended weight capacity : 10kgs/drawer.



**WARNING: ENSURE THE WALL STRAP IS ATTACHED TO  
AVOID SERIOUS INJURY.**

To avoid any serious or fatal injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Connecting attachments for your wall are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what wall connections to use.

## Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture  
to help create a home you'll love



# Fantastic Furniture

### Love it? Share it!


Fantastic buy! Share how it looks at home for your  
chance to win a \$250 Fantastic Furniture Gift Card!

**fantasticfurniture**


# Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.



# What you need

to assemble the product



**Other tools you need:**  
Phillips head screwdriver;  
Hammer

## Parts list

Top Panel (P1);  
Left Side Panel (P2);  
Right Side Panel (P3);  
Leg (P4); Leg (P5); Leg (P6);  
Leg (P7);  
3 x Back Panels (P8);  
2 x Rails (P9);  
Rail (P10); Rail (P11); Rail (P12);  
2 x Drawer Fronts (P13);  
2 x Left Drawer Side (P14);  
2 x Right Drawer Side (P15);  
2 x Drawer Back (P16);  
5 x Drawer Base (P17);  
4 x Drawer Front (P18);  
Drawer Base (P19);  
4 x Left Drawer Side (P20);  
4 x Right Drawer Side (P21);  
4 x Drawer Back (P22)

Leg  
(P4)

Left  
Side  
Panel  
(P2)

Leg  
(P5)

Top Panel  
(P1)

Back  
Panel  
(P8)

Leg  
(P6)

Rail  
(P9)

Back  
Panel  
(P8)



Rail  
(P10)

Back  
Panel  
(P8)

Rail  
(P12)

Rail  
(P11)

Leg  
(P7)



## Hardware pack



4 x Plastic  
Glides  
(H1)



30 x Dowels  
(H2)



32 x Cam  
Bolts  
(H3)



32 x Cam  
Nuts  
(H4)



60 x Small  
Screws  
(H5)



6 x CL Runner  
Tracks  
(H6)




6 x CR Runner  
Tracks  
(H7)



6 x DL  
Runners  
(H8)



6 x DR  
Runners  
(H9)




24 x Small  
Cam Bolts  
(H10)



24 x Small  
Cam Nuts  
(H11)



24 x Long  
Screws (L25mm)  
(H12)



6 x Handles  
(H13)




12 x Handle  
Bolts  
(H14)



8 x Wedges  
(H15)



8 x Screws  
(H16)








1 x Safety  
Strap  
(H17)

1 x Screw  
(L25mm)  
(H18)

2 x Washers  
(H19)




# Step 1

You will need	
	
16 x Cam Bolts (H3)	4 x Plastic Glides (H1)
	
Phillips Head Screwdriver	Hammer




Secure 16 x Cam Bolts (H3) to Legs(P4, P5, P6, P7) by tightening with the Phillips Head Screwdriver. Hammer 4 x Plastic Glides (H1) on Legs (P4, P5, P6, P7) as shown.

# Step 2


You will need	
	
16 x Cam Nuts (H4)	12 x Dowels (H2)
	
Phillips Head Screwdriver	

This is how a cam nut works.....








The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 12 x Dowels (H2) into the holes of Side Panels (P2, P3). Insert 16 x Cam Nuts (H4) into the holes of Side Panels (P2, P3). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Legs (P4, P5) to Left Side Panel (P2) and Legs (P6, P7) to Right Side Panel (P3). Tightening Cam Nuts with the Phillips Head Screwdriver.







## Step 3


You will need	
	
6 x CL Runner Track (H6)	18 x Small Screws (H5)
	
5 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 6 x CL Runner Tracks (H6) to Left Side Panel (P2) with 18 x Small Screws (H5). Secure 5 x Cam Bolts (H3) to Left Side Panel (P2) by tightening with the Phillips Head Screwdriver.




## Step 4


You will need	
	
6 x CR Runner Track (H7)	18 x Small Screws (H5)
	
5 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 6 x CR Runner Tracks (H7) to Right Side Panel (P3) with 18 x Small Screws (H5). Secure 5 x Cam Bolts (H3) to Right Side Panel (P3) by tightening with the Phillips Head Screwdriver.


## Step 5

You will need	
	
5 x Dowels (H2)	5 x Cam Nuts (H4)
	
Phillips Head Screwdriver	






Insert 5 x Dowels (H2) into Left Side Panel (P2). Insert 5 x Cam Nuts (H4) into the holes of Rails (P9X2, P10, P11, P12). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Rails (P9X2, P10, P11, P12) to the left frame, then tightening with the Phillips Head Screwdriver.


## Step 6



Slide 2 x Back Panels (P8) into the grooves of Rails (P9x2&P12).

## Step 7


You will need	
	
5 x Dowels (H2)	5 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 5 x Dowels (H2) into Right Side Panel (P3). Insert 5 x Cam Nuts (H4) into the holes of Rails (P9X2, P10, P11, P12). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Rails (P9X2, P10, P11, P12) to the Right frame, then tightening with the Phillips Head Screwdriver.


## Step 8


Ensure laminated side of panel is facing inwards.



Carefully turn the tallboy over to an upright position. Slide Back Panels (P8) into the grooves in Left Side Panel (P2) and Right Side Panel (P3) .



# Step 9


You will need	
	
8 x Dowels (H2)	



Insert 8 xDowels (H2) into Left Side Panel (P2), Right Side Panel (P3) and Legs (P4, P5, P6, P7).



# Step 10


You will need	
	
6 x Cam Bolts (H3)	Phillips Head Screwdriver



Secure 6 x Cam Bolts (H3) to Top Panel (P1) by tightening with the Phillips Head Screwdriver.



## Step 11


You will need	
	
6 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 6 x Cam Nuts (H4) into the holes of Side Panels (P2, P3) and Legs (P4, P5, P6, P7). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) into place, and then tighten the cam nuts.

## Step 12



You will need	
	
24 x Small Cam Bolts (H10)	Phillips Head Screwdriver




Secure 24 x Cam Bolts (H3) to Drawer Fronts (P13x2, P18x4) by tightening with the Phillips Head Screwdriver.




## Step 13

You will need	
	
24 x Small Cam Nuts (H11)	Phillips Head Screwdriver

This is how a cam nut works.....





The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Insert 24 x Small Cam Nuts (H11) into Left Drawer Sides (P14x2 & P20x4) & Right Drawer Sides (P15x2 & P21x4), attach to Drawer Fronts (P13x2, P18x4) by tightening Cam Nuts with the Phillips Head Screwdriver.



## Step 14




Slide the Drawer Bases (P17x5) into the grooves of Left & Right Drawer Side (P14 & P15, P20x4 & P21x4) as shown. Slide the Drawer Base (P19) into the grooves of Left & Right Drawer Side (P14 & P15) as shown.







## Step 15


You will need	
	
24 x Long Screws (H12)	Phillips Head Screwdriver



Attach Drawer Back (P16x2 ) to Left & Right Drawer Sides (P14x2 & P15x2) with 8 x Long Screws (H12) by tightening with the Phillips Head Screwdriver. Attach Drawer Back (P22x4 ) to Left & Right Drawer Sides (P20x4 & P21x4) with 16 x Long Screws (H12) by tightening with the Phillips Head Screwdriver. Before securing - Ensure the Bottom Panel lines up with the grooves the whole way around the drawer.




## Step 16


You will need	
	
6 x DL Runner (H8)	6 x DR Runner (H9)
	
24 x Small Screws (H5)	Phillips Head Screwdriver



Attach 6 x DL Runner (H8) to Left Drawer Side (P14x2 & P20x4) and 6 x DR Runner (H9) to Right Drawer Side (P15x2 & P21x4) with 24 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.


## Step 17

You will need	
	
6 x Handles (H13)	12 x Handle Bolts (H14)
	
Phillips Head Screwdriver	









Attach 6 x Handles (H13) to Drawer Fronts (P13x2, P18x4) with 12 x Handle Bolts (H14). Tighten Round Head Bolts using a Phillips head screwdriver.

## Step 18






Insert the assembled drawer into the unit by gently guiding the drawer runners into place.



# Step 19

You will need	
	
8 x Wedges (H15)	8 x Wedge Screws (H16)
	
1 x Safety Strap (H17)	1 x Safety Strap Screw (H18)
	
1 x Washer (H19)	Phillips Head Screwdriver

Attach 1 x Safety Strap (H17) to Top Panel (P1) with 1 x Safety Strap Screw (H18) and 1 x Washer (H19) by tightening with the Phillips Head Screwdriver. Secure Back Panel (P8x2) in place with 8 x Wedges (H15) using 8 x Wedge Screws (H16) by tightening with the Phillips Head Screwdriver.





# Step 20


You will need	
	
1 x Washer (H19)	Phillips Head Screwdriver
Screw and Wall Plug are not provided. Please use appropriate fixtures for your wall.	

**Seek advice from a qualified trades person on how to attach this safety strap to your specific wall.**

Move the unit to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)





## Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.