




**Fantastic
Furniture**

Version 1.0



Two People



Required

Amirah

Bed Single

fantasticfurniture.com.au



WARNING: Do not drag this bed

To move this bed it must be lifted and moved.
The bed has a centre rail and a support leg that may be damaged when dragged, which may in turn damage the bed frame.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



**Fantastic
Furniture**

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!


@fantasticfurniture




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE



Other tools you need

Phillips head screwdriver, soft headed mallet.

Parts list

Box 1:

Head Board (P1);

Foot Board (P4);

Support Leg (P7);

Hardware.

Box 2:


6 x Base Panels (P5).

Box 3:

Side Panel L (P2);

Side Panel R (P3);


Centre Support (P6).



1 x Allen Key
(H1)



4 x Cam Nuts
(H2)



8 x Wood Dowels
(H3)



30 x Large Screws
(H4)



26 x Hex Nuts
(H5)



26 x Washers
(H6)



4 x Small Screws
(H7)



1 x Spanner
(H8)



4 x Cam Bolts
(H9)






8 x Bolts
(H10)



4 x Barrel Nuts
(H11)






Step 1


You will need	
	
4 x Cam Bolts (H9)	Phillips Head Screwdriver



Screw 4 x cam bolts (H9) into the foot board (P4) by using a phillips head screwdriver.

Step 2

You will need	
	
1 x Allen Key (H1)	2 x Large Screws (H4)
	
2 x Hex Nut (H5)	2 x Washer (H6)
	
1 x Spanner (H8)	




Attach the support leg (P7) to the centre support (P6) with 2 x large screws (H4), 2 x washers (H6) and 2 x hex nuts (H5) using an allen key (H1) and spanner (H8) as shown.

Step 3


You will need



4 x Cam Nuts
(H2)




8 x Wood Dowels
(H3)



4 x Barrel Nuts
(H11)



Soft Headed
Mallet




Insert 4 x cam nuts (H2) into the side rails (P2) & (P3). Rotate the cam nuts (H2) so the arrows point towards the incoming cam bolts.

Insert 8 x dowels (H3) into the side rails (P2 & P3) by hand or gently using a soft headed mallet.


Insert 4 x barrel nuts (H11) into side rails (P2) & (P3). Ensure the opening of the nuts face the incoming screws.

Step 4


You will need




4 x Bolts
(H10)



4 x Large Screws
(H4)



1 x Allen Key
(H1)



Two People



Required



Attach the side rails panels (P2 & P3) to the head board (P1).

Align the dowels (H3) in the side panels with the holes on the


head board (P1). Fix the side rails (P2 & P3) with 4 x screws (H4) through the head board and rotate clockwise to tighten with an allen key (H1).

Then fix the side rails (P2 & P3) to the head board (P1) with 4 x bolts (H10) using a phillips head screwdriver.



Step 5

You will need	
	
4 x Bolts (H10)	Phillips Head Screwdriver

This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.





Attach the side rails (P2 & P3) to the foot board (P4).


Align the dowels (H3) in the side panels with the holes on the foot board (P4).

Turn the cam nuts (H2) on the side panels (P2 & P3) clockwise with a phillips head screwdriver to lock into position.

Then fix the side rails (P2 & P3) to the foot board (P4) with 4 x bolts (H10) using a phillips head screwdriver.

Step 6

You will need	
	
4 x Small Screws (H7)	1 x Allen Key (H1)



Two People




Required

Attach the metal centre support (P6) to the head board (P1) and foot board (P4) with 4 x small screws (H7) using an allen key.

Ensure all bolts are fully tightened.

fantasticfurniture.com.au


Step 7



Use two people to lift and move this bed to its final resting position. Extend the adjustable foot so that it sits 10mm above the floor before you place the mattress on the bed.


Step 8

You will need	
1 x Allen Key (H1)	24 x Large Screws (H4)
24 x Hex Nuts (H5)	24 x Washers (H6)
1 x Spanner (H8)	



Secure the first base panel (P5) to the rails on the side panels (P2 & P3) in the position closest to the head board (P1) with 4 x large screws (H4), 4 x washers (H6), 4 x hex nuts (H5) using an allen key (H1) and spanner (H8) as shown. Repeat this process with 1 x base panel placed closest to the foot board (P4). Then repeat this process for the remaining 4 x base panels and place in the middle. Ensure bolts are fully tightend.

fantasticfurniture.com.au



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.