




**Fantastic
Furniture**

Version 1.0



Emmett

Storage Trolley 3 Shelf

fantasticfurniture.com.au

RECOMMENDED WEIGHT CAPACITY PER SHELF: 10KG

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture


Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need


to assemble the product



DO NOT USE

Parts list



- 3 x Shelf (P1);
- 2 x Bottom Frame (P2);
- 2 x Bottom Frame (P3);
- 4 x Middle Frame (P4);
- 2 x Top Frame (P5)




Hardware pack

18 x Bolts (H1)	4 x Nuts (H2)	1 x Allen Key (H3)	2 x Wrenchs (H4)	2 x Brake Casters (H5)	2 x Casters (H6)





Step 1


You will need	
	
2 x Bolts (H1)	1 x Allen Key (H3)



Attach Bottom Frames (P2 & P3) with 1 x Bolt (H1) by tightening with the Allen Key (H3). Repeat for second set of Bottom Frames (P2 & P3).



Step 2


You will need			
			
4 x Nuts (H2)	2 x Brake Casters (H5)	2 x Casters (H6)	1 x Wrench (H4)



Screw 2 x Nuts (H2) onto 2 x Casters (H6), as shown.
 Attach 2 x Casters (H6) to Bottom Frames (P2 & P3) by screwing in until fully tightened.
 Repeat steps for remaining Nuts 2 x (H2) and Brake Casters 2 x (H5).
 Fully tighten Nuts 4 x (H2) with wrench (H4) if needed.


Step 3

You will need	
	
4 x Bolts (H1)	1 x Allen Key (H3)





Insert Middle Frames (P4x4) into Bottom Frames (P2x2) and (P3x2) and attach with 4 x Bolts (H1). Tighten with Allen Key (H3).


Step 4



Insert Top Frames (P5x2) into Middle Frames (P4x4) as shown.


Step 5


You will need	
	
12 x Bolts (H1)	1 x Allen Key (H3)



Attach Shelves (P1x3) to Middle and Top Frames (P4x4), (P5x2) with 12 x Bolts (H1) by tightening with Allen Key (H3) as shown.


Step 6

You will need

2 x Wrenchs (H4)



If the Storage Trolley is uneven on the floor, adjust the 4x Nuts (H2) on the 2 x Brake Casters (H5) and 2 x Casters (H6) with 2 x Wrenchs (H4), as shown.

Step 7



Job complete!

In the interest of our environment please dispose
of all packaging thoughtfully.