





Version 1.0



TWO PEOPLE



REQUIRED

MODENA

DOUBLE BED

www.fantasticfurniture.com.au

Enjoy

Your purchase From
Australia's Best Value Furniture Store




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need


to assemble the product



DO NOT USE



Other tools you need
Phillips head screwdriver




Parts list



Box 1 : Footboard (P2) ; Side Rail (P3) ; Centre Rail (P4);
Cross Rail (P7)

Box 2: Headboard (P1) ; Headboard Leg (P5) ; Metal Leg(P8) ;
Support leg (P6)


26 x End Connectors




13 x Center Connectors



26 x Fantastic Furniture
Comfort Slat™ Double



12 x Bolts 20 mm
(H1)




2 x Bolts 40 mm
(H2)




1 x Bolts 60 mm
(H3)



4 x Small Screws 20 mm
(H4)



2 x Medium Screws 32 mm
(H5)



4 x Large Screws 50 mm
(H6)



12 x Spring Washers
(H7)



12 x Flat Washers
(H8)



3 x Adjuster 35 mm
(H9)




1 x Allen Key
M5 x 70mm
(H10)




1 x Allen Key
M4 x 65mm
(H11)

Please make sure you have all these parts before you start






Step 1



Please take out the leg carton from back of headboard (inside the Back compartment)

Step 2

You will need	
	
4 x Large Screws 50mm (H6)	Phillips head screwdriver





Attach legs (P5) to the bottom of headboard (P1) with 4 x large screws (H6). The self-tapping screws provided do not require a hole to attach. Apply some pressure to the screw at the beginning, it will start to work itself into the timber frame. Keep applying the pressure as you screw until the leg is firmly attached. Repeat for the 3 other screws.

****Please measure the screw size first before using it.**

Ruler is provided on page 4**



Step 3



Loosen the bolts about 8mm as show.







Attach bed footboard to Side-rails with slotted brackets.


Step 4




Attach pre-assembled side-rails and footboard to bedhead. 2 people required.

Step 5

You will need	
	
1 x Allen Key M4 x 65mm (H11)	8 x Bolts 20 mm (H1)
	
8 x Spring Washers (H7)	8 x Flat Washers (H8)
	
4 x Small Screws 20mm (H4)	Phillips head screwdriver



TWO PEOPLE







REQUIRED

Important notice

Attach P6 to side-rail and footboard, on both corners. 2 people required
(1 person needs to support the other corner while attaching the 1st P8 to the bed.)
(Important notice : Please ensure H5 is attach into P3. This is important.)




Step 6


You will need	
	
2 x Bolts 40mm (H2)	1 x Allen Key M4 x 65mm (H11)
	
2 x Adjuster 35 mm (H9)	



Attach adjuster (H9) as shown. Attach each support legs (P6)
to the centre rail (P4) using 2x bolts(H2) as shown.





Step 7


You will need	
	
1 x Bolts 60 mm (H3)	1 x Allen Key M4 x 65mm (H11)
	
1 x Adjuster 35 mm (H9)	



Attach adjuster (H9) as shown. Attach support legs (P6) to the centre rail (P4) and the cross rail (P7) using 1x bolts(H3) as shown.




Step 8

You will need	
	
1 x Allen Key M4 x 65mm (H12)	4 x Bolts 20 mm (H1)
	
4 x Spring Washers (H8)	4 x Flat Washers (H9)




Attach centre rail (P4) and the cross rail (P7) to the Headboard (P1) and Footboard (P2) using 4x bolts(H1), Spring Washer(H7) and Flat Washers (H8) as shown.

Step 9


You will need	
	
26 x End Connectors	13 x Center Connectors
	
26 x Fantastic Furniture ComfortSlat™ Double	

1




Push 2 End Connectors, 2 Fantastic Furniture ComfortSlat™ Double and a Centre Connector together.

2




Insert the full slat into the side rail and centre rail one by one.

3






Sometimes it makes easier to line up the hole if you press down in the middle of the slat to flatten it out.


4




Repeat for every bed slat until finished.

Step 10

You will need	
	
2 x Medium Screw 32mm (H5)	1 x Allen Key M5 x 70mm (H10)
	
Phillips head screwdriver	



Make sure the bed frame is square, then attach the cross rail (P7) to the centre of side rails (P3) and centre rail (P4) using medium screw (H5). Now tighten all the bolts on the corner bracket and tighten screws on the headboard (P1) and footboard (P2).




Job Complete

In the interest of our environment please dispose of all packaging thoughtfully.



**Fantastic
Furniture**

Version 1.0



Two People



Required

TOTO
TALLBOY 5 DRAWER

fantasticfurniture.com.au

Recommended weight capacity : 40kgs.



**WARNING: ENSURE THE WALL STRAP IS ATTACHED TO
AVOID SERIOUS INJURY.**

To avoid any serious or fatal injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Connecting attachments for your wall are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what wall connections to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home for your
chance to win a \$250 Fantastic Furniture Gift Card!

fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product





DO NOT USE



Other tools you need:
Phillips head screwdriver;

Parts list

Top Panel (P1);
Left Side Panel (P2);
Right Side Panel (P3);
Bottom Panel (P4);
Rail (P5);
Rail (P6);
Rail (P7);
Rail (P8);
2 x Back Panels (P9);
2 x Rail (P10);
2 x Rail (P11);
5 x Drawer Fronts (P12);
5 x Left Drawer Sides (P13);
5 x Right Drawer Sides (P14);
5 x Rail (P15);
5 x Drawer Bases (P16);
5 x Drawer Backs (P17);



Hardware pack



12 x Dowels
(H1)



16 x Long
Screws
(H2)



41 x Cam
Bolts
(H3)



41 x Cam
Nuts
(H4)



50 x Small
Screws
(H5)



5 x CL
Runner
Tracks
(H6)



5 x CR
Runner
Tracks
(H7)



5 x DL
Runners
(H8)



5 x DR
Runners
(H9)



4 x Nuts
(H10)



4 x Bolts
(H11)




25 x Screws
(H12)



8 x Wedges
(H13)



8 x Screws
(H14)






1 x Safety
Strap
(H15)

1 x Screw
(H16)

2 x Washers
(H17)





Step 1




You will need	
	
16 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 16 x Cam Bolts (H3) to Top Panel (P1), Left Side Panel (P2) and right Side Panel (P3) as shown. Tighten with a Phillips Head Screwdriver.




Step 2

You will need	
	
30 x Small Screws (H5)	Phillips Head Screwdriver
	
5 x CL Runner Tracks (H6)	5 x CR Runner Tracks (H7)




Attach 5 x CR Runner Track (H7) to Right Side Panel (P3) with 15 x Small Screws (H5). Attach 5 x CL Runner Track (H6) to Left Side Panel (P2) with 15 x Small Screws (H5). Tighten with a Phillips Head Screwdriver.


Step 3

You will need	
	
1 x Dowel (H1)	6 x Cam Nuts (H4)
	
Phillips Head Screwdriver	

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.






Attach Rails (P5,P6,P7,P8) to Left Side Panel (P2) with 1 x Dowel (H1), and secure with 6 x Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.

Step 4




Slide remaining Back Panels (P9) into the grooves of Rails (P5,P8).


Step 5

You will need	
	
1 x Dowel (H1)	6 x Cam Nuts (H4)
	
Phillips Head Screwdriver	

This is how a cam nut works.....







The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.




Attach Right Side Panel (P3) to Rails (P5,P6,P7,P8) with 1 x Dowel (H1), and secure with 6 x Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.


Step 6

You will need	
	
6 x Dowels (H1)	Phillips Head Screwdriver
	
4 x Cam Nuts (H4)	4 x Long Screws (H2)

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.






Attach Top Panel (P1) to Rails (P5,P6) and Panels (P2,P3) with 6 x Dowels (H1), and secure with 4 x Cam Nuts (H4) and 4 x Long Screws (H2). Tighten with a Phillips Head Screwdriver.


Step 7



Slide Back Panel (P9) into the grooves between Panels (P2,P3) as shown.




Step 8


You will need	
	
4 x Dowels (H1)	Phillips Head Screwdriver
	
4 x Long Screws (H2)	



Attach Bottom Panel (P4) to Panels (P2,P3) with 4 x Dowels (H1), and secure with 4 x Long Screws (H2). Tighten with a Phillips Head Screwdriver.



Step 9


You will need	
	
4 x Nuts (H10)	Phillips Head Screwdriver
	
4 x Bolts (H11)	



Attach 2 x Legs (P11) to 2 x Rails (P10) with 4 x Cam Nuts (H10) and 4 x Bolts (H11). Tighten with a Phillips Head Screwdriver.



Step 10


You will need	
	
8 x Long Screws (H2)	Phillips Head Screwdriver



Attach Rails (P10,P11) to Bottom Panel (P4) with 8 x Long Screws (H2). Tighten with a Phillips Head Screwdriver.


Step 11


You will need	
	
25 x Cam Bolts (H3)	Phillips Head Screwdriver




Attach 5 x Cam Bolts (H3) to Drawer Fronts (P12) as shown. Tighten with a Phillips Head Screwdriver.

Step 12

You will need	
	
25 x Cam Nuts (H4)	Phillips Head Screwdriver




This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach Drawer Sides (P13, P14) and Rail (P15) to Drawer Front (P12). Insert 5 x Cam Nuts (H4) into the holes of Drawer Sides (P13, P14, P15). Make sure the opening on cam nuts point towards the incoming cam bolts. Tighten with a Phillips head screwdriver.


Step 13



Slide the middle Drawer Base (P16) into the grooves between drawer sides as shown.

Step 14


You will need	
	
25 x Screws (H12)	Phillips Head Screwdriver



Attach Drawer Back (P17) to Drawer Sides (P13, P14) and Rail (P15) with 5 x Screws (H2), make sure that the groove lines up the whole way around the drawer. Tighten with a Phillips Head Screwdriver.


Step 15

You will need	
10 x DL Runners (H8)	10 x DR Runners (H9)
20 x Small Screws (H5)	Phillips Head Screwdriver









Attach 1 x DL Runner (H8) to Left Drawer Side (P13) and 1 x DR Runner (H9) to Right Drawer Side (P14) with 4 x Small Screws (H5) using a Phillips Head Screwdriver.


Step 16



Carefully turn the bookcase over to an upright position. Slide the drawers into the bookcase.



Step 17


You will need	
	
8 x Wedges (H13)	8 x Screws (H14)
	
1 x Safety Strap (H15)	1 x Screw (H16)
	
1 x Washer (H17)	Phillips Head Screwdriver



Attach 1 x Safety Strap (H15) to Top Panel (P1) with 1 x Screw (H16) and 1 x Washer (H17) by tightening with the Phillips Head Screwdriver. Secure Back Panels (P9x2) in place with 8 x Wedges (H13) using 8 x Screws (H14) by tightening with the Phillips Head Screwdriver.

Step 18

You will need	
	
1 x Washer (H17)	Phillips Head Screwdriver
Screw and Wall Plug are not provided. Please use appropriate fixtures for your wall.	




Move the tallboy unit to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0



TOTO
Bedside 2 Drw

www.fantasticfurniture.com.au


Enjoy
Your purchase from
Australia's Best Value Furniture Store




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.
Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need

to assemble the product




DO NOT USE





Other tools you need

Flat head screwdriver;
Phillips head screwdriver;



Parts list


Box 1: Top Panel (P1); Left Side Panel (P2); Right Side Panel (P3); Bottom Panel (P4); Back Panel (P5); Leg (P6); Drawer Front (P7); Left Drawer Side (P8); Right Drawer Side (P9); Drawer Base (P10); Drawer Back (P11); Hardware Pack;



8 x Dowels
(H1)



12 x Long Screws
(H2)




12 x Cam Bolts
(H3)




12 x Cam Nuts
(H4)




20 x Small Screws
(H5)




2 x CL Runner
Tracks
(H6)



2 x CR Runner
Tracks
(H7)



2 x DL Runners
(H8)



2 x DR Runners
(H9)








4 x Wedges
(H10)



4 x Medium Screws
(H11)




Step 1



You will need	
	
2 x CL Runner Tracks (H6)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CL Runner Tracks (H6) to Left Side Panel (P2) with 6 x Small Screws (H5).




Step 2


You will need	
	
2 x CR Runner Tracks (H7)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CR Runner Tracks (H7) to Right Side Panel (P3) with 6 x Small Screws (H5).



Step 3


You will need	
	
4 x Dowels (H1)	4 x Long Screws (H2)
	
Phillips head screwdriver	



Insert 4 x Dowels (H1) into the holes of Side Panels (P2, P3).
Attach Side Panels (P2, P3) to Bottom Panel (P4) with 4 x Long Screws (H2).




Step 4

You will need	
	
4 x Cam Bolts (H3)	Phillips head screwdriver




Attach 4 x Cam Bolts (H3) into Top Panel (P1) using a Phillips head screwdriver.


Step 5

You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Insert Back Panel (P5) into the groove of Side Panels (P2, P3) and Bottom Panel (P4).
 Insert 4 x Dowels (H1) into Side Panels (P2, P3).
 Insert 4 x Cam Nuts (H4) into the holes of Side Panels (P2) and (P3).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Top Panel (P1) and tighten the cam nuts.


Step 6

You will need	
4 x Wedges (H10)	4 x Medium Screws (H11)
Phillips head screwdriver	





Secure Back Panel (P5) in place with 4 x Wedges (H10) using 4 x Medium Screws (H11).


Step 7



Turn 4 x Legs (P6) into brackets until firm.



Step 8


You will need	
	
4 x Cam Bolts (H3)	Phillips head screwdriver



Attach 4 x Cam Bolts (H3) to Drawer Front (P7) as shown.


Step 9

You will need	
	
4 x Cam Nuts (H4)	Flat head screwdriver





Insert 4 x Cam Nuts (H4) into the holes of Drawer Sides (P8, P9).
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Push Drawer Sides (P8, P9) into place and tighten the cam nuts.


Step 10



Slide Drawer Base (P10) into the groove in Drawer Sides (P8, P9).





Step 11


You will need	
	
4 x Long Screws (H2)	Phillips head screwdriver



Attach Drawer Back (P11) to Drawer Sides (P8, P9) with 4 x Long Screws (H2). Make sure that the groove lines up the whole way around the drawer.


Step 12

You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips head screwdriver




Attach 1 x DL Runner (H8) to Left Drawer Side (P8) and 1 x DR Runner (H9) to Right Drawer Side (P9) with 4 x Small Screws (H5).

Step 13




Repeat Step 8 to Step 12 to assemble the other drawer.

Step 13



Put the drawers into the chest.

Step 14



Recommended weight capacity : 40KG.

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.