




**Fantastic  
Furniture**

Version 1.0



**Two People**



**Required**

**Java**  
Coffee Table

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)

## **Rattan**

Rattan is a natural material that will respond to humidity in the environment. Low humidity may cause the rattan to shrink. High humidity may cause the rattan to absorb moisture and expand, causing the weaving to look loose and wavy.

This is a natural phenomenon and not a defect.

## **Looks like you've found your Fantastic!**

We're thrilled you've chosen Fantastic Furniture  
to help create a home you'll love!



# **Fantastic Furniture**

## **Love it? Share it!**

Fantastic buy! Share how it looks at home on Instagram  
for your chance to win a \$250 Fantastic Furniture Gift Card!  
**@fantasticfurniture**


# Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need

## to assemble the product




DO NOT USE



### Other tools you need


Flat Head Screwdriver;  
Phillips Head Screwdriver;  
Mallet



### Parts list

- |                           |                            |
|---------------------------|----------------------------|
| 1 x Top Panel (P1)        | 1 x Drawer Right Side (P8) |
| 1x Bottom Panel (P2)      | 1 x Drawer Back (P9)       |
| 2 x Side Panels (P3)      | 1 x Drawer Base (P10)      |
| 1 x Right Side Panel (P4) | 1 x Drawer Support (P11)   |
| 1 x Back Frame (P5)       | 4 x Legs (P12)             |
| 1 x Drawer Front (P6)     | 1 x Large Middle Leg (P13) |
| 1 x Drawer Left Side (P7) | 1 x Small Middle Leg (P14) |

## Hardware Pack



23 x Cam Bolts  
(H1)



17 x Large Cam  
Nuts (H2)



22 x Dowels ø8mm  
(H3)



1 x Handle  
(H4)



4 x Felt Feet  
(H5)




8 x Bolts  
(H6)



8 x Flat Washers  
(H7)



8 x Spring  
Washers (H8)




2 x Screws 28mm  
(H9)




1 x Allen Key  
(H10)



6 x Small Cam  
Nuts (H11)



2 x Dowels ø6mm  
(H12)



9 x Screws 38mm  
(H13)



12 x Screws 12mm  
(H14)





2 x Slides  
(H15)



1 x Adjustable  
Foot (H16)







# Step 1


You will need	
	
4 x Felt Feet (H5)	



Attach 1 x felt foot (H5) onto each leg (P12) as shown.






# Step 2


You will need	
	
8 x Bolts (H6)	8 x Flat Washers (H7)
	
8 x Spring Washers (H8)	1 x Allen Key (H10)
	
3 x Cam Bolts (H1)	Phillips Head Screwdriver



Attach each leg (P12) onto bottom panel (P2), using 2 x bolts (H6), 2 x spring washers (H8) and 2 x flat washers (H7). Tighten the bolts with allen key (H10).  
Screw 3 x cam bolts (H1) into bottom panel (P2), using a phillips head screwdriver.



## Step 3

You will need	
	
1 x Screw 38mm (H13)	Phillips Head Screwdriver
	
2 x Dowels ø8mm (H3)	Mallet
	
1 x Adjustable Foot (H16)	




Screw 1 x adjustable foot (H16) into the large middle leg (P13).  
Insert 2 x dowels (H3) into middle legs (P13, P14).  
Use a mallet to gently tap the dowels into place if needed.  
Attach small middle leg (P14) to large middle leg (P13)  
with 1 x screw (H13), using a phillips head screwdriver.

## Step 4


You will need	
	
3 x Large Cam Nuts (H2)	Flat Head Screwdriver

Two People




Required

This is how a cam nut works.....





The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.




Attach middle legs (P13, P14) to bottom panel (P2).  
Insert 3 x large cam nuts (H2) into middle legs (P13, P14).  
Rotate the cam nuts so the arrows point towards the incoming cam bolts  
and turn clockwise to lock with a flat head screwdriver.  
With assistance, turn the assembled unit over.



## Step 5

You will need	
	
5 x Cam Bolts (H1)	Phillips Head Screwdriver


Screw 5 x cam bolts (H1) into bottom panel (P2), using a phillips head screwdriver.





## Step 6

You will need	
	
7 x Cam Bolts (H1)	Phillips Head Screwdriver


Screw 7 x cam bolts (H1) into top panel (P1), using a phillips head screwdriver.









## Step 7

You will need	
	
12 x Dowels ø8mm (H3)	Mallet




Insert 8 x dowels (H3) into back frame (P5) as shown.  
Insert 4 x dowels (H3) into right side panel (P4) as shown.  
Use a mallet to gently tap the dowels into place if needed.




## Step 8

You will need	
	
2 x Slides (H15)	6 x Screws 12mm (H14)
	
2 x Cam Bolts (H1)	Phillips Head Screwdriver
	
8 x Dowels 30mm (H3)	Mallet

Separate the 2 x slide runners (H15-2) and slide tracks (H15-1) from the slides (H15) by following the steps below:  
 Extend the slide runner (H15-2) all the way out.  
 Press down the plastic release lever on the slide and pull out the slide runner (H15-2) completely.



Note the position of the rubber stopper






Attach 2 x separated slide tracks (H15-1) onto 2 x side panels (P3) with 6 x screws (H14), using a phillips head screwdriver as shown.  
 Ensure the slide tracks (H15-1) are attached so the rubber stopper is positioned as shown.

Screw 1 x cam bolt (H1) into each side panel (P3), using a phillips head screwdriver as shown.

Insert 4 x dowels (H3) into 2 x side panels (P3) as shown.  
 Use a mallet to gently tap the dowels into place if needed.



## Step 9


You will need	
	
1 x Large Cam Nut (H2)	Flat Head Screwdriver



Attach side panel (P3) to back frame (P5) as shown.  
 Insert 1 x large cam nut (H2) into back frame (P5).  
 Rotate the cam nut so the arrow points towards the incoming cam bolt.  
 Using a flat head screwdriver, turn clockwise to lock.



## Step 10


You will need	
	
1 x Large Cam Nut (H2)	Flat Head Screwdriver



Attach side panel (P3) to back frame (P5) as shown.  
 Insert 1 x large cam nut (H2) into back frame (P5).  
 Rotate the cam nut so the arrow points towards the incoming cam bolt.  
 Using a flat head screwdriver, turn clockwise to lock.



# Step 11


You will need	
	
5 x Large Cam Nuts (H2)	Flat Head Screwdriver



Attach assembled frame (P3, P5) into bottom panel (P2) as shown.  
 Insert 5 x large cam nuts (H2) into side panels (P3) and back frame (P5),  
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.  
 Using a flat head screwdriver, turn clockwise to lock.



# Step 12

You will need	
	
2 x Screws 38mm (H13)	Phillips Head Screwdriver




Attach right side panel (P4) to bottom panel (P2) as shown.  
 Screw 2 x screws (H13) into right side panel (P4), tighten with a phillips head screwdriver.


## Step 13

You will need	
	
7 x Large Cam Nuts (H2)	Flat Head Screwdriver

Two People






Required



With assistance, position top panel (P1) to assembled unit as shown. Insert 7 x cam nuts (H2) into panels (P3 x 2, P4) and back frame (P5). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Using a flat head screwdriver, turn clockwise to lock.



## Step 14


You will need	
	
6 x Cam Bolts (H1)	Phillips Head Screwdriver



Screw 6 x cam bolts (H1) into drawer front (P6) as shown, using a phillips head screwdriver.



## Step 15

You will need	
	
2 x Dowels 30mm (H12)	Mallet




Insert 2 x dowels (H12) into drawer side panels (P8, P7) as shown. Use a mallet to gently tap the dowels into place if needed.

## Step 16


You will need	
	
6 x Small Cam Nuts (H11)	Flat Head Screwdriver

Position drawer sides (P7, P8) and drawer support (P11) onto drawer front (P6). Insert 6 x small cam nuts (H11) into drawer sides (P7, P8) and drawer support (P11). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Using a flat head screwdriver, turn clockwise to lock..





## Step 17

Slide drawer base (P10) into the grooves on panels of (P6, P7, P8).




## Step 18




You will need	
	
6 x Screws 38mm (H13)	Phillips Head Screwdriver

Attach drawer back (P9) to assembled drawer with 6 x screws (H13), using a phillips head screwdriver as shown.


Ensure the pre-drilled holes on drawer side panels (P7, P8) align with holes on back panel (P9), and the holes on back panel (P9) align with the holes on drawer support (P11).



## Step 19




You will need	
	
2 x Slide Runners (H15-2)	6 x Screws 12mm (H14)
	
Phillips Head Screwdriver	


Please fasten the screws through these holes for this step.



Attach 1 x slide runner (H15-2) to each drawer side (P7, P8) with 3 x screws (H14), using a phillips head screwdriver as shown.




## Step 20

You will need	
	
2 x Screws 28mm (H9)	1 x Handle (H4)
	
Phillips Head Screwdriver	




Attach 1 x handle (H4) onto drawer front (P6) with 2 x screws (H9), using a phillips head screwdriver as shown.


## Step 21



Move inner ball bearing track to front of slide track (H15-1).




Gently insert drawer slide runner (H15-2) in between the ball bearing track.



Position drawer so that slide runners (H15-2) align with slide tracks (H15-1) as shown. Gently push drawer into the closed position.

## Step 22



## Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.