


Version 1.0







#### CAUTION:

Use this product for seating one person at a time.

Do not stand on, or use this chair as a step ladder.

Do not rock on chair as this may result in injury.

This product should be checked periodically to ensure all components are secure and all hardware is tight.

**RECOMMENDED WEIGHT CAPACITY 120 KG** 

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



#### Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!


@fantasticfurniture




#### Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



before you begin assembly.



Identify and lay out all of the components Unless instructed, do not fully tighten screws until the item is fully assembled.

#### Useful information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.



## What you need

to assembly the product







#### Part list

**Box 1:** 1 x Seat (P1); 1 x Base (P2); 4 x Leg (P3)

#### Hardware pack








Place the  $4 \times legs$  (P3) in position of the base (P2) as shown

## Step 2




Mount the 4 x legs (P3) to the base (P2) using bolts (H1), washers (H4), metal head (H3), big allen key (H5) and small allen key (H6)










Mount the base (P2) to the seat (P1) using bolts (H2), washers (H4) and big allen key (H5). Attach felt pads (H7) to the legs.

## Step 4



# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.





Version 1.0





STOCKHOLM TABLE D6

Recommended weight capacity: 50KG.

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love



#### Love it? Share it!

Fantastic buy! Share how it looks at home for your chance to win a \$250 Fantastic Furniture Gift Card!

fantasticfurniture




### **Assembly Checklist**



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.




Unless instructed, do not fully tighten screws until the item is fully assembled.

#### **Useful Information**

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need to assemble the product







#### Parts list


Top Panel (P1); 4 x Legs (P2);

#### Hardware pack





Attach  $4 \times \text{Legs}$  (P2) to Top Panel (P1) and secure with 16  $\times$  Bolts (H1). Tighten with an Allen Key (H2).




# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0





STOCKHOLM LOWLINE MEDIUM 1600MM

Recommended weight capacity: 10kgs/shelf.



## WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Connecting attachments for your wall are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what wall connections to use.

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love



#### Love it? Share it!

Fantastic buy! Share how it looks at home for your chance to win a \$250 Fantastic Furniture Gift Card!

fantasticfurniture




### **Assembly Checklist**




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

#### **Useful Information**

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need to assemble the product







Other tools you need:
Phillips head screwdriver;


#### Parts list


Top Panel (P1); Left Side Panel (P2); Right Side Panel (P3); Bottom Panel (P4); 2 x Shelf Panels (P5); Shelf Panel (P6): Shelf Panel (P7); Shelf Panel (P8); 2 x Back Panels (P9); Back Panel (P10); Rail (P11); Shelf Panel (P12); Door (P13); Door (P14); 4 x Legs (P15); 2 x Support Legs (P16); Drawer Fronts (P17); Drawer Backs (P18); Left Drawer Sides (P19); Right Drawer Sides (P20); Drawer Bases (P21);






#### Hardware pack






Attach 1 x CL Runner Track (H6) to Shelf Panel (P8) with 3 x Small Screws (H5). Attach 1 x CR Runner Track (H7) to Right Side Panel (P3) with 3 x Small Screws (H5). Tighten with a Phillips Head Screwdriver.

#### Step 2




Attach 12 x Cam Bolts (H3) to Top Panel (P1), Right Side Panel (P3) and Shelf Panel (P8). Tighten with a Phillips Head Screwdriver.





Attach 2 x Hinges (H11,H12) and 2 x Screws (H13) to Doors (P13,P14), securing with 8 x Small Screws (H10). Tighten with a Phillips Head Screwdriver.


#### Step 4




Attach 3 x Catchers (H14) to Top Panel (P1), Bottom Panel (P4) secure with 12 x Small Screws (H5). Tighten with a Phillips head screwdriver.











Attach Right Side Panel (P3) and Shelf Panel (P8) to Shelf Panel (P6) with  $4 \times 1$  Dowels (H1) and secure with  $4 \times 1$  Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.


#### Step 6






Attach Bottom Panel (P4) to Left Side Panel (P2), Right Side Panel (P3), Shelf Panel (P7) and Shelf Panel (P8) with 8 x Dowels (H1) and secure with 8 x Long Screws (H2). Tighten with a Phillips Head Screwdriver.








Attach 4 x Plates (H25) and 4 x Legs (P15) secure with 8 x Long Screws (H26), attach 4 x Legs (P15) and 2 x Support Legs (P16) to Bottom Panel (P4) and secure with 16 x Bolts (H15). Tighten with an Allen Key (H16). Insert the 2 x Adjusters (H24) into the middle Support Legs (P16).


#### Step 8




Slide remaining Back Panels (P9,P10) into the groovesof Left Side Panel (P2), Shelf Panel (P7), Shelf Panel (P8) and Right Side Panel (P3).











Attach Top Panel (P1) to Left Side Panel (P2), Right Side Panel (P3), Shelf Panel (P7) and Shelf Panel (P8) with 8 x Dowels (H1) and secure with 8 x Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.






Press Shelf Panel (P12) against Right Side Panel (P3), then slide Shelf Panel (P12) between Shelf Panel (P6) and Top Panel (P1) to form the unit as shown. Attach Shelf Panel (P12) to Right Side Panel (P3) with 2 x Screws (H17). Tighten with a Phillips Head Screwdriver.





Press Rail (P11) against Top Panel (P1), then slide Rail (P11) between Shelf Panel (P12) and Top Panel (P1) to form the unit as shown. Attach Rail (P11) to Top Panel (P1) with 2 x Screws (H17). Tighten with a Phillips Head Screwdriver.


#### Step 12



Insert 8  $\times$  Shelf Plugs (H23) into the end cavities of the cabinet as shown. Insert the 2  $\times$  Shelf Panels (P5) and balance on top of the plugs.








Secure Door Panels (P13, P14) to the main unit by attaching the other end of the 2 x Hinges (H11,H12) with 16 x Small Screws (H10) as shown. Tighten with a Phillips Head Screwdriver.


#### Step 14






Attach  $4 \times \text{Cam}$  Bolts (H3) and  $1 \times \text{Screw}$  (H13) to Drawer Front (P17) as shown. Tighten with a Phillips Head Screwdriver.






Attach Drawer Sides (P19, P20) to Drawer Front (P17). Insert 4 x Cam Nuts (H4) into the holes of Drawer Sides (P19, P20). Make sure the opening on cam nuts point towards the incoming cam bolts. Tighten with a Phillips Head Screwdriver.


#### Step 16



Slide the Drawer Base (P21) into the grooves between drawer sides as shown.

#### Step 17






Attach Drawer Back (P18) to Drawer Sides (P19, P20) with  $4 \times 1$  Screws (H17), make sure that the groove lines up the whole way around the drawer. Tighten with a Phillips Head Screwdriver.









Attach 1 x DL Runner (H8) to Left Drawer Side (P19) and 1 x DR Runner (H9) to Right Drawer Side (P20) with  $4 \times \text{Small Screws}$  (H5) using a Phillips Head Screwdriver.

#### Step 19





If the doors and drawer fronts are not flush or can't be bounced. Please adjust the head of Catcher accordingly.



Insert the assembled drawers into the corresponding compartments as shown. Ensure the drawers slide easily along the rails.







Use 1  $\times$  Screw (H21) and 1  $\times$  Washer (H22) to connect 1  $\times$  Safety Strap (H20) on Top Panel (P1). Secure Back Panels (P9,P10) in place with 12  $\times$  Wedges (H18) using 12  $\times$  Screws (H19). Tighten with a Phillips Head Screwdriver.

#### Step 21




Screw and Wall Plug are not provided. Please use appropriate fixtures for your wall. trades person on how to attach this safety strap to your specific wall.

H22
Wall
Screw

Seek advice from a qualified

Move the entertainment unit to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.







# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0





STOCKHOLM COFFEE TABLE RECTANGLE

Recommended weight capacity: 10kgs/shelf.

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love



#### Love it? Share it!

Fantastic buy! Share how it looks at home for your chance to win a \$250 Fantastic Furniture Gift Card!

fantasticfurniture




### **Assembly Checklist**




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

#### **Useful Information**

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

## What you need


to assemble the product




Other tools you need:
Phillips head screwdriver;


#### Parts list


Box 1: Top Panel (P1); Left Side Panel (P2); Right Side Panel (P3); Bottom Panel (P4); Shelf Panel (P5); Back Panel (P6); 4 x Legs (P7); Drawer Front (P8); Drawer Back (P9); Left Drawer Side (P10); Right Drawer Side (P11); Drawer Base (P12); Rail (P13); Support (P14);






#### Hardware pack






Attach 6 x Cam Bolts (H3) to Top Panel (P1) as shown. Attach 1 x Catcher (H12) to Bottom Panel (P4) and secure with 4 x Small Screws (H5). Tighten with a Phillips Head Screwdriver.


#### Step 2




Attach 1 x CL Runner Track (H6) to Shelf Panel (P5) with 3 x Small Screws (H5). Attach 1 x CR Runner Track (H7) to Right Side Panel (P3) with 3 x Small Screws (H5). Tighten with a Phillips Head Screwdriver.












Attach Left Side Panel (P2), Back Side Panel (P6), Shelf Panel (P5) and Right Side Panel (P3) to Top Panel (P1) secure with 8 x Dowels (H1) and secure with 6 x Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.


### Step 4






Attach Bottom Panel (P4) to Right Side Panel (P3), Back Side Panel (P6), Shelf Panel (P5) and Left Side Panel (P2) with 8 x Dowels (H1) and secure with 6 x Long Screws (H2). Tighten with a Phillips Head Screwdriver. Attach Support (P14) to Bottom Panel (P4) and secure with 4 x Long Bolts (H17). Tighten with an Allen Key (H10).






Attach 4 x Plates (H15) and 4 x Legs (P7) secure with 8 x Long Screws (H16), attach 4 x Legs (P7) to Bottom Panel (P4) and secure with 16 x Bolts (H13). Tighten with an Allen Key (H10).


#### Step 6







Attach  $5 \times Cam$  Bolts (H3) and  $1 \times Screws$  (H11) to Drawer Front (P8) as shown. Tighten with a Phillips Head Screwdriver.











Attach Drawer Sides (P10, P11) to Drawer Front (P8). Insert 5 x Cam Nuts (H4) into the holes of Drawer Sides (P10, P11,P13). Make sure the opening on cam nuts point towards the incoming cam bolts. Tighten with a Phillips Head Screwdriver.


#### Step 8



Fantastic Furniture PAGE 8

Slide the Drawer Base (P12) into the grooves between drawer sides as shown.






Attach Drawer Back (P9) to Drawer Sides (P10, P11,P13) with 5 x Screws (H14), make sure that the groove lines up the whole way around the drawer. Tighten with a Phillips Head Screwdriv.


#### Step 10






Attach 1 x DL Runner (H8) to Left Drawer Side (P10) and 1 x DR Runner (H9) to Right Drawer Side (P11) with  $4 \times 5$  Small Screws (H5) using a Phillips Head Screwdriver.





Insert the assembled drawer into the corresponding compartment as shown. Ensure the drawer slide easily along the rails.




## **Job Complete!**

In the interest of our environment please dispose of all packaging thoughtfully.





Version 1.0



# STOCKHOLM

Recommended weight capacity: 40kgs.

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love



#### Love it? Share it!

Fantastic buy! Share how it looks at home for your chance to win a \$250 Fantastic Furniture Gift Card!

fantasticfurniture




## **Assembly Checklist**



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

#### **Useful Information**

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

## What you need


to assemble the product




Other tools you need:
Phillips head screwdriver;


#### Parts list


Top Panel (P1);
Left Side Panel (P2);
Right Side Panel (P3);
Bottom Panel (P4);
Shelf Panel (P5);
2 x Shelf Panels (P6);
Rail (P7);
Back Panel (P8);
4 x Legs (P9);
Drawer Front (P10);
Drawer Back (P11);
Left Drawer Side (P12);
Right Drawer Side (P13);
Drawer Base (P14);






#### Hardware pack






Attach 4 x Cam Bolts (H3) to Top Panel (P1) as shown. Tighten with using a Phillips Head Screwdriver. Attach 1 x Magnetic Catcher (H13) to Bottom Panel (P4) and secure with 4 x Small Screws (H5). Tighten with a Phillips Head Screwdriver.




Attach 4 x Cam Bolts (H3) to Left Side Panel (P2) and Right Side Panel (P3) as shown. Tighten with a Phillips Head Screwdriver. Attach  $1 \times CL$  Runner Track (H6) to Left Side Panel (P2) with  $3 \times Small$  Screws (H5). Attach  $1 \times CR$  Runner Track (H7) to Right Side panel (P3) with  $3 \times Small$  Screws (H5). Tighten with a Phillips Head Screwdriver.






Attach Left Side Panel (P2) and Right Side Panel (P3) to Shelf Panel (P5) with  $4 \times 1$  Dowels (H1) and secure with  $4 \times 1$  Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.

#### Step 4






Attach Left Side Panel (P2) and Right Side Panel (P3) to Top Panel (P1) with 4 x Dowels (H1) and secure with 4 x Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.









Press 2 x Shelf Panels (P6) against Shelf Panels (P2,P3), then slide 2 x Shelf Panels (P6) between Shelf Panels (P5) and Top Panel (P1) to form the unit as shown. Attach 2 x Shelf Panels (P6) to Left Side Panel (P2) and Right Side Panel (P3) secure with 4 x Screws (H16). Tighten with a Phillips Head Screwdriver.









Slide remaining Back Panels (P8) into the groovesof Left Side Panel (P2) and Right Side Panel (P3). Press Rail (P7) against Top Panel (P1), then slide Rail (P7) between Left Side Panel (P2) and Right Side Panel (P3) to form the unit as shown. Attach Rail (P7) to Top Panel (P1) secure with 2 x Small Bolts (H19). Tighten with a Phillips Head Screwdriver.


Fantastic Furniture







Attach Bottom Panel (P4) to Left Side Panel (P2) and Right Side Panel (P3) with 4 x Dowels (H1) and secure with 4 x Long Screws (H2). Tighten with a Phillips Head Screwdriver.

#### Step 8









Ensure the countersunk holes on the Leg Plate are face up, so that

Attach 4 x Plates (H17) and 4 x Legs (P9) secure with 8 x Long Screws (H18), attach 4 x Legs (P9) to Bottom Panel (P4) and secure with 16 x Bolts (H14). Tighten with an Allen Key (H15).









Attach  $4 \times \text{Cam}$  Bolts (H3) and  $1 \times \text{Screw}$  (H12) to Drawer Front (P10) as shown. Tighten with a Phillips Head Screwdriver.

## Step 10




Attach Drawer Sides (P12, P13) to Drawer Fronts (P10). Insert 4 x Cam Nuts (H4) into the holes of Drawer Sides (P12, P13). Make sure the opening on cam nuts point towards the incoming cam bolts. Tighten with a Phillips head screwdriver.





Slide the Drawer Base (P14) into the grooves between drawer sides as shown.


## Step 12



Attach Drawer Back (P11) to Drawer Sides (P12, P13) with  $4 \times 1$  Long Screws (H2), make sure that the groove lines up the whole way around the drawer. Tighten with a Phillips Head Screwdriver.









Attach 1  $\times$  DL Runner (H8) to Left Drawer Side (P12) and 1  $\times$  DR Runner (H9) to Right Drawer Side (P13) with 4  $\times$  Small Screws (H5) using a Phillips Head Screwdriver.

#### Step 14





To open the drawer, firmly press the middle of the drawer front to trigger the Catch to bounce the drawer open. If the drawer does not pop open when pressed or is not sitting flush with the front of the unit, reach to the Rail and adjust the head of the Catch by gently turning left or right to reach the right resistance.




Insert the assembled drawer into the corresponding compartment as shown. Ensure the drawer slide easily along the rails.







Secure Back Panel (P8) in place with 4 x Wedges (H10) using 4 x Wedge Screws (H11). Tighten with a Phillips Head Screwdriver.




## **Job Complete!**


In the interest of our environment please dispose of all packaging thoughtfully.





Version 1.0





STOCKHOLM BUFFET 2 DOOR Recommended weight capacity: 60kgs.



## WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Connecting attachments for your wall are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what wall connections to use.

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love



#### Love it? Share it!

Fantastic buy! Share how it looks at home for your chance to win a \$250 Fantastic Furniture Gift Card!

fantasticfurniture




## **Assembly Checklist**



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

#### **Useful Information**

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product





Other tools you need: Phillips head screwdriver;

#### Parts list

Top Panel (P1);

Left Side Panel (P2);

Right Side Panel (P3);

Bottom Panel (P4);

2 x Shelf Panels (P5);

Shelf Panel (P6):

Shelf Panel (P7);

Shelf Panel (P8);

2 x Back Panels (P9);

Back Panel (P10);

Rail (P11); Shelf Panel (P12);

Door (P13); Door (P14);

4 x Legs (P15);

2 x Support Legs (P16);

2 x Drawer Fronts (P17);

2 x Drawer Backs (P18);


2 x Left Drawer Sides (P19);


2 x Right Drawer Sides (P20);

2 x Drawer Bases (P21);

Rail (P22)

#### Hardware pack












#### Step 1 You will need H6 (P8) 2 x CL Runner 2 x CR Runner Tracks (H6) Tracks (H7) (P3) **H5** Phillips Head 12 x Small Screwdriver Screws (H5) **H5** CR 00


Attach 2 x CL Runner Tracks (H6) to Shelf Panel (P8) with 6 x Small Screws (H5). Attach 2 x CR Runner Tracks (H7) to Right Side Panel (P3) with 6 x Small Screws (H5). Tighten with a Phillips Head Screwdriver.

#### Step 2




Attach 14 x Cam Bolts (H3) to Top Panel (P1), Right Side Panel (P3) and Shelf Panel (P8). Tighten with a Phillips Head Screwdriver.







Attach 2  $\times$  Hinges (H12) and 1  $\times$  Screws (H13) to Door (P13), attach 2  $\times$  Hinges (H11) and 1 x Screws (H13) to Door (P14), securing with 8 x Small Screws (H10). Tighten with a Phillips Head Screwdriver. Make sure the Hinges (H11) are assembled on Door (P14), the Hinges (H12) are assembled on door (P13).




Attach 4 x Magnetic Catchers (H14) to Top Panel (P1), Bottom Panel (P4) and Rail (P22) secure with 16 x Small Screws (H5). Tighten with a Phillips head screwdriver.











Attach Right Side Panel (P3) and Shelf Panel (P8) to Shelf Panel (P6) and Rail (P22) with 6 x Dowels (H1) and secure with 6 x Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.

## Step 6






The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.




Attach Top Panel (P1) to Left Side Panel (P2), Right Side Panel (P3), Shelf Panel (P7) and Shelf Panel (P8) with 8 x Dowels (H1) and secure with 8 x Cam Nuts (H4). Tighten with a Phillips Head Screwdriver.






Slide remaining Back Panels (P9,P10) into the groovesof Left Side Panel (P2), Shelf Panel (P7), Shelf Panel (P8) and Right Side Panel (P3).


## Step 8





Attach Bottom Panel (P4) to Left Side Panel (P2), Right Side Panel (P3), Shelf Panel (P7) and Shelf Panel (P8) with 8 x Dowels (H1) and secure with 8 x Long Screws (H2). Tighten with a Phillips Head Screwdriver.






Attach 6 x Plates (H25) to 4 x
Legs (P15) and 2 x Support legs
(P16) secure with 12 x Long Screws
(H26), attach 4 x Legs (P15) and 2 x
Support Legs (P16) to Bottom Panel (P4) and secure with 24 x Bolts (H15). Tighten with an Allen Key (H16). Insert the 2 x Adjusters (H24) into the middle Support Legs (P16).


H24 (P15) (P16) H24 (P16) (P4) (P15) H15 **Ensure the countersunk** holes on the Leg Plate are face up, so that the Screws sit flush with the top of the Leg Plate once H25 attached. (P15)

(P15)




Press Shelf Panel (P12) against Right Side Panel (P3), then slide Shelf Panel (P12) between Shelf Panel (P6) and Top Panel (P1) to form the unit as shown. Attach Shelf Panel (P12) to Right Side Panel (P3) with 2 x Screws (H17). Tighten with a Phillips Head Screwdriver.


Fantastic Furniture PAGE 9



Press Rail (P11) against Top Panel (P1), then slide Rail (P11) between Shelf Panel (P12) and Top Panel (P1) to form the unit as shown. Attach Rail (P11) to Top Panel (P1) with 2 x Screws (H17). Tighten with a Phillips Head Screwdriver.


#### Step 12






Insert 8  $\times$  Shelf Plugs (H23) into the end cavities of the cabinet as shown. Insert the 2  $\times$  Shelf Panels (P5) and balance on top of the plugs.






To open the door, firmly press the middle or top left of the door front to trigger the Catch to bounce the door open. If the door does not pop open when pressed or is not sitting flush with the front of the unit, reach bottom of top panel and adjust the head ofthe Catch by gently turning left or right to reach the right resistance.



Secure Door Panels (P13, P14) to the main unit by attaching the other end of the 2 x Hinges (H11,H12) with 16 x Small Screws (H10) as shown. Tighten with a Phillips Head Screwdriver.


#### Step 14


You will need	
8 x Cam Bolts (H3)	Phillips Head Screwdriver
*	
2 x Screws (H13)	




Attach  $4 \times Cam$  Bolts (H3) and  $1 \times Screw$  (H13) to Drawer Front (P17) as shown. Tighten with a Phillips Head Screwdriver.











Attach Drawer Sides (P19, P20) to Drawer Fronts (P17). Insert  $4 \times 2$  Cam Nuts (H4) into the holes of Drawer Sides (P19, P20). Make sure the opening on cam nuts point towards the incoming cam bolts. Tighten with a Phillips head screwdriver.


#### Step 16



Slide the Drawer Base (P21) into the grooves between drawer sides as shown.


#### Step 17






Attach Drawer Back (P18) to Drawer Sides (P19, P20) with 4 x Long Screws (H2), make sure that the groove lines up the whole way around the drawer. Tighten with a Phillips Head Screwdriver.








Attach 1 x DL Runner (H8) to Left Drawer Side (P19) and 1 x DR Runner (H9) to Right Drawer Side (P20) with  $4 \times 5$  Small Screws (H5) using a Phillips Head Screwdriver.


#### Step 19




To open the drawer, firmly press the middle of the drawer front to trigger the Catch to bounce the drawer open. If the drawer does not pop open when pressed or is not sitting flush with the front of the unit, reach to the Rail& bottom panel and adjust the head of the Catch by gently turning left or right to reach the right resistance.


Insert the assembled drawers into the corresponding compartments as shown. Ensure the drawers slide easily along the rails.








Use 1 x Safety Screw (H21) and 1 x Washer (H22) to connect 1 x Safety Strap (H20) on Top Panel (P1). Secure Back Panels (P9,P10) in place with 12 x Wedges (H18) using 12 x Wedge Screws (H19). Tighten with a Phillips Head Screwdriver.



Move the buffet unit to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.






# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.

#### TO ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN


#### STEP 1

Open the door.




#### STEP 1

Adjust the door move in or out a little




Loosen the screw indicated a little, adjust the hinge to right position (see step 2a & 2B), then tighten screw.

#### STEP 2a MOVE DOOR IN




Push the hinge back a little.

#### STEP 2b MOVE DOOR OUT




Pull the hinge forward a little.

# STEP 3 To adjust the gap between




Loosen or tighten the screw indicated a little to adjust the gap between door and side panel (see step 3a & step 3b)

#### STEP 3a MOVE DOOR RIGHT STEP 3b MOVE DOOR LEFT



Turn the screw clockwise a litte as shown to make the gap big.



Turn the screw counterclockwise a litte as shown to make the gap small.

