




**Fantastic
Furniture**

Version 1.0



Two People



Required

Java
Buffet 3 Door
fantasticfurniture.com.au



Warning: Ensure the wall strap is attached to avoid serious injury

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Rattan

Rattan is a natural material that will respond to humidity in the environment. Low humidity may cause the rattan to shrink. High humidity may cause the rattan to absorb moisture and expand, causing the weaving to look loose and wavy.

This is a natural phenomenon and not a defect.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE



Other tools you need

Flat Head Screwdriver;
Phillips Head Screwdriver;
Mallet;
Hammer



Parts list


Carton 1:

1 x Bottom Panel (P2)
4 x Legs (P9)

Carton 2:

1 x Top Panel (P1)
2 x Side Panels (P3)
1 x Left Divider Panel (P4)
1 x Right Divider Panel (P5)
3 x Shelves (P6)
1 x Back Panel (P7)
3 x Doors (P8)


Hardware Pack



16 x Cam Bolts
(H1)



16 x Cam
Nuts (H2)



16 x Dowels
(H3)



3 x Handles
(H4)



4 x Felt Feet
(H5)



10 x Screws 16mm
(H6)



6 x Back Panel
Connectors (H7)




8 x Bolts 55mm
(H8)



12 x Flat Washers
(H9)




8 x Spring
Washers (H10)



6 x Screws 28mm
(H11)



1 x Allen Key
(H12)




2 x Wall Straps
(H13)



2 x Screws 25mm
(H14)




12 x Screws 12mm
(H15)




12 x Screws 17mm
(H16)



6 x Hinges
(H17)



12 x Shelf Pins
(H18)




6 x Stoppers
(H19)



12 x Screws 12mm
(H20)

Step 1



You will need	
4 x Felt Feet (H5)	



Attach 1 x felt foot (H5) onto each leg (P9) as shown.

Step 2

You will need	
8 x Bolts 55mm (H8)	8 x Flat Washers (H9)
8 x Spring Washers (H10)	1 x Allen Key (H12)







Attach 1 x leg (P9) onto bottom panel (P2) using 2 x bolts (H8), 2 x spring washers (H10) and 2 x flat washers (H9).


Tighten the bolts with allen key (H12).

Repeat this step for the other 3 x legs (P9).

With assistance, turn the assembled frame over.





Step 3


You will need	
	
8 x Cam Bolts (H1)	Phillips Head Screwdriver
	
6 x Screws 12mm (H20)	3 x Stoppers (H19)



Screw 8 x cam bolts (H1) into bottom panel (P2), using a phillips head screwdriver. Attach 3 x stoppers (H19) onto bottom panel (P2) with 6 x screws (H20) as shown, tightening with a phillips head screwdriver.



Step 4


You will need	
	
8 x Cam Bolts (H1)	Phillips Head Screwdriver
	
6 x Screws 12mm (H20)	3 x Stoppers (H19)



Screw 8 x cam bolts (H1) into top panel (P1), using a phillips head screwdriver. Attach 3 x stoppers (H19) onto top panel (P1) with 6 x screws (H20) as shown, tightening with a phillips head screwdriver.



Step 5

You will need	
	
16 x Dowels (H3)	Mallet




Insert 4 x dowels (H3) into each panel (P3, P4, P5) as shown.
Use a mallet to gently tap the dowels into place if needed.

Step 6


You will need	
	
8 x Cam Nuts (H2)	Flat Head Screwdriver

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Position the panels (P3 x 2, P4, P5) onto bottom panel (P2) as shown. Ensure the grooves on 2 x side panels (P3) align with the grooves on bottom panel (P2). Insert 8 x cam nuts (H2) into panels (P3 x 2, P4, P5). Rotate the cam nuts so the arrow faces incoming cam bolts. Using a flat head screwdriver turn clockwise to lock.





Step 7





Unfold and slide back panel (P7) into the groove of panels (P2, P3 x 2).

Step 8




You will need	
	
8 x Cam Nuts (H2)	Flat Head Screwdriver


Two People



With assistance, position top panel (P1) onto panels (P3 x 2, P4, P5). Ensure the grooves on the top panel (P1) align with the grooves on the 2 x side panels (P3). Insert 8 x cam nuts (H2) into panels (P3 x 2, P4, P5) and lock by turning clockwise using a flat head screwdriver.

Step 9

You will need	
	
10 x Screws 16mm (H6)	6 x Back Panel Connectors (H7)
	
Phillips Head Screwdriver	






If necessary, gently adjust the top panel (P1) sideways in either direction until XX and YY are equal.

Holding it in place, fix 6 x back panel connectors (H7) to assembled unit with 6 x screws (H6) as shown, using a phillips head screwdriver.

Fasten back panel (P7) to divider panels with 4 x screws (H6), using a phillips head screwdriver.

Step 10

You will need	
	
12 x Shelf Pins (H18)	Mallet









Insert 12 x shelf pins (H18) into desired holes in panels (P3 x 2, P4, P5).

Use a mallet to gently tap them into place if needed.

Place 3 x shelves (P6) onto shelf pins (H18).



Step 11


You will need	
	
12 x Screws 12mm (H15)	6 x Hinges (H17)
	
3 x Handles (H4)	6 x Screws 28mm (H11)
	
Phillips Head Screwdriver	



Insert 2 x hinges (H17) onto each door (P8), attach with 4 x screws (H15), tightening using a phillips head screwdriver. Attach 3 x handles (H4) to doors (P8) with 6 x screws (H11), tightening using a phillips head screwdriver.

Step 12

You will need	
	
Phillips Head Screwdriver	12 x Screws 17mm (H16)




Attach doors onto assembled unit as shown. Fix 6 x hinges (H17) onto panels (P3) and (P5) with 12 x screws (H16), tightening using a phillips head screwdriver.

TO ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN (OPTIONAL).


STEP 1

Open the door.




STEP 2

Adjust the door panel to be flush with side panel and top panel edge.




Slightly loosen the screw indicated and adjust the hinge to the desired position (see step 2a & 2b), then tighten the screw with a phillips head screwdriver.

STEP 2a MOVE DOOR OUT



Slightly pull the hinge forward.


STEP 2b MOVE DOOR IN



Slightly push the hinge back.


STEP 3

Adjust the gap between door panel and side panel.




Slightly loosen or tighten the screw indicated and adjust the hinge to the desired position (see step 3a & 3b).

STEP 3a MOVE DOOR LEFT



Slightly turn the screw clockwise to make the gap smaller.





STEP 3b MOVE DOOR RIGHT




Slightly turn the screw counterclockwise to make the gap larger.

Step 13



We strongly recommend that this product is permanently fixed to the wall or other suitable surface.

You will need	
	
2 x Flat Washers (H9)	2 x Screws 25mm (H14)
	
2 x Wall Straps (H13)	Phillips Head Screwdriver




Fasten 2 x wall straps (H13) on top panel (P1) with 2 x screws (H14) and 2 x flat washers (H9), tighten using a phillips head screwdriver.


Step 14

You will need	
	
2 x Flat Washers (H9)	Phillips Head Screwdriver

Two People




Seek advice from a qualified trades person on how to attach this wall strap to your specific wall.



Screw and wall plug are not included. Please use appropriate fixtures for your wall.

With assistance, move the buffet to the final position. Attach the wall straps to the wall with the appropriate fixtures. Make sure they are firmly attached and secure.

Step 15



Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.