




**Fantastic  
Furniture**

Version 1.0



# Hamilton

Coffee Table Rectangle

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)

Recommended weight capacity : 30kgs on top.

## Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture  
to help create a home you'll love!



# Fantastic Furniture

### Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for  
your chance to win a \$250 Fantastic Furniture Gift Card!

**@fantasticfurniture**


# Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need


to assemble the product



DO NOT USE



**Other tools you need:**  
Phillips head screwdriver;



## Parts list

Top Panel (P1);  
2 x Side Panels (P2);  
Shelf Panel (P3);  
4 x Rails (P4);

## Hardware pack



4 x Dowels  
(H1)




8 x Bolts  
(H2)



8 x Nuts  
(H3)



12 x Long  
Screws  
(H4)






4 x Cam  
Bolts  
(H5)



4 x Cam  
Nuts  
(H6)





# Step 1



You will need	
	
6 x Long Screws (H4)	Phillips Head Screwdriver



Attach Rails (P4x2) to Bottom Panel (P3) with 6 x Screws (H4) by tightening with the Phillips Head Screwdriver.





# Step 2


You will need	
	
2 x Dowels (H1)	4 x Bolts (H2)
	
4 x Nuts (H3)	Phillips Head Screwdriver



Insert 2 x Dowels (H1) into Bottom Panel (P3). Push 4 x Bolts (H2) through Side Panel (P2) and insert 4 x Nuts (H3) into Rails (P4x4). Rotate the nuts so the opening point towards the incoming bolts. Attach Rails (P4x4) to Side Panel (P2) by tightening all nuts with the Phillips Head Screwdriver.



## Step 3


You will need	
	
4 x Bolts (H2)	4 x Nuts (H3)
	
2 x Dowels (H1)	Phillips Head Screwdriver



Insert 2 x Dowels (H1) into Bottom Panel (P3). Push 4 x Bolts (H2) through Side Panel (P2) and insert 4 x Nuts (H3) into Rails (P4x4). Rotate the nuts so the opening point towards the incoming bolts. Attach Rails (P4x4) to Side Panel (P2) by tightening all nuts with the Phillips Head Screwdriver.




## Step 4

You will need	
	
4 x Cam Bolts (H5)	Phillips Head Screwdriver




Attach 4 x Cam Bolts (H5) to Top Panel (P1) by tightening with the Phillips Head Screwdriver.


## Step 5

You will need	
	
6 x Long Screws (H4)	4 x Cam Nuts (H6)
	
Phillips Head Screwdriver	


This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Insert 4 x Cam Nuts (H6) into Side Panels (P2x2) as shown. Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Rails (P4x2) and Side Panels (P2x2) to Top Panel (P1) with 6 x Long Screws (H4) by tightening with the Phillips Head Screwdriver.



## Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.